

Teensy4.1

U1
DEV-16771

Power and Ground:

- VIN:** +5V (green line)
- 3.3V:** 3.3V (blue line)
- GND:** GND (green line)

Control and Status:

- PROGRAM:** PROGRAM (blue line)
- QW/INT:** QW/INT (blue line)
- Main_RST:** Main_RST (blue line)

Module Connections:

- RXteensy-TXArduino-3V3:** 0
- TXteensy-RXArduino-3V3:** 1
- Buzzer:** 2
- SWstart:** 4
- Motoren:** 5
- RXteensy-TXESP32C301:** 6
- TXteensy-RXESP32C301:** 7
- Motor1PWM:** 8
- Motor2PWM:** 9
- Motor3PWM:** 10
- Motor4PWM:** 11
- TXteensy-RXESP32C302:** 12
- RXteensy-TXESP32C302:** 13
- RXteensy-TXunitV1:** 14
- TXteensy-RXunitV1:** 15
- SDA:** 16
- SCL:** 17

Pinout Table:

Pin	Function	Module
0	TX1	RXteensy-TXArduino-3V3
1	RX7	TXteensy-RXArduino-3V3
2	OUT2	Buzzer
3	LRCLK2	
4	BCLK2	SWstart
5	IN2	Motoren
6	OUT1D	RXteensy-TXESP32C301
7	RX2	TXteensy-RXESP32C301
8	TX2	Motor1PWM
9	OUT1C	Motor2PWM
10	CS1	Motor3PWM
11	MOSI	Motor4PWM
12	MISO	TXteensy-RXESP32C302
13	SCK	RXteensy-TXESP32C302
14	A0	RXteensy-TXunitV1
15	A1	TXteensy-RXunitV1
16	A2	SDA
17	A3	SCL
18	A4	
19	A5	
20	A6	TXteensy-RXunitV2
21	A7	RXteensy-TXunitV2
22	A8	DribblerFront-EN
23	A9	DribblerFront-PWM
24	A10	TXteensy-RXunitV3
25	A11	RXteensy-TXunitV3
26	A12	BallCatchFront
27	A13	BallCatchBack
28	A14	TXteensy-RXunitV4
29	A15	RXteensy-RXunitV4
30	CRX3	KickerStroke
31	CTX3	Kickertip
32	OUT1B	ENaost
33	MCLK2	LED
34	RX8	RXteensy-TXunitV5
35	TX8	TXteensy-RXunitV5
36	CS2	DribblerBack
37	CS3	
38	A14	
39	A15	
40	A16	
41	A17	

Level-Conversion

Connector_Relay

The diagram shows a 17-pin connector labeled J1, Conn_Relay. The connections are as follows:

- Pin 1: MotorEN
- Pin 2: TXteensy-RXArduino-5V
- Pin 3: Motor1PWM
- Pin 4: RXteensy-TXArduino-5V
- Pin 5: Motor2PWM
- Pin 6: DribblerFront-PWM
- Pin 7: Motor3PWM
- Pin 8: DribblerFront-EN
- Pin 9: Motor4PWM
- Pin 10: (Unlabeled)
- Pin 11: BallCatchFront
- Pin 12: (Unlabeled)
- Pin 13: (Unlabeled)
- Pin 14: BallCatchBack
- Pin 15: DribblerBack
- Pin 16: Kickertip
- Pin 17: KickersStroke
- Pin 18: EN800ST

Power supply connections are indicated at the top: +3.3V and +5V. A ground connection is shown at the bottom, labeled GND.

Buzzer

The diagram shows a circuit for a buzzer. A 5V supply is connected to a buzzer component (labeled BZ1 Buzzer) through a 1k resistor (labeled R6). The buzzer component is connected to ground (GND).

Diagram illustrating the J2 connector pinout for the RXteensy board. The pins are numbered 1 through 18, and the connections are as follows:

- Pin 1: +3.3V
- Pin 2: RXteensy-TXunitV2
- Pin 3: RXteensy-RXunitV2
- Pin 4: RXteensy-RXunitV1
- Pin 5: RXteensy-TXunitV1
- Pin 6: RXteensy-TXESP32C302
- Pin 7: RXteensy-RXESP32C302
- Pin 8: TXteensy-RXunitV5
- Pin 9: SWSTART
- Pin 10: RXteensy-TXunitV5
- Pin 11: GND
- Pin 12: GND
- Pin 13: RXteensy-TXESP32C301
- Pin 14: TXteensy-RXESP32C301
- Pin 15: RXteensy-TXunitV3
- Pin 16: TXteensy-RXunitV3
- Pin 17: TXteensy-RXunitV4
- Pin 18: RXteensy-TXunitV4

A circuit diagram showing an LED connected in series with a resistor (R9, 330 ohms) and a diode (D1, LED_Small) to ground (GND). The LED is represented by a green rectangle with the label 'LED' inside. The resistor is a yellow rectangle with 'R9' and '330' next to it. The diode is a red symbol with 'D1' and 'LED_Small' next to it. The ground is represented by a triangle symbol with 'GND' below it.