# **Software Writing for Timer and Debugging**

## Introduction

This lab guides you through the process of writing a software application that utilizes the private timer of the CPU. You will refer to the timer's API in the SDK to create and debug the software application. The application you will develop will monitor the switch values and increment a count on the LEDs. The application will exit when the center push button is pressed.

# **Objectives**

After completing this lab, you will be able to:

- Utilize the CPU's private timer in polled mode
- Use SDK Debugger to set break points and view the content of variables and memory

#### **Procedure**

This lab is separated into steps that consist of general overview statements that provide information on the detailed instructions that follow. Follow these detailed instructions to progress through the lab.

This lab comprises 4 primary steps: Open the project in Vivado, create a SDK software project, verify operation in hardware, and launch the debugger and debug the design.

# **Design Description**

You will use the hardware design created in lab 3 to use CPU's private timer (see **Figure 1**). You will develop the code to use it.





Figure 1. Design updated from Previous Lab

## **General Flow for this Lab**



In the instructions below;

{ sources} refers to: C:\Xilinx\_trn\Zynq\_base\lab\_sources

 $\{labs\}$  refers to : C:\Xilinx\_trn\Zynq\_base

## **Open the Project in Vivado**

Step 1

- 1-1. Use the lab4 project from the last lab and save it as *lab5*. Open the project in Vivado and then export to SDK.
- **1-1-1.** Start the Vivado if necessary and open the lab4 project (lab4.xpr) you created in the previous lab using the **Open Project** link in the Getting Started page.
- **1-1-2.** Select **File > Project > Save As** ... to open the *Save Project As* dialog box. Enter **lab5** as the project name. Make sure that the *Create Project Subdirectory* option is checked, the project directory path is *C:/Xilinx\_trn/Zynq\_base* and click **OK**.

This will create the lab5 directory and save the project and associated directory with lab4 name.

Since we will be using the private timer of the CPU, **which is always present**, we don't need to modify the hardware design.

- **1-1-3.** Open the Block Design. You may notice that the status changes to synthesis and implementation out-of-date as the project was *saved as*. Since the bitstream is already generated and will be in the exported directory, we can safely ignore any warning about this.
- 1-2. Export the hardware along with the generated bitstream to SDK.
- 1-2-1. Click File > Export > Export Hardware.
- **1-2-1.1.** Click on the checkbox of *Include the bitstream*
- 1-2-1.2. Click **OK** and then click **Yes** to overwrite.
- 1-2-2. Select File > Launch SDK and click OK.
- 1-2-3. Click Yes.

## **Create an SDK Software Project**

Step 2

- 2-1. Close previously created projects. Create a new empty application project called lab5 utilizing already existing standalone\_bsp\_0 software platform. Import the lab5.c source file.
- **2-1-1.** In the *Project Explorer* in SDK, *right click+cntl* on *lab4*, *lab4\_bsp* and *system\_wrapper\_hw\_platfrom\_2* and select **Close Project**
- 2-1-2. Select File > New > Application Project.
- **2-1-3.** Name the project **lab5**, and for the board Support Package, (Leave *Create New* for the *Board Support Package* and name as *lab5\_bsp*) and click **Next.**
- 2-1-4. Select Empty Application and click Finish.
- **2-1-5.** Select *lab5* > *src* in the project explorer, right-click, and select *Import*.
- 2-1-6. Expand General category and double-click on File System.
- **2-1-7.** Browse to C:\Xilinx\_trn\Zynq\_base\lab\_sources\lab5 folder, click **OK**.
- 2-1-8. Select lab5.c and click Finish.

You will notice that there are multiple compilation errors. This is expected as the code is incomplete. You will complete the code in this lab.

- 2-2. Refer to the Scutimer API documentation.
- 2-2-1. Open the system.mss from lab5\_bsp
- **2-2-2.** Click on **Documentation** link corresponding to **scutimer** (*ps7\_scutimer*) peripheral under the *Peripheral Drivers* section to open the documentation in a default browser window.
- **2-2-3.** In the window appeared click on the **File List** link to see available files related to the private timer API.
- **2-2-4.** In the window appeared click on the **xscutimer.h** file.

Look at the XScuTimer\_LookupConfig() and XScuTimer\_CfgInitialize() API functions which must be called before the timer functionality can be accessed.

Look at various functions available to interact with the timer hardware.







Figure 2. Useful Functions

#### 2-3. Correct the errors

**2-3-1.** In SDK, in the **Problems** tab, double-click on the *unknown type name* **x** for the parse error.



This will open the source file and bring you around to the error place.

```
1 #include "xparameters.h"
 2 #include "xgpio.h"
 3 #include "led_ip.h"
 4 // Include scutimer header file
 6 //===========
7 XScuTimer Timer; /* Cortex A9 SCU Private Timer Instance */
 9 #define ONE_TENTH 32500000 // half of the CPU clock speed/10
11⊖int main (void)
12 {
13
14
15
      XGpio dip, push;
      int psb_check, dip_check, dip_check_prev, count, Status;
16
17
      // PS Timer related definitions
18
      XScuTimer_Config *ConfigPtr;
919
      XScuTimer *TimerInstancePtr = &Timer;
20
21
22
      xil_printf("-- Start of the Program --\r\n");
```

Figure 3. First error

**2-3-2.** Add the include statement at line 5 of the file for the *XScuTimer.h.* Save the file and the errors should disappear.

```
#include "xscutimer.h"
```

**2-3-3.** Scroll down the file and notice that there are few lines intentionally left blank with some guiding comments.

```
31
      // Initialize the timer
32
33
34
      // Read dip switch values
      dip check prev = XGpio DiscreteRead(&dip, 1);
35
      // Load timer with delay in multiple of ONE TENTH
36
37
38
      // Set AutoLoad mode
39
40
      // Start the timer
41
```

#### Figure 4. Fill in Missing Code

- Lines 32, 33: The timer needs to be initialized,
- Line 37: The timer needs to be loaded with the value ONE\_TENTH\*dip\_check\_prev,
- Line 39: AutoLoad needs to be enabled,
- Line 41: The timer needs to be started.
- **2-3-4.** Using the API functions list, fill those lines. Save the file and correct errors if any. (Use the completed code further on in this workbook as a guide if necessary.)

2-3-4.1. In lines 32, 33 of lab5.c add the following functions:

```
ConfigPtr = XScuTimer_LookupConfig (XPAR_PS7_SCUTIMER_0_DEVICE_ID);
```

XScuTimer CfgInitialize (TimerInstancePtr, ConfigPtr, ConfigPtr->BaseAddr);

```
// Initialize the timer
ConfigPtr = XScuTimer_LookupConfig (XPAR_PS7_SCUTIMER_0_DEVICE_ID);
XScuTimer_CfgInitialize (TimerInstancePtr, ConfigPtr, ConfigPtr->BaseAddr);
```

**2-3-4.2.** In line 37 of lab5.c add the following function:

XScuTimer\_LoadTimer(TimerInstancePtr, ONE\_TENTH\*dip\_check\_prev);

```
// Load timer with delay in multiple of ONE_TENTH
XScuTimer LoadTimer(TimerInstancePtr, ONE TENTH*dip check prev);
```

**2-3-4.3.** In line 39 of lab5.c add the following function:

XScuTimer\_EnableAutoReload(TimerInstancePtr);

```
// Set AutoLoad mode

XScuTimer_EnableAutoReload(TimerInstancePtr);
```

**2-3-4.4.** In line 41 of lab5.c add the following function:

**2-3-5.** Scroll down the file further (down to line 56) and notice that there are few more lines intentionally left blank with some guiding comments.

```
56
             // load timer with the new switch settings
57
58
             count = 0;
59
         if(XScuTimer IsExpired(TimerInstancePtr)) {
60
                 // clear status bit
61
62
63
                 // output the count to LED and increment the count
64
65
         }
```

Figure 5. More Code to be completed

- Line 57: The value of ONE\_TENTH\*dip\_check needs to be written to the timer to update the timer.
- Line 62: The InterruptStatus needs to be cleared.
- Line 64: , and the LED needs to be written to, and the count variable incremented.

- **2-3-6.** Using the API functions list, complete those lines.
- **2-3-6.1.** In line 57 of lab5.c add the following function:

XScuTimer\_LoadTimer(TimerInstancePtr, ONE\_TENTH\*dip\_check);

```
// load timer with the new switch settings
XScuTimer_LoadTimer(TimerInstancePtr, ONE_TENTH*dip_check);
```

**2-3-6.2.** In line 62 of lab5.c add the following function:

XScuTimer\_ClearInterruptStatus(TimerInstancePtr);

```
// clear status bit
XScuTimer_ClearInterruptStatus(TimerInstancePtr);
```

**2-3-6.3.** In line 64 of lab5.c add the following function:

```
LED_IP_mWriteReg(XPAR_LED_IP_S_AXI_BASEADDR, 0, count);
```

```
// output the count to LED and increment the count LED_IP_mWriteReg(XPAR_LED_IP_S_AXI_BASEADDR, 0, count);
```

**2-3-7.** Save the file and correct errors if necessary.

```
1 #include "xparameters.h"
2 #include "xgpio.h"
3 #include "led_ip.h"
4 // Include scutimer header file
5 #include "xscutimer.h"
    XScuTimer Timer;
                          /* Cortex A9 SCU Private Timer Instance */
8
9 #define ONE TENTH 32500000 // half of the CPU clock speed/10
11 int main (void)
12 {
13
14
       XGpio dip, push;
15
       int psb_check, dip_check, dip_check_prev, count, Status;
16
17
       // PS Timer related definitions
      XScuTimer_Config *ConfigPtr;
18
19
      XScuTimer *TimerInstancePtr = &Timer;
20
21
       xil_printf("-- Start of the Program --\r\n");
22
23
       XGpio_Initialize(&dip, XPAR_SWITCHES_DEVICE_ID);
24
       XGpio_SetDataDirection(&dip, 1, 0xffffffff);
25
26
       XGpio_Initialize(&push, XPAR_BUTTONS_DEVICE_ID);
27
       XGpio_SetDataDirection(&push, 1, 0xfffffffff);
28
29
       count = 0;
30
31
       // Initialize the timer
32
       ConfigPtr = XScuTimer_LookupConfig (XPAR_PS7_SCUTIMER_0_DEVICE_ID);
33
       XScuTimer_CfgInitialize (TimerInstancePtr, ConfigPtr, ConfigPtr->BaseAddr);
34
       // Read dip switch values
35
      dip_check_prev = XGpio_DiscreteRead(&dip, 1);
       // Load timer with delay in multiple of ONE_TENTH
36
37
      XScuTimer_LoadTimer(TimerInstancePtr, ONE_TENTH*dip_check_prev);
38
       // Set AutoLoad mode
39
       XScuTimer_EnableAutoReload(TimerInstancePtr);
40
       // Start the timer
41
      XScuTimer_Start (TimerInstancePtr);
42
      while (1)
43
          // Read push buttons and break the loop if Center button pressed
44
45
          psb_check = XGpio_DiscreteRead(&push, 1);
46
          if(psb_check > 0)
47
48
              xil_printf("Push button pressed: Exiting\r\n");
49
              XScuTimer_Stop(TimerInstancePtr);
50
             break;
51
52
          dip_check = XGpio_DiscreteRead(&dip, 1);
53
          if (dip_check != dip_check_prev) {
54
             xil_printf("DIP Switch Status %x, %x\r\n", dip_check_prev, dip_check);
             dip_check_prev = dip_check;
56
              // load timer with the new switch settings
57
             XScuTimer_LoadTimer(TimerInstancePtr, ONE_TENTH*dip_check);
58
             count = 0;
59
          if(XScuTimer_IsExpired(TimerInstancePtr)) {
60
61
                 // clear status bit
62
                  XScuTimer_ClearInterruptStatus(TimerInstancePtr);
63
                  // output the count to LED and increment the count
64
                  LED_IP_mWriteReg(XPAR_LED_IP_S_AXI_BASEADDR, 0, count);
65
          }
66
       }
67
       return 0;
```

Figure 6. The completed Code

## **Verify Operation in Hardware**

Step 3

- 3-1. Connect the board with micro-usb cable(s) and power it ON. Establish the serial communication using SDK's Terminal tab.
- **3-1-1.** Make sure that micro-USB cable(s) is(are) connected between the board and the PC. Turn ON the power
- 3-1-2. Select the Ferminal tab. If it is not visible then select Window > Show view > Terminal.
- **3-1-3.** Click on and if required, select appropriate COM port (depends on your computer), and configure it with the parameters as shown. (These settings may have been saved from previous lab).
- 3-2. Program the FPGA by selecting Xilinx > Program FPGA and assigning system\_wrapper.bit file. Run the TestApp application and verify the functionality.
- 3-2-1. Select Xilinx > Program FPGA.
- **3-2-2.** Click the **Program** button to program the FPGA.
- **3-2-3.** Select **lab5** in *Project Explorer*, right-click and select **Run As > Launch on Hardware (GDB)** to download the application, execute ps7\_init, and execute lab5.elf

Depending on the switch settings you expect to see LEDs implementing a binary counter with corresponding delay, BUT you don't see it. There is a bug in the source code.

Flip the DIP switches and verify that in the Terminal window the previous and current switch settings are displayed whenever you flip switches.

```
-- Start of the Program --
DIP Switch Status 1, 3
DIP Switch Status 3, 7
```

Figure 7. Terminal window output

## Launch Debugger

Step 4

## 4-1. Launch Debugger and debug

**4-1-1.** Right-click on the **Lab5** project in the Project Explorer view and select **Debug As > Launch on Hardware (GDB)**.

The lab5.elf file will be downloaded and if prompted, click **Yes** to stop the current execution of the program.

**4-1-2.** Click **Yes** if prompted to change to the *Debug perspective*.

At this point you could have added global variables by right clicking in the **Variables** tab and selecting **Add Global Variables** ... All global variables would have been displayed and you could have selected desired variables. Since we do not have any global variables, we won't do it.

**4-1-3.** Double-click in the left margin to set a breakpoint on various lines in **lab5.c** shown below. A breakpoint has been set when a "tick" and blue circle appear in the left margin beside the line when the breakpoint was set. (The line numbers may be slightly different in your file.)

The first breakpoint is where count is initialized to 0. The second breakpoint is to catch if the timer initialization fails. The third breakpoint is when the program is about to read the dip switch settings. The fourth breakpoint is when the program is about to terminate due to pressing of center push button. The fifth breakpoint is when the timer has expired and about to write to LED.

```
1 #include "xparameters.h"
 2 #include "xgpio.h"
 3 #include "led ip.h"
 4 // Include scutimer header file
 5 #include "xscutimer.h"
 6 //----
 7 XScuTimer Timer;
                       /* Cortex A9 SCU Private Timer Instance */
 9 #define ONE_TENTH 3250000 // half of the CPU clock speed/10
10
11⊖int main (void)
12 {
13
14
      XGpio dip, push;
15
      int psb check, dip check, dip check prev, count, Status;
16
17
      // PS Timer related definitions
18
      XScuTimer_Config *ConfigPtr;
19
      XScuTimer *TimerInstancePtr = &Timer;
20
21
      xil_printf("-- Start of the Program --\r\n");
22
23
      XGpio_Initialize(&dip, XPAR_SWITCHES_DEVICE_ID);
24
      XGpio_SetDataDirection(&dip, 1, 0xffffffff);
25
26
      XGpio_Initialize(&push, XPAR_BUTTONS_DEVICE_ID);
27
      XGpio_SetDataDirection(&push, 1, 0xffffffff);
28
29
    count = 0;
30
31
       // Initialize the timer
32
      ConfigPtr = XScuTimer_LookupConfig (XPAR_PS7_SCUTIMER_0_DEVICE_ID);
33
      XScuTimer_CfgInitialize (TimerInstancePtr, ConfigPtr, ConfigPtr->BaseAddr);
34
      // Read dip switch values
35
     dip_check_prev = XGpio_DiscreteRead(&dip, 1);
36
      // Load timer with delay in multiple of ONE_TENTH
 37
      XScuTimer_LoadTimer(TimerInstancePtr, ONE_TENTH*dip_check_prev);
38
      // Set AutoLoad mode
39
      XScuTimer_EnableAutoReload(TimerInstancePtr);
40
      // Start the timer
41
      XScuTimer_Start (TimerInstancePtr);
42
      while (1)
43
      {
44
          // Read push buttons and break the loop if Center button pressed
45
         psb_check = XGpio_DiscreteRead(&push, 1);
46
         if(psb_check > 0)
47
         {
48
             xil_printf("Push button pressed: Exiting\r\n");
49
             XScuTimer_Stop(TimerInstancePtr);
50 -
             break;
51
52
         dip_check = XGpio_DiscreteRead(&dip, 1);
53
         if (dip_check != dip_check_prev) {
54
             xil_printf("DIP Switch Status %x, %x\r\n", dip_check_prev, dip_check);
55
             dip_check_prev = dip_check;
56
             // load timer with the new switch settings
57
             XScuTimer_LoadTimer(TimerInstancePtr, ONE_TENTH*dip_check);
58
             count = 0;
59
60
         if(XScuTimer_IsExpired(TimerInstancePtr)) {
61
                 // clear status bit
62
                 XScuTimer_ClearInterruptStatus(TimerInstancePtr);
63
                 // output the count to LED and increment the count
64-
                 LED_IP_mWriteReg(XPAR_LED_IP_S_AXI_BASEADDR, 0, count);
65
         }
66
67
      return 0;
```

#### Figure 8. Setting breakpoints

**4-1-4.** Click on the **Resume** ( ) button to continue executing the program up until the first breakpoint is reached.

In the Variables tab you will notice that the count variable may have value other than 0.

- **4-1-5.** Click on the **Step Over** ( ) button or press F6 to execute one statement. As you do step over, you will notice that the **count** variable value changed to 0.
- **4-1-6.** Click on the **Resume** button again and you will see that several lines of the code are executed and the execution is suspended at the third breakpoint..
- **4-1-7.** Click on the **Step Over** (F6) button to execute one statement. As you do step over, you will notice that the **dip\_check\_prev** variable value changed to a value depending on the switch settings on your board.
- 4-1-8. Click on the memory tab. If you do not see it, go to Window > Show View > Memory.
- **4-1-9.** Click the sign to add a Memory Monitor




Figure 9. Monitor memory location

4-1-10. Enter the address for the private counter load register (0xF8F00600), and click OK.




Figure 10. Monitoring a Memory Address

You can find the address by looking at the xparameters.h file entry to get the base address ( \*\* XPAR\_PS7\_SCUTIMER\_0\_BASEADDR ), and find the load offset double-clicking on the xscutimer.h in the outline window followed by double-clicking on the xscutimer\_hw.h and then selecting XSCUTIMER\_LOAD\_OFFSET.

# XSCUTIMER\_HW\_H

xil\_types.h

xil\_io.h

xil\_assert.h

XSCUTIMER\_LOAD\_OFFSET

XSCUTIMER\_COUNTER\_OFFSET

XSCUTIMER\_CONTROL\_OFFSET

XSCUTIMER\_ISR\_OFFSET

XSCUTIMER\_ISR\_OFFSET

Figure 11. Memory Offset

**4-1-11.** Make sure the DIP Switches are not set to "0000" and click on the **Step Over** button to execute one statement which will load the timer register.

Notice that the address 0xF8F00604 has become red colored as the content has changed. Verify that the content is same as the value: dip\_check\_prev\*32500000. You will see hexadecimal equivalent (displaying bytes in the order 0 -> 3).

E.g. for dip\_check\_prev = 1; the value is 0x01EFE920; (reversed: 0x20E9EF01)

**4-1-12.** Click on the **Resume** button to continue execution of the program. The program will stop at the writing to the LED port (skipping fourth breakpoint as center push button as has not occurred).

Notice that the value of the counter register is changed from the previous one as the timer was started and the countdown had begun.

- **4-1-13.** Click on the **Step Over** button to execute one statement which will write to the LED port and which should turn OFF the LEDs as the count=0.
- **4-1-14.** Double-click on the fifth breakpoint, the one that writes to the LED port, so the program can execute freely.
- **4-1-15.** Click on the **Resume** button to continue execution of the program. This time it will continuously run the program changing LED lit pattern at the switch setting rate.
- **4-1-16.** Flip the switches to change the delay and observe the effect.
- **4-1-17.** Press a push button and observe that the program suspends at the fourth breakpoint. The timer register content as well as the control register (offset 0x08) is red as the counter value had changed and the control register value changed due to timer stop function call. (In the Memory monitor, you may need to right click on the address that is being monitored and click *Reset* to refresh the memory view.)

Try to find and work around the issue with counter value on LED. Tip: Try to find in the source code where counter is incremented.

- **4-1-18.** Correct source code. Save it. Rerun and check that it works correctly.
- **4-1-19.** Terminate the session by clicking on the **Terminate** ( ) button.
- 4-1-20. Exit the SDK and Vivado.

**4-1-21.** Power OFF the board.

# Conclusion

This lab led you through developing software that utilized CPU's private timer. You studied the API documentation, used the appropriate function calls and achieved the desired functionality. You verified the functionality in hardware. Additionally, you used the SDK debugger to view the content of variables and memory, and stepped through various part of the code.