2012-07-11

Issued by: (dept., name, location)
26738, Jessica Erlandsson, HÄ6/AB3N

# **Preparation**

- Test leader, at office

Order &
PVT Check Test code

PVT order: An order for a PVT Check is sent to the PVT group mail by PMCV or Build leader at KAA.

At present: Email Johan Hallberg and request an excel document of the specific test code.

Soon: Export an excel file of the PVT Check test code from PVT Manager, by selecting:
- PVT Test Sequences
→ Default Sequences, and select the relevant.

**Cover Page** 

Fill out the cover page. May look like this:



Cover Page

Information about the truck is available from PROTUS, under "edit variant specification". Tip: Use the search function to find info e.g. BHP or retarder.

Printout

Make sure the headings will be printed on every page:

How To - Print TC with Headings

"section in driver mother tongue", select "selection" in the printing window and print. Put the print-out into a

Note the truck ID and date on the first page.

plastic folder.

**Logging System** 

Report the logging system in E-FACTS Collector. Open the program by "right mouse click" on the collector icon in the activity field.

Select "Edit M log installation info". Check Vehicle ID if the correct logger is already installed. If not – find the truck id in the drop down menu under "add new configuration" and fill in the remaining information and change the "M-Log System Id" – press "insert"

M-Logg ID: logging equipment ID no, 8000xxxx

Chassis ID: e.g. A-xxxxxx Vehicle ID:

Tag: GOT
Info available in Protus - "Mini

Test Leader: your name SW Release: the current

If truck does not exist in the list press "request new items" and send the details to support.efacts@volvo.com Test Loggfile

Make a test log file with engine running. Insert USB into logger and load the system – finished when a steady red light appears. Insert the USB in the computer and open the folder "CVEL\_USBAuto and the file "CVEL\_USBAutpRun.exe". Choose COPY CVEL DATA: the data will now be transferred. Do not click "yes" until the transfer is completed. Click "exit" when the button is

Open E-FACTS Data refiner, "Load meas", sort by "vehicle id" – find your truck and dragand-drop to "drag a column header..." Sort by date and choose todays dates mea package and click "load". Check

that all "Data present on bus" are active. (Externals/LIN, Backbone1, Backbone2, Chassis, Display, Powertrain/eng(e6), Safety1, Safety2, Cab, Security,

If not check if M-Log is correctly installed.

Type of document:

#### **PVT Check Process map**

2012-07-11

Page:

Issued by: (dept., name, location)

26738, Jessica Erlandsson, HÄ6/AB3N

### **Preparation**

- Driver, in truck

## **PVT Check Test**

- Driver, in truck

### **Driver Preparation**

Bring printed test code, tag, USB and GPS to truck. If no logger installed - connect the logging equipment by connecting all CAN connections (MCAN should not be connected, sometimes less than 12 connections depending on truck spec) to resp. connection in the truck (marked with the same name). Special connection for EU6: Safety 1 – Powertrain CAN EU6. Connect the power cables: vellow to green, red to red, black to black, and blue to

Start the engine, the control light will light red, then blue (=logger ok). Make a test log file: (if test leader has not yet done this) push the trigger button, the control light lit yellow for 15sec (time for logging), then continuously blue. Mount the tag vertically on the truck with plastic strapping as low as possible.

Start up & Logging

Start PVT check by logging all the pop-ups that appears in all vehicle modes. Continue the check by following the test case protocol. All errors should be logged, also those that not included in the protocol (OFD = other faults found during driving)

A PVT Check is expected to cover around 6 hours of driving.



- At the end of the check the logging files should be transferred on a USB by:
- Turning off the engine and ignition and wait until the control light on the logger stops flashing and switch on the ignition again.

Connect the USB directly to the logging equipment or to an extension cable. The light on the logger is flashing red and blue for about 10-30min (depending on the amount of files).

- The data transfer is ready when the light is red a longer time
- Disconnect the USB



After the test:

Disconnect and dismount the logging Equipment (if the truck is not about to run another PVT test) and send an email to: supportTTsupportGOT @volvo.com

that you've done so.

Dismount the tag.





Type of document:

2012-07-11

### **PVT Check Process map**

Page:

Issued by: (dept., name, location)

26738, Jessica Erlandsson, HÄ6/AB3N

## **After the Test**

#### Data Transfer

Data transfer (logged files) from USB into PC:

- Connect USB into PC
- CVEL USBAuto folder (EFACTS Collector starts
- Choose CVEL USBAutoRun
- Choose COPY CVEL DATA: the data will now be transferred.
- Push "exit" when the button is activated NOTE: Do not click "Yes" before the transfer is done.

### **Data Control**

Start the program **EFACTS Data Refiner** "Load meas". Sort by "Vehicle ID" and dragand-drop the column "vehicle ID" to the area "Drag a column

and sort by "start Check if the MEA-files are placed under the specific vehicle.

- Choose the vehicle ID

## **Data Control**

Fill out the PVT Check PVT Check Status the faults found concerning the test code. Other faults and pop-ups shall be written down in an email to the project leader, vehicle owner and other interests (and Arne Olsson), and cc Jessica Erlandsson. Send from the PVT

# group mail.

Attach the digital document (PVT Check) in the email.

## Save on TeamPlace

Save the PVT Check FHxxx document in a folder and a copy (word) of the OFD

# Performed PVT Check

- Also save locally on PC in My documents/PVT





Type of document: Page: **PVT Check Process map** Issued by: (dept., name, location) 2012-07-11 26738, Jessica Erlandsson, HÄ6/AB3N **After the Test** Upload in Protus Update P2540 Compilation Update the document Start PROTUS; **PVT Check Result** the performed PVT Enter the specific vehicle ID in the box status for the current points) and send it to press search. Find the the coordinator to vehicle under "Current Don't forget to "check include in PVT status version" and go to the out" the document mail once a week on tab "Documents" – before opening it, to Browse and upload prevent it to be May look like this: both documents (one overwritten. word, one excel) W TFV Status