You can choose to install the XDJ-XZ mapping with or without BOME.


# TO INSTALL **WITH** BOME:


- See the installation video <a href="https://youtu.be/MbGP\_ECnWiQ">https://youtu.be/MbGP\_ECnWiQ</a>
- Follow the DDJ-1000 installation guide PDF
  - Then see the XDJ-XZ specific instructions on <u>Page 45</u>

# WHAT WILL YOU GAIN?

- Jog screens
- All traktor MacroFX and MixerFX
  - (these are **in addition** to Pioneer SoundColorFX Hardware effects)
- Any future updates to this mapping

## XDJ Config:





More info: See page 128 of the Pioneer Manual:

https://github.com/pestrela/music/blob/master/ddj/4%20Manuals/XDJ-XZ%20-%20Full%20Manual.pdf


#### **XDJ-XZ features video:**

https://www.youtube.com/watch?v=7EPfY9bGGlw&list=PLIIvTGzSxI0UV1oJfRDL4fYY9oRyLkBik&index=1


#### **BOME installation video:**

https://youtu.be/MbGP\_ECnWiQ


#### **BOME** aliases:



## Proper BOME config:



## Proper BOME config:





## Proper BOME log:


```
795: MIDIManager stopped.
796: MIDIManager started.
797 Opened MIDI OUTPUT 'Bome MIDI Translator 1 Virtual Out'
798: Opened MIDI OUTPUT 'XDJ-XZ (2)'
799: Opened MIDI OUTPUT 'XDJ-XZ (1)'
800: Opened MIDI INPUT 'XDJ-XZ (2)'
801: Opened MIDI INPUT 'XDJ-XZ (2)'
802: Spened MIDI INPUT 'XDJ-XZ (1)'

| Incoming | Rules | Outgoing | MIDIN | MIDIOUT | Timestamped
```

## Traktor config:








#### **BOME Clock:**

If the needle is jerky or you have "ghosting" then change the BOME clock value and restart BOME



Note: the panel on step 3 may not appear in mac the first time you run bome. In this case restart bome