# CFD modeling of flow behavior over NACA0012 airfoil for wind turbine applications

Ole Petersen

Dec 7, 2022

#### Abstract

In this tutorial, I will show from end to end how to do a 2d CFD simulation of an aerofoil including the generation of the geometry, the meshing using gmsh and the simulation using OpenFoam.

#### Introduction

The starting point is the NACA0012 tutorial case in OpenFoam. Copy this case to your new working directory. In this tutorial, we will have a look at how to simulate your custom 2d geometry as the tutorial is intransparent about how the mesh was generated.

## Mesh generation

We will use gmsh to generate the mesh. To do so, we will first generate the geometry using gmsh's geometry format, use the gmsh GUI to debug the geometry and finally generate the mesh.

### Geometry generation

The geometry will look as follows:

The volume in which fluid is to be simulated is the whole body from which the aerofoil in the middle is cut out. The circle arc on the left is the inlet while the outlet is the rectangle on the right.

The whole geometry generation is done in the mesh\_generation.jl script, which outputs a gmsh geometry file aerofoil.geo that gmsh can read. Note that gmsh has its own geometry scripting language, but I found it easier to use a proper programming language like julia to generate the geometry.

#### Generating the profile

end

We will simulate a NACA0012 airfoil, which is described by the following equation:

```
y(x) = \pm 0.594689181*(0.298222773*\sqrt{x} - 0.127125232*x - 0.357907906*x^2 + 0.291984971*x^3 - 0.105174606*x^4)
```

Now, we will generate a set of points that describe the profile:

```
y(x) = 0.594689181*(0.298222773*sqrt(x) - 0.127125232*x - 0.357907906*x^2 + 0.291984971*x^3 - 0.105174606*x^2 + 0.291984971*x^3 + 0.2919
```




Figure 1: Geometry of our simulation

```
for i in 1:n_points_per_side
       x=1-(i-1)/(n \text{ points per side})
      mesh_size=0.005
      println(io, "Point(\$(i+n_points_per_side)) = \{\$(x), \$(-y(x)), 0.0, \$mesh_size\};")
   end
Point(1) = \{0.0, 0.0, 0.0, 0.005\};
Point(2) = \{0.1, 0.046561895043862704, 0.0, 0.005\};
Point(3) = \{0.2, 0.056968557150769476, 0.0, 0.005\};
Point(4) = \{0.3, 0.05948422462775665, 0.0, 0.005\};
Point(5) = \{0.4, 0.05738266105317275, 0.0, 0.005\};
Point(6) = \{0.5, 0.05219019673131475, 0.0, 0.005\};
Point(7) = \{0.6, 0.04479110070446828, 0.0, 0.005\};
Point(8) = \{0.7, 0.03570927685952479, 0.0, 0.005\};
Point(9) = \{0.8, 0.025211311562171167, 0.0, 0.005\};
Point(10) = \{0.9, 0.013352458679209828, 0.0, 0.005\};
Point(11) = \{1.0, 1.650594053104193e-17, 0.0, 0.005\};
Point(12) = \{0.9, -0.013352458679209828, 0.0, 0.005\};
Point(13) = \{0.8, -0.025211311562171167, 0.0, 0.005\};
Point(14) = \{0.7, -0.03570927685952479, 0.0, 0.005\};
Point(15) = \{0.6, -0.04479110070446828, 0.0, 0.005\};
Point(16) = \{0.5, -0.05219019673131475, 0.0, 0.005\};
Point (17) = \{0.4, -0.05738266105317275, 0.0, 0.005\};
Point(18) = {0.30000000000000004, -0.05948422462775666, 0.0,0.005};
Point(20) = {0.0999999999999999999, -0.046561895043862704, 0.0,0.005};
```

The syntax is Point(i) = {x, y, z, mesh\_size}; where i is a unique index of the point, x, y and z are the coordinates and mesh\_size is the desired mesh size at this point. Pasting this output into a file called aerofoil.geo (or setting the script up to write its output to that file like in the final version and running gmsh aerofoil.geo will prompt you with the following:

Figure 2: Profile points

The next critical step is to connect all the points with a spline. The profile points should be connected with a single spline instead of a set of hundreds of single lines since this will later enable us to name the aerofoil surface. This is done by the following code:

```
println(io,"""Spline(1)={1:$n_aerofoil_points,1};""")
Spline(1)={1:20,1};
```

The syntax is Spline(i)={p1,p2,...pk}; where i is a unique index of the spline and pi are the indices of the points the spline should connect. pi:pj is a shorthand for pi,pi+1,...,pj. The 1 at the end of the line is the first index again, which is needed to close the spline. The result is the following:




Figure 3: Profile with spline

#### Generating the bounding box

The next step is to generate the bounding box. This is done by the following code:

```
bounding_radius=5.0
  far_field_mesh_size=0.3
  println(io, "Point($(n_aerofoil_points+1)) = {0.0, $(bounding_radius), 0.0, $far_field_mesh_size};")
  println(io, "Point($(n_aerofoil_points+2)) = {0.0, $(-bounding_radius), 0.0, $far_field_mesh_size};")
  println(io, "Point($(n_aerofoil_points+3)) = {$(-bounding_radius), 0.0, 0.0, $far_field_mesh_size};")
  println(io, "Point($(n_aerofoil_points+4)) = {$(bounding_radius), $(bounding_radius), 0.0, $far_field_mes
  println(io, "Point($(n_aerofoil_points+5)) = {$(bounding_radius), $(-bounding_radius), 0.0, $far_field_me
  println(io, "Circle($(n_aerofoil_points+1)) = {$(n_aerofoil_points+2), 1, $(n_aerofoil_points+3)};")
  println(io, "Circle($(n_aerofoil_points+2)) = {$(n_aerofoil_points+3), 1, $(n_aerofoil_points+1)};")
  println(io, "Line($(n_aerofoil_points+3)) = {$(n_aerofoil_points+1), $(n_aerofoil_points+4)};")
  println(io, "Line(\$(n_aerofoil\_points+4)) = \{\$(n_aerofoil\_points+4), \$(n_aerofoil\_points+5)\}; ")
  println(io, "Line($(n_aerofoil_points+5)) = {$(n_aerofoil_points+5), $(n_aerofoil_points+2)};")
Point(21) = \{0.0, 5.0, 0.0, 0.3\};
Point(22) = \{0.0, -5.0, 0.0, 0.3\};
Point(23) = \{-5.0, 0.0, 0.0, 0.3\};
Point(24) = \{5.0, 5.0, 0.0, 0.3\};
Point(25) = \{5.0, -5.0, 0.0, 0.3\};
Circle(21) = \{22, 1, 23\};
Circle(22) = \{23, 1, 21\};
Line(23) = \{21, 24\};
Line(24) = \{24, 25\};
Line(25) = \{25, 22\};
```

You can look up the exact syntax of the commands in the Gmsh documentation. The result is the following:




Figure 4: Profile with bounding box  $\,$ 

Next, we want to create a surface that fills the area between the aerofoil and the bounding box. This is done by the following code:

```
println(io, "Curve Loop(2) = {$(n_aerofoil_points+1):$(n_aerofoil_points+5)};")
println(io, "Curve Loop(3) = {1};")
println(io, "Plane Surface(1) = {2,3};")

Curve Loop(2) = {21:25};
Curve Loop(3) = {1};
Plane Surface(1) = {2,3};
```

We join a set of lines to a loop with Curve Loop(i) = {p1,p2,...pk}; where i is a unique index of the loop and pi are the indices of the lines the loop should connect. Loop 2 is the bounding box and loop 3 is the aerofoil. We then join the loops to a surface with Plane Surface(i) = {11,12,...lk}; where i is a unique index of the surface and li are the indices of the loops the surface should connect. This does not make a visual difference.

#### Extruding the geometry

OpenFoam does not allow us to use 2D geometries, so we need to extrude the geometry in the z-direction. This is done by the following code:

```
println(io,"""
  meshThickness=1.0;
  surfaceVector[] = Extrude {0, 0, meshThickness} {
       Surface{1};
      Layers{1};
      Recombine;
  };
  Physical Volume("internalField") = surfaceVector[1];
  Physical Surface("frontAndBackPlanes") = {surfaceVector[0],1};
  Physical Surface("INLET")={surfaceVector[2],surfaceVector[3]};
  Physical Surface("OUTLET")={surfaceVector[5]};
  Physical Surface("AIRFOIL")={surfaceVector[7]};
  Physical Surface("WALL")={surfaceVector[4],surfaceVector[6]};
   """)
meshThickness=1.0;
surfaceVector[] = Extrude {0, 0, meshThickness} {
    Surface{1};
    Layers{1};
    Recombine;
};
Physical Volume("internalField") = surfaceVector[1];
Physical Surface("frontAndBackPlanes") = {surfaceVector[0],1};
Physical Surface("INLET")={surfaceVector[2],surfaceVector[3]};
Physical Surface("OUTLET")={surfaceVector[5]};
Physical Surface("AIRFOIL")={surfaceVector[7]};
Physical Surface("WALL")={surfaceVector[4], surfaceVector[6]};
```

We extrude in the direction of the vector {0,0,meshThickness} with Extrude {0, 0, meshThickness} {Surface{1}; Layers{1}; Recombine;};. Surface{1}; tells gmsh we want to extrude the surface with the index one we just created. The Layers{1} command tells Gmsh to only generate one mesh layer. The Recombine command does something I do not understand but is recommended in other tutorials.

Finally, we need to assign names to surfaces in order to be able to later set boundary conditions in OpenFoam.

The keyword Physical means that a name needs to be exported to the mesh. The syntax is Physical Surface{"name\_i\_choose"}={p1,p2,...pk}; where p1,p2,...pk are the indices of the surfaces we want to assign the name to. The same holds for volumes. The names we choose are frontAndBackPlanes, INLET, OUTLET, AIRFOIL and WALL. The names are not important, but they need to be consistent with the names we use in OpenFoam. The Extrude command returns a list of surfaces it created by the extrusion as well as the volume it created. The ordering of these values is described by the docs as follows:

By default, the list contains the "top" of the extruded entity at index 0 and the extruded entity at index 1, followed by the "sides" of the extruded entity at indices 2, 3, etc.

Now you see why it is important the aerofoil consists of only one loop: Else we would have to assign a few hundred surfaces to a physical surface now. Even now the assignment is not trivial, but you can either try to keep track of the order in which the lines were added to the extrusion or use the visibility tool in gmsh, go to the tree view, select only one physical surface and click Apply. This will show you if you assigned the physical surface to the correct surfaces.

#### Meshing the geometry

Now we have the geometry ready to be meshed. Running the geometry generation script will create a file aerofoil.geo in the current directory. We can now run gmsh on this file to create the mesh:

```
julia mesh_generation.jl
gmsh -3 aerofoil.geo -format msh2
```

Here, the -3 flag tells gmsh to create a 3D mesh. The -format msh2 flag tells gmsh to create a mesh in the msh2 format instead of the newest msh4 format. This is necessary since else we will not be able to convert the mesh to the OpenFoam format, resulting in hard-to-debug errors. The resulting mesh file aerofoil.msh can be viewed by typing gmsh aerofoil.msh in the terminal. The result should look like this:

## Converting the mesh to OpenFoam format

Now we have the mesh in the msh2 format by running

```
# load OpenFoam into context
source /opt/OpenFOAM/OpenFOAM-10/etc/bashrc
gmshToFoam aerofoil.msh
```

This will create a directory constant/polyMesh with the mesh in the OpenFoam format. Now have a look at the constanc/boundary file. It should look like this:




Figure 5: Mesh

```
physicalType
                         patch;
                         33288;
        nFaces
        startFace
                         24701;
    }
    INLET
                         patch;
        type
        physicalType
                         patch;
        nFaces
                         54;
        startFace
                         57989;
    }
    WALL
                         patch;
        type
        physicalType
                         patch;
        nFaces
                         34;
        startFace
                         58043;
    }
    OUTLET
        type
                         patch;
                         patch;
        physicalType
        nFaces
                         34;
                         58077;
        startFace
    }
    AIRFOIL
                         patch;
        physicalType
                         patch;
                         408;
        nFaces
        startFace
                         58111;
    }
)
```

Now we need to assign the types of the frontAndBackPlanes to empty, telling OpenFoam that the geometry is "pseudo-2d" and that of the AIRFOIL to wall. We can do this either by editing the file manually or by running

```
function setBoundaryType {
    foamDictionary constant/polyMesh/boundary -entry entry0/$1/type -set $2
}
setBoundaryType frontAndBackPlanes empty
setBoundaryType AIRFOIL wall
```

And now we have our mesh!

# Setting boundary conditions

Boundary conditions are set in the 0 directory. Here we reference the names we gave to the physical surfaces earlier and set values accordingly. For example the velocity boundary conditions are set as follows:

```
//0/U
FoamFile
{
    format
                    ascii;
    class
                    volVectorField;
    object
}
dimensions
                [01-10000];
angle
                10;
                51.4815;
magnitude
radAngle
                #calc "degToRad($angle)";
               uniform ( #calc "$magnitude*cos($radAngle)" #calc "$magnitude*sin($radAngle)" 0 );
internalField
boundaryField
{
    INLET
    {
                        freestreamVelocity;
        freestreamValue $internalField;
    }
    OUTLET
                        freestreamVelocity;
        freestreamValue $internalField;
    }
    WALL
    {
                        freestreamVelocity;
        freestreamValue $internalField;
    AIRFOIL
    {
                        noSlip;
        type
    frontAndBackPlanes
        type
                        empty;
}
```

The #calc macro can be used to evaluate expressions and I use it to be able to set the angle of attack. For the other fields, have a look at the repository.

## Running the simulation

Now we can run the simulation by running

```
./Allclean
./Allrun
```

in the case directory. Now calling paraFoam -builtin will open a window with the results, here showing the pressure field at  $10^{\circ}$  angle of attack:




Figure 6: Pressure field

# Postprocessing

Finally, we might want to compute force coefficients. To do so, we edit system/controlDict:

```
timePrecision 6;

runTimeModifiable true;
// here the new code starts
functions
{
    calcForceCoefficients
    {
      type forceCoeffs;
```

```
functionObjectLibs ( "libforces.so" );
        enabled
                          true:
        writeControl
                         outputTime;
        р
                          p;
        U
                          U;
        rhoInf 1.225;
                     rhoInf;
        rho
        CofR (0 0 0);
        patches (AIRFOIL);
        liftDir (0 1 0);
        dragDir (1 0 0);
        magUInf 51.4815;
                          (0\ 0\ 1);
        pitchAxis
        lRef
                          1;
        Aref
                         1.0;
    }
}
```

We are specifying that force coefficients should be computed from the pressure and velocity fields at a certain density, the center of rotation is in the origin (for calculating rotation coefficients), we want to compute forces on the AIRFOIL patch/surface, the lift direction is in the y-direction, the drag direction is in the x-direction, the freestream velocity is 51.4815 m/s, the pitch axis is in the z-direction, the reference length is 1 m and the reference area is  $1m^2$  (1m length, the extrusion depth is 1m). Now we can run the simulation again and the results will be written to postProcessing/forceCoeffs/0/forceCoeffs.dat. The results should look like this for an angle of attack of  $10^{\circ}$ :

```
# Force coefficients
# liftDir
               : (0.000000e+00 1.000000e+00 0.000000e+00)
                 (1.000000e+00 0.000000e+00 0.000000e+00)
# dragDir
# pitchAxis
                 (0.000000e+00 0.000000e+00 1.000000e+00)
# magUInf
               : 5.148150e+01
# 1Ref
               : 1.000000e+00
               : 1.000000e+00
# Aref
               : (0.000000e+00 0.000000e+00 0.000000e+00)
# CofR
# Time
                 Cm
                                  Cd
                                                   Cl
                                                                    Cl(f)
                                                                                     Cl(r)
0
                 1.005199e-04
                                  8.689213e-04
                                                   2.007876e-04
                                                                    2.009136e-04
                                                                                     -1.260811e-07
50
                 2.035919e-01
                                  -4.819210e-02
                                                   7.422555e-01
                                                                    5.747196e-01
                                                                                     1.675359e-01
                 2.156512e-01
                                  -7.982419e-02
                                                   8.268958e-01
                                                                    6.290991e-01
                                                                                     1.977967e-01
100
150
                 1.989127e-01
                                  -8.818876e-02
                                                   8.174411e-01
                                                                    6.076333e-01
                                                                                     2.098078e-01
200
                 1.937071e-01
                                  -9.057140e-02
                                                   8.183314e-01
                                                                    6.028728e-01
                                                                                     2.154586e-01
250
                 1.982154e-01
                                  -9.338277e-02
                                                   8.350128e-01
                                                                    6.157218e-01
                                                                                     2.192910e-01
300
                 2.051837e-01
                                  -9.658069e-02
                                                   8.551922e-01
                                                                    6.327799e-01
                                                                                     2.224124e-01
350
                 2.116860e-01
                                  -9.937373e-02
                                                   8.728818e-01
                                                                    6.481269e-01
                                                                                     2.247549e-01
                 2.160577e-01
                                  -1.015911e-01
                                                   8.854153e-01
                                                                    6.587653e-01
                                                                                     2.266499e-01
400
450
                 2.185094e-01
                                  -1.031260e-01
                                                   8.930907e-01
                                                                    6.650547e-01
                                                                                     2.280360e-01
                 2.198577e-01
                                  -1.040943e-01
                                                   8.976094e-01
                                                                    6.686624e-01
                                                                                     2.289470e-01
500
```

The coefficients are calculated at each time step of the solver (a time step is more of an iterative step since the simulation is steady). Note that the lift- and drag direction are not set according to the convention, normally the lift is perpendicular to the free stream velocity and not to the aerofoil. One can either fix this in the configuration or by rotating lift and drag by the angle of attack after the simulation, which is done here.

## Results

```
using DataFrames,CSV
liftData=CSV.read("case/allResults.dat",DataFrame,header=false)[:,[1,4,5]]|>Matrix
#display(liftData)
tangentCoeffs=liftData[:,3]
normalCoeffs=liftData[:,2]
angles=liftData[:,1]
radAngles=deg2rad.(angles)
using Plots
a=1
liftCoeffs=cos.(radAngles).*normalCoeffs.-sin.(radAngles).*tangentCoeffs
dragCoeffs=sin.(radAngles).*normalCoeffs.+cos.(radAngles).*tangentCoeffs
plot(angles,[liftCoeffs,dragCoeffs],label=["Lift coefficient" "Drag coefficient"],xlabel="Angle of attack)
```

