Site Readiness Best Practice

GC/Owner/Developer Responsibilities prior to Pier Foundations mobilizing to site

1.) Site Prep
    a. Temp Construction Stone Driveway Entrance needs placed from entrance at the street to the building pad for each entry GC plans to allow PF to bring in dump trucks for stone deliveries.
    b. Spoil pile locations identified just off the building pad that PF will place excess spoils at.
2.) Utilities
    a. GC to have all private utilities to be located and marked prior to PF mobilizing in.
    b. Pier Foundations will have all public utilities located and marked prior to mobilizing in.
    c. No new utilities to be installed within 10' of the building pad prior to PF scope of work completion.
3.) Building Pad Prep prior to PF Mobilization in
    a. Building Pad needs to be built to working grade elevation provided to PF from GC at time of submittals/shop drawing preparation.
        i. Any variance greater than 3" may result in a change order.
        ii. GC to send PF PM a picture of site with elevation on grade stake
    b. Building pad needs to be over built by 10' on all sides.
    c. Building Pad needs to have minimum 4"-6" of stone placed to work off of.
    d. Building Pad needs to be proof rolled and inspected by 3rd party testing agency.
        i. Letter from 3rd Party Testing Agency confirming the proof roll passed
4.) PF General Operations Items
    a. PF will bring in 200TN – 300TN of stone daily while working onsite and typically place the stone in several spots to help with production and pad protection.
    b. Stone will need to be dumped near and on the building pad by the trucks bringing stone to the jobsite.
        i. Stone is typically dumped within 50' of where we are working each day.
    c. Mob & Demob – GC to notify PF if site constraints will not allow lowboy trailers to be able to offload equipment on the jobsite.