# 专题12-按键驱动程序设计

## 一、混杂驱动设备模型

## 1.1、混杂设备描述

在Linux系统中,存在一类字符设备,它们拥有相同的主设备号(10),但次设备号不同,我们称这类设备为混杂设备 (miscdevice)。所有的混杂设备形成一个链表,对设备访问时内核根据次设备号查找到相应的混杂设备。


```
Linux中使用struct miscdevice来描述一个混杂设备。
```

```
struct miscdevice {
 int minor; /* 次设备号*/
  const char *name; /* 设备名*/
  const struct file_operations *fops; /*文件操作*/
  struct list head list;
  struct device *parent;
  struct device *this_device;
  1.2、混杂设备注册
    Linux中使用misc_register函数来注册一个混杂设备驱动。
int misc_register(struct miscdevice * misc)
  1.3、范例区动分析
#include linux/module.h>
#include linux/init.h>
#include linux/miscdevice.h>
int key_open(struct inode * node, struct file * filp)
return 0;
struct file_operations key_fops = {
.open = key_open,
struct miscdevice key_miscdev = {
.minor = 200,
.name = "key",
.fops = &key_fops,
static int key_init(void)
misc_register(&key_miscdev);
static void key_exit(void)
misc_deregister(&key_miscdev);
module_init(key_init);
```

## 二、Linux中断处理

module\_exit(key\_exit);

## 2.1、Linux中断处理流程分析



# 2.2、Linux中断处理程序设计

# 2.2.1、注册中断

request\_irq函数用于注册中断。

int request\_irq(unsigned int irq, void (\*handler)(int, void\*, struct pt\_regs \*), unsigned long flags, const char \*devname, void \*dev id)

返回0表示成功,或者返回一个错误码

unsigned intirq

中断号。

void (\*handler)(int,void \*)

中断处理函数。

unsigned long flags

与中断管理有关的各种选项。

const char \* devname

设备名

void \*dev\_id

共享中断时使用。

在flags参数中,可以选择一些与中断管理有关的选项如:

• IRQF\_DISABLED ( SA\_INTERRUPT )

如果设置该位,表示是一个"快速"中断处理程序;如果没有设置这位,那么是一个"慢速"中断处理程序。

• IRQF\_SHARED ( SA\_SHIRQ )


该位表明该中断号是多个设备共享的。

快/慢速中断的主要区别在于:快速中断保证中断处理的原子性(不被打断),而慢速中断则不保证。换句话说,也就是"开启中断"标志位(处理器印)在运行快速中断处理程序时是关闭的,因此在服务该中断时,不会被其他类型的中断打断,而调用慢速中断处理时,其它类型的中断仍可以得到服务。

## 2.2.2、中断处理

中断处理程序的特别之处是在中断上下文中运行的,它的行为受到某些限制:

- 1.不能使用可能引起阻塞的函数
- 2.不能使用可能引起调度的函数




# 2.2.3、注销处理

当设备不再需要使用中断时(通常在驱动卸载时), 应当把它们注销, 使用函数: void free\_irq(unsigned int irq, void \*dev\_id)

# 三、按键区动硬件操作实现

## 四、中断分层处理

#### 4.1、中断嵌套



## 4.2、中断分层方式

上半部: 当中断发生时,它进行相应地硬件读写,并"登记"该中断。通常由中断处理程序充当上半部。

下半部:在系统空闲的时候对上半部"登记"的中断进行后续处理。

4.2.1、软中断

4.2.2 tasklet


# 4.2.3、工作队列

#include finux/module.h>
#include finux/init.h>
#include finux/workqueue.h>
#include finux/slab.h>

struct workqueue\_struct \* my\_wq; struct work\_struct \* work1; struct work\_struct \* work2;

```
void work1_func(struct work_struct * work)
  printk(KERN_WARNING"this is work1->\n");
void work2_func(struct work_struct * work)
  printk(KERN_WARNING"this is work2->\n");
static int queue_init(void)
  /*creat workqueue*/
  my_wq = create_workqueue("my_wq");
  work1 = kmalloc(sizeof(struct work_struct), GFP_KERNEL);
  INIT_WORK(work1, work1_func);
  /*queue work*/
  queue_work(my_wq, work1);
  /*init work*/
  work2 = kmalloc(sizeof(struct work_struct), GFP_KERNEL);
  INIT WORK(work2, work2 func);
  /*queue work*/
  queue_work(my_wq, work2);
  return 0;
static void queue_exit(void)
module_init(queue_init);
module_exit(queue_exit);
MODULE_LICENSE("GPL");
```

工作队列是一种将任务推后执行的形式,他把推后的任务交由一个内核线程去执行。这样下半部会在进程上下文执行,它允许重新调度甚至睡眠。每个被推后的任务叫做"工作",由这些工作组成的队列称为工作队列。



## 4.3、使用工作队列实现分层

# 在大多数情况下,驱动并不需要自己建立工作队列,只需定义工作,然后将工作提交到内核已经定义好的工作队列keventd\_wq中。 1. 提交工作到默认队列

schedule\_work

```
key.c:
#include linux/module.h>
#include linux/init.h>
#include linux/miscdevice.h>
#include linux/interrupt.h>
#include linux/fs.h>
#include ux/io.h>
#include linux/workqueue.h>
#include linux/slab.h>
#define GPNCON 0x7f008830
struct work_struct * work1;
void work1_func(struct work_struct * work)
  printk(KERN_WARNING"key down!\n");
static irqreturn_t key_int(int irq, void *dev_id)
  /*Check if a key interrupt has occurred */
  /*Clear key interrupts that have occurred(If it is a CPU internal interrupt (non-peripheral), the system will help clear) */
  /*Submit the bottom half */
    /*queue work*/
  schedule_work(work1);
  return 0;
void key_hw_init(void)
  unsigned int data;
  unsigned int * gpio_config;
  gpio_config = ioremap(GPNCON, 4);
  data = readl(gpio_config);
  data &= ~0b11;
                             //set key1
  data |= 0b10;
  writel(data, gpio_config);
int key_open(struct inode * node, struct file * filp)
{
  return 0;
struct file_operations key_fops = {
  .open = key_open,
struct miscdevice key_miscdev = {
  .minor = 200,
  .name = "key",
  .fops = &key_fops,
};
static int key_init(void)
  printk(KERN WARNING"key init\n");
```

```
misc_register(&key_miscdev);
  request_irq(S3C_EINT(0), key_int, IRQF_TRIGGER_FALLING, "key", 0);
  key_hw_init();
  /*init work*/
  work1 = kmalloc(sizeof(struct work_struct), GFP_KERNEL);
  INIT WORK(work1, work1 func);
  return 0;
static void key_exit(void)
  printk(KERN_WARNING"key exit\n");
  free_irq(S3C_EINT(0), 0);
  misc_deregister(&key_miscdev);
module_init(key_init);
module_exit(key_exit);
MODULE LICENSE("GPL");
Makefile:
obj-m := key.o
KDIR := /home/S5-driver/lesson7/linux-ok6410
  make -C $(KDIR) M=$(PWD) modules CROSS_COMPILE=arm-linux- ARCH=arm
clean:
  rm -f *.order *.symvers *.mod.o *.o *.ko *.mod.c
五、按键定时器去抖
#include linux/module.h>
#include linux/init.h>
#include linux/miscdevice.h>
#include linux/interrupt.h>
#include ux/fs.h>
#include ux/io.h>
#include linux/workqueue.h>
#include linux/slab.h>
#include linux/timer.h>
#define GPNCON 0x7f008830
#define GPNDAT 0x7f008834
struct work_struct * work1;
struct timer_list key_timer;
unsigned int * gpio_data;
void work1_func(struct work_struct * work)
{
  mod_timer(&key_timer, jiffies + HZ/10);
void key_timer_func(unsigned long data)
  unsigned int key_val;
```

```
key_val = readl(gpio_data) & 0x01;
  if (key_val == 0) {
     printk(KERN_WARNING"key down!\n");
}
static irgreturn_t key_int(int irg, void *dev_id)
  /*Check if a key interrupt has occurred */
  /*Clear key interrupts that have occurred(If it is a CPU internal interrupt (non-peripheral), the system will help clear) */
  /*Submit the bottom half */
     /*queue work*/
  schedule_work(work1);
  return 0;
void key_hw_init(void)
  unsigned int data;
  unsigned int * gpio_config;
  gpio_config = ioremap(GPNCON, 4);
  data = readl(gpio_config);
  data &= ~0b11;
                              //set key1
  data |= 0b10;
  writel(data, gpio_config);
  gpio_data = ioremap(GPNDAT, 4);
int key_open(struct inode * node, struct file * filp)
  return 0;
struct file_operations key_fops = {
  .open = key_open,
};
struct miscdevice key_miscdev = {
  .minor = 200,
  .name = "key",
  .fops = &key_fops,
};
static int key_init(void)
  printk(KERN_WARNING"key init\n");
  misc_register(&key_miscdev);
  request_irq(S3C_EINT(0), key_int, IRQF_TRIGGER_FALLING, "key", 0);
  key_hw_init();
  /*init work*/
  work1 = kmalloc(sizeof(struct work struct), GFP KERNEL);
  INIT_WORK(work1, work1_func);
  /*init timer */
```

```
init_timer(&key_timer);
  key_timer.function = key_timer_func;

/*register timer */
  add_timer(&key_timer);

return 0;
}

static void key_exit(void)
{
  printk(KERN_WARNING"key exit\n");
  free_irq(S3C_EINT(0), 0);
  misc_deregister(&key_miscdev);
}

module_init(key_init);
  module_exit(key_exit);
MODULE_LICENSE("GPL");
```

## 5.1、按键抖动

按键所用开关为机械的单性开关,当机械触点断开、闭合时,由于机械触点的弹性作用,开关不会马上稳定地接通或断开。因而在闭合及断开的瞬间总是伴随有一连串的抖动。

# 5.2、按键消斗的方法

按键去抖动的方法主要有二种,一种是硬件 电路去抖动;另一种就是软件延时去抖。而延 时又一般分为二种,一种是for循环等待,另一种是定时器延时。在操作系统中,由于效 率方面的原因,一般不允许使用for循环来等 待,只能使用定制器。

#### 5.3、内核定时器

Linux内核使用struct timer\_list来描述一个定时器:

```
struct timer_list {
    struct list_head entry;
    unsigned long expires;
    void (*function)(unsigned long);
    unsigned long data;
    struct tvec_base *base;
};
```

## 5.4、定时器使用流程

5.4.1、定义定时器变量

5.4.2、初始化定时器

5.4.2.1、init\_timer初始化

5.4.2.1、设置超时函数

5.4.3、add timer注册定时器

5.4.4、mod\_timer启动定时器

# 5.5、Linux定时器理解内容

在linux内核里,有一个叫jiffies的变量(定义在linux/jiffies)记录了自系统启动以来产生的节拍的总数。启动时,内核将该变量初始化为0,此后每次时钟中断处理程序都会增加该变量的值。因为一秒内时钟中断的次数等于HZ,所以jiffies一秒内增加的值也就为HZ.系统运行时间以秒为单位计算,就等于jiffes/HZ.它作为在计算机表示的变量,就总存在大小,当这个变量增加到超出它的表示上限时,就要回绕到0.这个回绕看起来很简单,但实际上还是给我们编程造成了很大的麻烦,比如边界条件判断时。幸好,内核提供了四个宏来帮助比较节拍计数,这些宏定义在linux/jiffies.h可以很好的处理节拍回绕的情况。

Linux是使用一个硬件定时器模拟成一个超级定时器,可以产生多个软中断。

```
key.c:
#include linux/module.h>
#include linux/init.h>
#include linux/miscdevice.h>
#include linux/interrupt.h>
#include ux/fs.h>
#include ux/io.h>
#include linux/workqueue.h>
#include linux/slab.h>
#include linux/timer.h>
#include linux/uaccess.h>
#define GPNCON 0x7f008830
#define GPNDAT 0x7f008834
struct work_struct * work1;
struct timer_list key_timer;
unsigned int * gpio_data;
unsigned int key_num;
void work1_func(struct work_struct * work)
{
  mod_timer(&key_timer, jiffies + HZ/10);
void key_timer_func(unsigned long data)
  unsigned int key_val;
  key_val = readl(gpio_data) & 0b11;
  if (key_val == 0b10) {
    key_num = 1;
  if (key_val == 0b01) {
    key_num = 2;
static irqreturn_t key_int(int irq, void *dev_id)
  /*Check if a key interrupt has occurred */
  /*Clear key interrupts that have occurred(If it is a CPU internal interrupt (non-peripheral), the system will help clear) */
  /*Submit the bottom half */
    /*queue work*/
  schedule_work(work1);
  return 0;
void key_hw_init(void)
  unsigned int data;
  unsigned int * gpio_config;
  gpio_config = ioremap(GPNCON, 4);
  data = readl(gpio_config);
                               //set key1 and key2
  data &= ~0b1111;
  data |= 0b1010;
  writel(data, gpio_config);
  gpio_data = ioremap(GPNDAT, 4);
```

```
int key_open(struct inode * node, struct file * filp)
  return 0;
}
ssize_t key_read (struct file * filp, char __user * buf, size_t size, loff_t * pos)
{
  copy_to_user(buf, &key_num, 4);
  return 4;
ssize_t key_write (struct file * filp, const char _user * buf, size_t size, loff_t * pos)
  return 0;
int key_close (struct inode * node, struct file * filp)
{
  return 0;
struct file_operations key_fops = {
  .open = key_open,
  .read = key_read,
  .write = key_write,
  .release = key_close,
};
struct miscdevice key_miscdev = {
  .minor = 200,
  .name = "key"
  .fops = &key_fops,
};
static int key_init(void)
  printk(KERN_WARNING"key init\n");
  misc_register(&key_miscdev);
  request_irq(S3C_EINT(0), key_int, IRQF_TRIGGER_FALLING, "key", 0);
  request_irq(S3C_EINT(1), key_int, IRQF_TRIGGER_FALLING, "key", 0);
  key_hw_init();
  /*init work*/
  work1 = kmalloc(sizeof(struct work_struct), GFP_KERNEL);
  INIT_WORK(work1, work1_func);
  /*init timer */
  init_timer(&key_timer);
  key_timer.function = key_timer_func;
  /*register timer */
  add_timer(&key_timer);
  return 0;
static void key_exit(void)
  printk(KERN_WARNING"key exit\n");
  free_irq(S3C_EINT(0), 0);
```

```
misc_deregister(&key_miscdev);
module_init(key_init);
module_exit(key_exit);
MODULE_LICENSE("GPL");
key_app.c:
#include <stdio.h>
#include <stdlib.h>
int main(void)
int fd;
int key_num;
/*open device*/
fd = open("/dev/ok6410key", 0);
if (fd < 0)
 printf("open device fail!\n");
/*read device*/
read(fd, &key_num, 4);
printf("key is %d\n", key_num);
/*close device*/
close(fd);
                                                                                                VDD_IO
                                                  XEXTCLK W11
AC17
AC16
XXTI
AZ7MXTO
AB14
                                                                                        100k
                                                                                                    XTO
                                                                                                    XTI
                                                 X27MXTO
X27MXTI
                                                                                                     27MXTO
                                                            AB15
AD12
AB9
                                                                                                    27MXTI
                                                                                                    RTCXTO
                                                  XRTCXTO
                                                                                                    RTCXTI
                                                  XRTCXTI
                                                            D23
H16
                                                                                                    PWM_TOUT1
                                      XPWMTOUT1/GPF15
                           XPWMTOUT0/XCLKOUT/GPF14
XPWMECLK/GPF13
                                                                                                    CLKOUT
                                                                                                    GPF13
                                                            AE17
V10
AD17
AB17
AE18
AC18
                                                                                                    KEYINT1
                                   XEINTO/KPROWO/GPN0
                                                                                                     KEYINT2
                                   XEINT1/KPROW1/GPN1
XEINT2/KPROW2/GPN2
XEINT3/KPROW3/GPN3
                                                                                                    KEYINT3
                                                                                                     KEYINT4
                                                                                                     KEYINT5
                                   XEINT4/KPROW4/GPN4
YEINT5/KPROW5/GPN5
                                                                                                     KEYINT6
MMC1_CDN
                                    XEINT6/KPROW6/GPN6
                                                             AC19
W12
                                                                                                    IRQ_LAN
EINT8
                                   XEINT7/KPROW7/GPN7
                                          7/KPROW//GPN7
XINT8/GPN8
XINT9/GPN9
XEINT10/GPN10
XINT11/GPN11
XEINT12/GPN12
XEINT13/GPN13
XEINT14/GPN14
XEINT15/GPN15
XEINT15/GPN15
                                                                                                    EINT9
                                                                                                    EINT10
                                                                                                    EINT11
                                                                                                    EINT12
                                                                                                    EINT13
EINT14
                                                                                                    EINT15
七、阻塞型驱动设计
#include linux/module.h>
#include linux/init.h>
#include linux/miscdevice.h>
#include linux/interrupt.h>
```

#include linux/fs.h>
#include linux/io.h>

```
#include linux/workqueue.h>
#include linux/slab.h>
#include linux/timer.h>
#include linux/uaccess.h>
#include linux/wait.h>
#include linux/sched.h>
#define GPNCON 0x7f008830
#define GPNDAT 0x7f008834
struct work struct * work1;
struct timer_list key_timer;
unsigned int * gpio_data;
unsigned int key_num = 0;
wait_queue_head_t key_q;
void work1_func(struct work_struct * work)
{
  mod_timer(&key_timer, jiffies + HZ/10);
void key_timer_func(unsigned long data)
  unsigned int key_val;
  key_val = readl(gpio_data) & 0b11;
  if (key_val == 0b10) {
    key_num = 1;
  if (key_val == 0b01) {
    key_num = 2;
  wake_up(&key_q);
static irqreturn_t key_int(int irq, void *dev_id)
  /*Check if a key interrupt has occurred */
  /*Clear key interrupts that have occurred(If it is a CPU internal interrupt (non-peripheral), the system will help clear) */
  /*Submit the bottom half */
    /*queue work*/
  schedule_work(work1);
  return 0;
void key_hw_init(void)
  unsigned int data;
  unsigned int * gpio_config;
  gpio_config = ioremap(GPNCON, 4);
  data = readl(gpio_config);
  data &= ~0b1111;
                               //set key1 and key2
  data |= 0b1010;
  writel(data, gpio_config);
  gpio_data = ioremap(GPNDAT, 4);
```

```
int key_open(struct inode * node, struct file * filp)
  return 0;
ssize_t key_read (struct file * filp, char __user * buf, size_t size, loff_t * pos)
  wait_event(key_q, key_num);
  copy_to_user(buf, &key_num, 4);
  key_num = 0;
  return 4;
ssize_t key_write (struct file * filp, const char _user * buf, size_t size, loff_t * pos)
{
  return 0;
int key_close (struct inode * node, struct file * filp)
{
  return 0;
}
struct file_operations key_fops = {
  .open = key_open,
  .read = key_read,
  .write = key_write,
  .release = key_close,
struct miscdevice key miscdev = {
  .minor = 200,
  .name = "key",
  .fops = &key_fops,
};
static int __init ok6410_key_init(void)
  printk(KERN_WARNING"key init\n");
  misc_register(&key_miscdev);
  request_irq(S3C_EINT(0), key_int, IRQF_TRIGGER_FALLING, "key", 0);
  request_irq(S3C_EINT(1), key_int, IRQF_TRIGGER_FALLING, "key", 0);
  key_hw_init();
  /*init work*/
  work1 = kmalloc(sizeof(struct work_struct), GFP_KERNEL);
  INIT_WORK(work1, work1_func);
  /*init timer */
  init_timer(&key_timer);
  key_timer.function = key_timer_func;
  /*register timer */
  add_timer(&key_timer);
  /*init wait queue*/
  init_waitqueue_head(&key_q);
  return 0;
```

```
static void __exit ok6410_key_exit(void)
{
    printk(KERN_WARNING"key exit\n");
    free_irq(S3C_EINT(0), 0);
    misc_deregister(&key_miscdev);
}

module_init(ok6410_key_init);
    module_exit(ok6410_key_exit);
MODULE_LICENSE("GPL");
```

## 7.1、阻塞必要性

当一个设备无法立刻满足用户的读写请求时应当如何处理?例如:调用read时,设备没有数据提供但以后可能会有;或者一个进程试图向设备写入数据,但是设备暂时没有准备好接收数据。当上述情况发生的时候,驱动程序应当(缺省地)阻塞进程,使它进入等待(睡眠)状态,直到请求可以得到满足。

#### 7.2、内核等待队列0

在实现阻塞驱动的过程中,也需要有一个"候车室"来安排被阻塞的进程"休息",当唤醒它们的条件成熟时,则可以从"候车室"中将这些进程唤醒。而这个"候车室"就是等待队列。

1、定义等待队列

wait\_queue\_head\_t my\_queue

2、初始化等待队列

init\_waitqueue\_head(&my\_queue)

3、定义+初始化等待队列

DECLARE\_WAIT\_QUEUE\_HEAD(my\_queue)

4、进入等待队列,睡眠

wait\_event(queue,condition)

当condition(布尔表达式)为真时,立即返回;否则让进程进入TASK\_UNINTERRUPTIBLE模式的睡眠,并挂在queue参数所指定的等待队列上。

wait\_event\_interruptible(queue,condition)

当condition(布尔表达式)为真时,立即返回;否则让进程进入TASK\_INTERRUPTIBLE的睡眠,并挂在queue参数所指定的等待队列上。int wait\_event\_killable(queue, condition)

当condition(一个布尔表达式)为真时,立即返回;否则让进程进入TASK\_KILLABLE的睡眠,并挂在queue参数所指定的等待从列上。5、从等待从列中唤醒进程

wake\_up(wait\_queue\_t \*q)

从等待队列q中唤醒状态为TASK\_UNINTERRUPTIBLE, TASK\_INTERRUPTIBLE, TASK\_KILLABLE的所有进程。 wake up interruptible(wait queue t\*q)

从等待队列q中唤醒状态为TASK\_INTERRUPTIBLE 的进程

## 7.3、阻塞驱动优化

驱动程序通常需要提供这样的能力:当应用程序进行read(),write()等系统调用时,若设备的资源不能获取,而用户又希望已阻塞的方式访问设备,驱动程序应在设备的xxx\_read(),xxx\_writ()等操作过程中将进程阻塞直到资源可以获取,以后,应用程序的read(),write()等调用才能返回,整个过程仍然进行了正确的设备访问,用户并没有感值到。