CLRWDT

< Previous instruction: <u>CLRF</u> | Instruction <u>index</u> | Next instruction: <u>COMF</u> >

CLRWDT Clear Watchdog Timer

Syntax: [label] CLRWDT

Operands: None

Operation: $000h \rightarrow WDT$,

000h → WDT postscaler,

 $\begin{array}{l} 1 \rightarrow \overline{\text{TO}}, \\ 1 \rightarrow \overline{\text{PD}} \end{array}$

Status Affected: TO, PD

Encoding: 0000 0000 0000 0100

Description: CLRWDT instruction resets the

Watchdog Timer. It also resets the postscaler of the WDT. Status bits

TO and PD are set.

Words: 1 Cycles: 1

Q Cycle Activity:

Q1	Q2	Q3	Q4
Decode	No	Process	No
	operation	Data	operation

Example: CLRWDT

Before Instruction

WDT Counter = ?

After Instruction

 $\begin{array}{lll} \text{WDT Counter} & = & 0x00 \\ \underline{\text{WDT Postscaler}} & = & 0 \\ \underline{\text{TO}} & = & 1 \\ \hline{\text{PD}} & = & 1 \end{array}$

< Previous instruction: <u>CLRF</u> | Instruction <u>index</u> | Next instruction: <u>COMF</u> >