

3. Drainage

Method of works

Method of works to be followed when installing new drainage system underground on private property.

- Refer to CPP and PCI to establish where and what works will be carried out
- Ensure site is set up correctly with correct guarding and signage in place in accordance with the CPP
- Ensure there are no underground services present, refer to *Cat and Genny Procedure* along with utility providers drawings if present
- If a layer of stone, concrete or tarmac needs to be cut, refer to Rotary Disc Cutter and Excavations
- Dig the area
 - o Machine Dig refer to Excavations
 - O Dig the area to a depth accounting for the fall of the pipework, and/or inspection chamber and anything else being installed as per works, accounting for backfill of sand, pea-gravel and or spoil
- Install the drainage system as per manufactures instructions
 - Ensure correct fall of pipework using spirit level
 - o If installing a chamber, use a spirit level to ensure cover is level with surrounding groundwork after backfill-this also applies if rodding points are being installed
 - If adhesives are used, follow all COSHH data sheets and ensure all PPE is work as per these instructions
 - o Test the system, ensuring that the pipework is fully supported to prevent damage
- Ensure all covers are fitted, backfill the area using sand, pea-gravel or the spoil if fine soft soil ensuring the pipe work is fully covered
- Backfill with remaining spoil
- Compact spoil using hand tamp or Whacker plate/trench compactor-*Refer to HAVS*. If a layer of concrete or tarmac is to be used for the upper layer, mix as per manufacturer's instructions following all COSHH assessments and finish as per PCI/required finish
- Clean and sweep the area, disposing of any remaining spoil or rubble via site skips or as per CPP waste management plan

See additional docs

Permit to dig
Cat and Genny procedure
Excavations
COSHH assessments
HAVS procedure
Rotary Disc cutter



Risk Assessment

Hazard	Control Measures
Falls from Height	Refer to Working At Height
	Extra care must be given around excavation considering uneven ground and loose spoil and additional trip hazards.
	Extra consideration must be given to the prevention of falls from
	MOP/tenants/building occupiers and guarding must be readily available before the dig commences
Chemicals	Refer to COSHH assessments and ensure additional PPE is worn if required.
Underground Services	Refer to site specific RAMS, Permit to dig and CAT and Genny Procedure
Weather	Sun: Advice will be taken from the H&S team when working outside and refer to TBT
	and contract managers advice
	Rain: Consider what actions will be taken in the event of excavation being filled with
	water and if there are any environmental implications with silt run off from the spoil
Falling objects	Ensure there is adequate distance between the excavation and the spoil to prevent
	objects falling back in on exposed services or personnel
Slips, trips and falls	Only persons working in the area will have access to the pipework in the ground. The
	pipework will not be used as a step
Manual Handling	Care will be taken when bending down in the excavation, fitting pipework. Bending
	using the knees and not the lower back
Respirable dust	Refer to RDC procedure, ensuring all dust is dampened down if floor cutting is be
	carried out

PPE

