

Lesson 7 Raspberry Pi WLAN Connection

1. LAN Mode Introduction


Local Area Network (LAN) mode is to connect to the wireless router which is more complicated and cannot coexist with the direct connection mode. To return to direct connection Mode, you can long press KEY1 on the expansion board until LED2 flashes.

This section takes the Android version as an example. The operation steps are applicable to the Apple version. If you just want to learn the connection method of LAN mode, you can check “2. Quick User Experience/Lesson 3 (Optional) LAN Mode Connection” directly.

Before starting, please turn on the robot.


2. LAN Mode Connection

1) Disconnect the hotspot under direct connection mode. Open WonderPi, click “+” button to choose the “LAN Mode”. Then follow the interface prompts to set up Wi-Fi connection.







2) Click the Wi-Fi to connect (take "LH" as example).



3) After the connection is complete, return to the APP to enter the password of the connected Wi-Fi (if prompt does not pop up, click "LAN Mode" again), and then click "Next". (Please enter the password correctly otherwise the connection will fail)



4) According to the APP prompt, go to the settings again to connect to the hotspot named with the first letters "HW".



5) After connecting to the hotspot, you will find that the APP is connecting automatically. During the connection process, if you are prompted whether to join, click "Join".



6) After a while, it will back to the APP home interface and the LED1 on the expansion board will stop flashing and remain on as LED2, which means that the Raspberry Pi is successfully connected to the Internet.



7) You can long press the robot icon in the APP to check the IP and ID.

