EEL 6509 Wireless Communications—Fading Dr. John M. Shea

1 Overview

- Fading
 - Review: Time Dispersion Parameters
 - Frequency Dispersion Parameters.
 - Classification (Types of Fading)
 - Rayleigh & Rician Distributions
 - Clarke's/Jakes Fading Model

2 Time Dispersion Parameters

- based on power delay profile (PDP)
- mean excess delay, $\overline{\tau}$ = mean delay of PDP
- RMS delay spread = σ_{τ} = standard deviation of PDP
- coherence bandwidth = $B_C \propto \frac{1}{\sigma_{\tau}}$

3 Frequency Dispersion Parameters

Doppler Spread, $B_D = f_m$

- measure of spectral broadening
- equal to max. Doppler shift = $\frac{v}{\lambda}$ Coherence Time, T_C
- measure of time duration over which channel impulse response is \approx constant
- Loose approximation,

$$T_C \approx \frac{1}{f_m} \tag{1}$$

• For time correlation > 0.5,

$$T_C \approx \frac{9}{16\pi f_m} \tag{2}$$

• Rule of thumb used for modern digital comm., T_C = geometric mean of 1 and 2,

$$T_C \approx \sqrt{\frac{9}{16\pi f_m^2}} \approx \frac{0.423}{f_m}$$

4 Classification of Fading

- depends on nature of transmitted signal with respect to characteristics of channel
- 2 difference (and indep.) fading effects:
 - 1. Multipath delay spread leads to time dispersion and frequency-selective fading
 - 2 possibilities:

Flat Fading

BW of signal < BW of channel

BW of signal > BW of channel

Delay spread < Symbol period

Delay spread > Symbol period

2. Doppler spread leads to freq. dispersion and time-selective fading Again, 2 possibilities:

Fast Fading
High Doppler spread
Coherence time < Symbol period Coherence time >> Symbol period

• time dispersion and freq. dispersion are caused by independent propagation mechanisms

4.1 Effects due to multipath Delay

1. Flat Fading

- channel response has flat gain and linear phase over BW that is > signal BW
- spectral characteristics of signal are preserved over time




Figure 4.12 Flat fading channel characteristics.

Rappaport, P. 168

- gain of signal varies over time
- flat fading channels are also known as *amplitude varying channels* and *narrowband channels* (signal BW is narrow compared to channel BW)
- signal undergoes flat fading if

$$B_S \ll B_C$$

and

$$T_S >> \sigma_{\tau}$$

2. Frequency Selective Fading

- BW over which channel has constant gain and linear phase ≮BW of signal
- caused by *intersymbol interference*, where received signal consists of multiple delayed and attenuated versions of transmitted signal




Figure 4.13 Frequency selective fading channel characteristics.

Rappapart P.170

• signal undergoes freq.-selective fading if

$$B_S > B_C$$

and

$$T_S < \sigma_{\tau}$$

• Rule of thumb: channel is freq.-selective if $T_S \leq 10\sigma_{\tau}$

4.2 Effects due to Doppler spread

1. Fast fading

- channel impulse response changes rapidly within symbol duration
- occurs if $T_S > T_C$, $B_S < B_D$
- in practice, only occurs for very low data rates

2. Slow fading

- impulse response changes much slower than transmitted signal
- occurs if $T_S \ll T_C$, $B_S \gg B_D$

5 Fading Distributions

5.1 Rayleigh Distribution


- used to model envelope of received signal or individual multipath component as random variable or random process
- used when no line-of-sight or other dominant non-fading path exists
- used for flat fading

Rayleigh PDF:

$$p(r) = \begin{cases} \frac{r}{\sigma^2} \exp\left\{-\frac{r^2}{2\sigma^2}\right\}, & 0 \le r < \infty \\ 0, & r < 0 \end{cases}$$

 σ^2 = avg. power of received signal before detection

Rapporport, Fighlo, p. 174 Rayleigh PDF



Received signal envelope voltage r (volts)







Figure 4.15 A typical Rayleigh fading envelope at 900 MHz [From [Fun93] © IEEE].

5.2 Rician Distribution

- used when LOS path or other dominant non-fading path exists
- characterized by Rician factor K that compares signal power in nonfading path to variance of multipath
- For $K \to -\infty$ dB, Rician \to Rayleigh

Rician density: Rappaport Fig 4.18, P. 176



Received signal envelope voltage r (volts)

6 Clarke's Model for Flat Fading

- ullet models received signal as N plane waves with equal amplitudes and arbitrary phases and azimuthal angles of arrival
- each wave undergoes Doppler shift dependent on velocity and angle of arrival
- resultant signal envelope is Rayleigh random variable
- Doppler power spectrum of an unmodulated wave:




Figure 4.20
Doppler power spectrum for an unmodulated CW carrier [From [Gan72]] © IEEE].