





Corner #0 (top-left of plan)



Corner #1 (top-right of plan)



Corner #2 (bottom-right of plan)



Corner #3 (bottom-left of plan)

Spares. plan_print already includes these in the right place.
If you place them by hand, update the corner positions in plan.json.