

ISE Sample Calculation Worksheet

Calculations Verified By MD Date 02-18-2026

Sample Name	Type	Solution Volume	Aliquot Factor*	ppm F-	ug F-	Air Volume	mg/M3	X Mol. Vol./At. Wt. = ppm F-
QC131052	1280	50	1	1.92	96		#DIV/0!	#DIV/0!
QC131053	1280	50	1	3.66	183		#DIV/0!	#DIV/0!
QC131054	1280	50	1	7.2	360		#DIV/0!	#DIV/0!
QC131055	1280	50	1	0.164	8.2		#DIV/0!	#DIV/0!
F58027	1280	50	1	0.147	7.35	79.04	0.092990891	0.119677191
F58028	1280	50	1	0.161	8.05	83.6	0.096291866	0.123925472
F58029	1280	50	1	0.18	9	88.16	0.102087114	0.131383827
F58030	1280	50	1	0.158	7.9	98.8	0.079959514	0.102906102
F58031	1280	50	1	0.165	8.25	91.2	0.090460526	0.116420669
F58032	1280	50	1	0.158	7.9	88.16	0.0896098	0.115325804
F58033	1280	50	1	0.163	8.15	98.8	0.082489879	0.106162624
F58034	1280	50	1	0.162	8.1		#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!

HD 2/12/2026

Molar volume: 24.45 (25 degrees C and 760mm Hg); Molecular weight (F) = 18.998

HF is reported as ppm F-

Formulae:

ug Fluoride = ppm Fluoride X Aliquot Volume X Dilution Factor

IMIS 1280: mg/M3 Fluoride = ug Sample/Air Volume, L

IMIS 1460: ppm Fluoride = Molar Volume X ug Sample/(Molecular Wt. X Air Volume, L)