

ISE Sample Calculation Worksheet

Calculations Verified By JAD Date 02-18-2026

Sample Name	Type	Solution Volume	Aliquot Factor*	ppm F-	ug F-	Air Volume	mg/M3	X Mol. Vol./At. Wt. = ppm F-
QC131268	1460	50	1	1.76	88		#DIV/0!	#DIV/0!
QC131269	1460	50	1	3.34	167		#DIV/0!	#DIV/0!
QC131270	1460	50	1	6.82	341		#DIV/0!	#DIV/0!
QC131271	1460	50	1	0.148	7.4		#DIV/0!	#DIV/0!
F58027	1460	50	1	0.13	6.5	79.04	0.082236842	0.105836972
F58028	1460	50	1	0.118	5.9	83.6	0.070574163	0.090827365
F58029	1460	50	1	0.117	5.85	88.16	0.066356624	0.085399488
F58030	1460	50	1	0.12	6	98.8	0.060728745	0.078156533
F58031	1460	50	1	0.124	6.2	91.2	0.067982456	0.087491897
F58032	1460	50	1	0.121	6.05	88.16	0.068625227	0.088319128
F58033	1460	50	1	0.113	5.65	98.8	0.057186235	0.073597402
F58034	1460	50	1	0.119	5.95		#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!
							#DIV/0!	#DIV/0!

HD 2/12/2026

Molar volume: 24.45 (25 degrees C and 760mm Hg); Molecular weight (F) = 18.998

HF is reported as ppm F-

Formulae:

ug Fluoride = ppm Fluoride X Aliquot Volume X Dilution Factor

IMIS 1280: mg/M3 Fluoride = ug Sample/Air Volume, L

IMIS 1460: ppm Fluoride = Molar Volume X ug Sample/(Molecular Wt. X Air Volume, L)