

Semiconductor English

Instructor guide for advanced ESL learners working in semiconductor

Audience: semiconductor process engineers, yield engineers, product engineers, equipment engineers, fab supervisors, quality teams, test and packaging teams, foundry coordinators, supply planners, applications engineers, and technical program managers

Focus: A semiconductor English curriculum for wafer fabrication, lithography, process integration, deposition and etch, metrology, yield learning, cleanroom discipline, equipment uptime, packaging, reliability qualification, foundry communication, and customer pressure.

Designed for advanced ESL learners who already use professional English and need industry-specific terminology, realistic meetings, role-play pressure, careful pushback, and polished workplace outputs.

Teaching stance: this is language and workplace-communication training, not legal, medical, financial, safety, or regulatory advice. Instructors should connect every scenario to the learner's current company policies, local rules, and approved procedures.

Purpose and Course Logic

A semiconductor English curriculum for wafer fabrication, lithography, process integration, deposition and etch, metrology, yield learning, cleanroom discipline, equipment uptime, packaging, reliability qualification, foundry communication, and customer pressure.

Core language challenge

Advanced learners do not only need vocabulary. They need the ability to ask which standard applies, who owns the decision, what evidence is sufficient, what risk is being accepted, and how to disagree without sounding vague, defensive, or reckless.

Each module trains a realistic workplace pressure point with role-specific terms, decision language, pushback practice, and a written output learners can adapt to their own work.

Course objectives

- Use semiconductor terminology accurately in meetings, written updates, handoffs, escalations, reviews, and client or stakeholder conversations.
- Turn vague requests into specific questions about evidence, owner, deadline, constraint, risk, and decision rights.
- Push back on unsafe, unsupported, noncompliant, unrealistic, or poorly scoped proposals while preserving professional trust.
- Handle realistic dialogues from the field, including conflict, uncertainty, documentation gaps, customer or stakeholder pressure, and cross-functional disagreement.
- Produce concise workplace outputs: briefing notes, escalation updates, meeting scripts, risk memos, decision records, and follow-up messages.

Instructor Module Plans

Module 1. Wafer Fabrication Flow and Process Integration (90 minutes)

Explain the fab process as a controlled sequence of dependencies, not a simple production line.

Learners should be able to

- Use these terms accurately: wafer, fab, process flow, node.
- Explain the workplace tension: Process flow, route control, layer dependency, and integration risk must be confirmed before movement.
- Respond professionally when a stakeholder says: Release the lot to protect the customer schedule.
- Draft a usable lot-disposition recommendation with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A program manager asks why one wafer lot cannot skip a hold and move directly to the next module.

Release the lot to protect the customer schedule.

Process flow, route control, layer dependency, and integration risk must be confirmed before movement.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.

3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a lot-disposition recommendation.

Module 2. Lithography, Reticles, and Critical Dimensions (90 minutes)

Discuss patterning risk with enough precision for engineers and enough clarity for non-specialists.

Learners should be able to

- Use these terms accurately: lithography, photoresist, reticle, critical dimension.
- Explain the workplace tension: Reticle status, photoresist behavior, exposure conditions, metrology repeatability, and control limits need review.
- Respond professionally when a stakeholder says: Tell them the lithography module is under control.
- Draft a usable lithography risk update with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A customer asks whether a critical-dimension trend is only a measurement artifact.

Tell them the lithography module is under control.

Reticle status, photoresist behavior, exposure conditions, metrology repeatability, and control limits need review.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a lithography risk update.

Module 3. Deposition, Etch, CMP, and Process Windows (90 minutes)

Connect process module changes to downstream device performance.

Learners should be able to

- Use these terms accurately: deposition, etch, CMP, process window.
- Explain the workplace tension: Deposition uniformity, etch selectivity, CMP margin, and the qualified process window must be protected.
- Respond professionally when a stakeholder says: Approve the recipe because cycle time improves.
- Draft a usable process-window tradeoff memo with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A team wants to widen an etch recipe to improve throughput.

Approve the recipe because cycle time improves.

Deposition uniformity, etch selectivity, CMP margin, and the qualified process window must be protected.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.

2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a process-window tradeoff memo.

Module 4. Metrology, SPC, and Yield Learning (90 minutes)

Use data language that separates signal, noise, and urgent excursion.

Learners should be able to

- Use these terms accurately: metrology, SPC, yield, excursion.
- Explain the workplace tension: SPC trends, sampling change, tool history, defect signatures, and product mix must be separated.
- Respond professionally when a stakeholder says: Call it a bad lot and move on.
- Draft a usable yield-learning brief with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A dashboard shows yield loss after a new metrology sampling plan.

Call it a bad lot and move on.

SPC trends, sampling change, tool history, defect signatures, and product mix must be separated.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a yield-learning brief.

Module 5. Defect Density and Cleanroom Contamination (90 minutes)

Escalate contamination risk without creating blame or panic.

Learners should be able to

- Use these terms accurately: defect density, particle, cleanroom, contamination control.
- Explain the workplace tension: Defect density, cleanroom protocol, contamination source, containment, and affected-lot traceability require action.
- Respond professionally when a stakeholder says: Restart production and watch the next few lots.
- Draft a usable contamination containment note with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A particle excursion appears after maintenance in a critical bay.

Restart production and watch the next few lots.

Defect density, cleanroom protocol, contamination source, containment, and affected-lot traceability require action.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a contamination containment note.

Module 6. Equipment Uptime, Recipes, and Tool Matching (90 minutes)

Discuss equipment pressure without sacrificing process control.

Learners should be able to

- Use these terms accurately: tool uptime, preventive maintenance, recipe, tool matching.
- Explain the workplace tension: Tool uptime, preventive maintenance status, recipe qualification, tool matching evidence, and bottleneck risk must be balanced.
- Respond professionally when a stakeholder says: Move all lots to the second tool immediately.
- Draft a usable tool-qualification escalation with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A high-demand tool is repeatedly down and a second tool is almost matched.

Move all lots to the second tool immediately.

Tool uptime, preventive maintenance status, recipe qualification, tool matching evidence, and bottleneck risk must be balanced.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a tool-qualification escalation.

Module 7. Packaging, Test, and Reliability Qualification (90 minutes)

Explain post-fab risk using test and reliability language.

Learners should be able to

- Use these terms accurately: package, binning, burn-in, qualification.
- Explain the workplace tension: Package interaction, binning criteria, burn-in results, qualification status, and customer-use conditions are not interchangeable.
- Respond professionally when a stakeholder says: Ship the units because electrical test passed.
- Draft a usable qualification readiness update with facts, caveats, owner, and next step.

Customized scenario

Workplace pressure

A product team wants to ship early units before reliability stress testing is complete.

Ship the units because electrical test passed.

Package interaction, binning criteria, burn-in results, qualification status, and customer-use conditions are not interchangeable.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a qualification readiness update.

Module 8. Foundry, Tape-Out, PDK, and Capacity Communication (90 minutes)

Handle customer and executive pressure around constrained foundry schedules.

Learners should be able to

- Use these terms accurately: foundry, tape-out, PDK, capacity allocation.
- Explain the workplace tension: Foundry allocation, PDK readiness, mask schedule, change freeze, and capacity allocation need documented assumptions.
- Respond professionally when a stakeholder says: Promise the date to protect the relationship.
- Draft a usable foundry customer update with facts, caveats, owner, and next step.

Customized scenario**Workplace pressure**

A customer asks for a guaranteed tape-out and wafer-start date despite capacity constraints.

Promise the date to protect the relationship.

Foundry allocation, PDK readiness, mask schedule, change freeze, and capacity allocation need documented assumptions.

Classroom sequence

1. Terminology drill: define each term, then use it in one sentence from the learner's own role.
2. Risk map: identify the stakeholder, the decision, the evidence gap, the operating constraint, and the cost of being wrong.
3. Pushback ladder: move from clarifying question to evidence-based objection to consequence to decision request.
4. Output lab: draft and revise a foundry customer update.

Nomenclature and Jargon

These are classroom working definitions. Learners should adapt wording to their organization's policies, systems, and local regulatory environment.

Wafer Fabrication Flow and Process Integration

Term	Working meaning
wafer	Thin semiconductor substrate, usually silicon, on which integrated circuits are fabricated.
fab	Semiconductor fabrication facility where wafers are processed through manufacturing steps.
process flow	Ordered sequence of semiconductor manufacturing steps, layers, inspections, holds, and decision points.
node	Technology generation or process family, often associated with feature size, performance, density, and design rules.

Lithography, Reticles, and Critical Dimensions

Term	Working meaning
lithography	Patterning process that transfers circuit features to a wafer using light, masks, and photoresist.
photoresist	Light-sensitive material used in lithography to define patterns on a wafer.
reticle	Photomask used in lithography to project circuit patterns onto a wafer.
critical dimension	A measured feature size on a wafer that must stay within specification for device performance and yield.

Deposition, Etch, CMP, and Process Windows

Term	Working meaning
deposition	Process of adding material layers to a wafer by physical, chemical, epitaxial, or atomic-layer methods.
etch	Process that removes selected material from a wafer using wet chemistry or plasma-based methods.
CMP	Chemical mechanical planarization; a process that smooths wafer surfaces for later manufacturing steps.
process window	Range of process conditions under which results meet specification with acceptable margin.

Metrology, SPC, and Yield Learning

Term	Working meaning
metrology	Measurement discipline used to verify process, dimension, film, defect, and device characteristics.
SPC	Statistical process control; use of control charts and limits to monitor process stability.
yield	Share of wafers, die, units, or lots that meet requirements after manufacturing, test, or qualification.
excursion	Manufacturing event or trend outside expected control limits, specifications, or normal process behavior.

Defect Density and Cleanroom Contamination

Term	Working meaning
defect density	Number or rate of defects on a wafer, die, layer, lot, or process area.
particle	Small contaminant that can create defects, yield loss, reliability risk, or process instability.
cleanroom	Controlled manufacturing environment designed to limit particles, humidity, electrostatic risk, and contamination.
contamination control	Practices used to prevent particles, residues, metals, organics, moisture, or handling errors from affecting wafers or devices.

Equipment Uptime, Recipes, and Tool Matching

Term	Working meaning
tool uptime	Percentage of time equipment is available and qualified for production use.
preventive maintenance	Planned equipment service performed to reduce unplanned downtime, drift, contamination, safety risk, or tool instability.
recipe	Controlled equipment parameters used to run a process step on a wafer, lot, or tool.
tool matching	Effort to make similar manufacturing tools produce equivalent results within defined limits.

Packaging, Test, and Reliability Qualification

Term	Working meaning
package	Protective and electrical interface that connects a semiconductor die to a board or system.
binning	Sorting tested semiconductor units into performance, power, speed, or quality categories.
burn-in	Stress testing used to screen for early-life failures before product release or shipment.
qualification	Evidence-based approval that a process, product, tool, package, supplier, or change meets defined requirements.

Foundry, Tape-Out, PDK, and Capacity Communication

Term	Working meaning
foundry	Semiconductor manufacturer that fabricates chips for external customers or design companies.
tape-out	Final release of a chip design to the foundry for mask generation and fabrication.
PDK	Process design kit; foundry-provided design rules, models, and files used to design chips for a process.
capacity allocation	Decision process for assigning limited foundry, tool, test, or assembly capacity across products or customers.

Industry-Specific Meeting Moves

Situation	Useful language
Wafer Fabrication Flow and Process Integration	Before we commit, I want to confirm wafer, fab, the owner, and the evidence behind the decision. If process flow, route control, layer dependency, and integration risk must be confirmed before movement., I recommend we document the risk and agree on the next step.
Lithography, Reticles, and Critical Dimensions	Before we commit, I want to confirm lithography, photoresist, the owner, and the evidence behind the decision. If reticle status, photoresist behavior, exposure conditions, metrology repeatability, and control limits need review., I recommend we document the risk and agree on the next step.
Deposition, Etch, CMP, and Process Windows	Before we commit, I want to confirm deposition, etch, the owner, and the evidence behind the decision. If deposition uniformity, etch selectivity, cmp margin, and the qualified process window must be protected., I recommend we document the risk and agree on the next step.
Metrology, SPC, and Yield Learning	Before we commit, I want to confirm metrology, SPC, the owner, and the evidence behind the decision. If spc trends, sampling change, tool history, defect signatures, and product mix must be separated., I recommend we document the risk and agree on the next step.
Defect Density and Cleanroom Contamination	Before we commit, I want to confirm defect density, particle, the owner, and the evidence behind the decision. If defect density, cleanroom protocol, contamination source, containment, and affected-lot traceability require action., I recommend we document the risk and agree on the next step.

Situation	Useful language
Equipment Uptime, Recipes, and Tool Matching	Before we commit, I want to confirm tool uptime, preventive maintenance, the owner, and the evidence behind the decision. If tool uptime, preventive maintenance status, recipe qualification, tool matching evidence, and bottleneck risk must be balanced., I recommend we document the risk and agree on the next step.
Packaging, Test, and Reliability Qualification	Before we commit, I want to confirm package, binning, the owner, and the evidence behind the decision. If package interaction, binning criteria, burn-in results, qualification status, and customer-use conditions are not interchangeable., I recommend we document the risk and agree on the next step.
Foundry, Tape-Out, PDK, and Capacity Communication	Before we commit, I want to confirm foundry, tape-out, the owner, and the evidence behind the decision. If foundry allocation, pdk readiness, mask schedule, change freeze, and capacity allocation need documented assumptions., I recommend we document the risk and agree on the next step.

High-pressure pushback frames

- I understand the urgency. The risk is that we move faster than the evidence or process supports.
- I am not blocking the goal. I am naming the condition we need before the decision is safe and credible.
- If we accept this risk, we should name the owner, document the assumption, and define the trigger for escalation.
- That may be possible, but not under the current scope, timeline, or approval path.
- Let's separate what we know, what we assume, and what still needs confirmation.

Practical Collocations and Field Moves

These phrases are intentionally practical. Learners should rehearse them as complete workplace moves: what they mean, when to use them, what evidence they require, and what decision they support.

Collocation set 1

Collocation	How it works in the field
put a lot on hold	Stop a wafer lot from moving until the hold reason, owner, risk, and release condition are clear.
release a lot	Allow a held lot to continue only after route, disposition, and risk acceptance have been documented.
open an excursion	Start a formal investigation when SPC, defect, yield, or tool behavior moves outside expected limits.
contain affected lots	Identify, quarantine, or restrict lots that may share the same exposure, tool path, material, or time window.
verify lot genealogy	Trace where a lot has been, which tools touched it, and which lots share possible exposure.
quarantine suspect material	Physically or systemically prevent wafers, chemicals, parts, or finished units from being used or shipped.
review SPC charts	Look at control charts, rules, limits, and trends before deciding whether a signal is real.
separate signal from noise	Avoid reacting to a single data point until sampling, repeatability, and tool history are checked.
tighten the process window	Reduce allowed process variation when yield, reliability, or margin is at risk.
run split lots	Process comparable lots or wafers under different conditions to isolate a variable or compare paths.

Collocation set 2

Collocation	How it works in the field
qualify a recipe	Generate evidence that a controlled tool recipe meets process, quality, and reliability requirements.

Collocation	How it works in the field
match a tool	Show that two tools produce equivalent results within approved limits for a given process step.
move lots to the matched tool	Transfer work to an alternate tool only within the approved matching, recipe, and product constraints.
pull in preventive maintenance	Move planned maintenance earlier to reduce drift, contamination, safety, or downtime risk.
recover tool uptime	Restore qualified equipment availability without bypassing restart, monitor, or qualification requirements.
check chamber history	Review recent maintenance, cleans, alarms, consumables, recipes, and abnormal events for a process chamber.
confirm metrology repeatability	Repeat or cross-check measurements before treating a trend as a process problem.
hold shipment	Prevent finished units from leaving until quality, reliability, customer, or compliance questions are resolved.
screen for early-life failure	Use burn-in, stress, or test screening to identify infant mortality risk before release.
bin devices by speed and power	Sort parts into usable categories after test, often tied to customer specifications or price.

Collocation set 3

Collocation	How it works in the field
perform failure analysis	Investigate failed die, packages, or returned units to identify physical, electrical, process, or use-related causes.
close the 8D	Complete the structured customer problem-solving report with verified root cause and effective corrective action.
freeze the mask set	Stop design changes so masks, reticles, wafer starts, and downstream schedules can proceed.
release the PDK	Publish foundry design rules, models, and files for a process after readiness checks are complete.
lock the tape-out package	Finalize the files, checks, signoffs, and assumptions needed for mask generation.
allocate wafer starts	Assign constrained foundry capacity or fab starts across products, customers, or priorities.
approve a deviation	Permit a controlled exception only after impact, owner, duration, and risk acceptance are documented.
issue a customer quality notice	Give customers a factual update about risk, containment, impact, and next action without speculation.

Additional Practical Dialogues

These dialogues are written for advanced role-play. Learners should practice the first version as written, then replace the technical facts with a similar problem from their own role.

1. Lot Hold vs Customer Expedite

Setting

A strategic customer is waiting for units, but a wafer lot is on hold after an inline monitor showed abnormal film thickness.

Speaker	Line
Customer program manager	Can we release the lot today? The customer is escalating and the ship date is already tight.

Speaker	Line
Process integration engineer	I understand the schedule pressure, but the hold code is tied to a film-thickness excursion after deposition.
Customer program manager	Is it a real excursion or just a metrology artifact?
Process integration engineer	That is exactly what we need to confirm. I want repeat metrology, chamber history, and lot genealogy before release.
Customer program manager	What is the fastest responsible option?
Process integration engineer	We can contain the affected lots, run a split on one lower-risk lot, and prepare a deviation request if quality agrees.
Customer program manager	So I should not promise shipment today.
Process integration engineer	Right. Say the lot is under controlled disposition, with an update after repeat measurement and quality review.

Coach notes

- The learner does not say no; the learner names hold code, excursion, metrology, genealogy, containment, and disposition.
- The response gives the commercial team usable customer language without pretending the risk is solved.

Target collocations

- put a lot on hold
- confirm metrology repeatability
- verify lot genealogy
- approve a deviation

2. Critical Dimension Drift on a Customer Call

Setting

A customer quality lead challenges whether a CD trend is real before a corrective action report is due.

Speaker	Line
Customer quality lead	Your report shows CD drift, but we think the trend could be measurement noise.
Lithography engineer	That is a fair question. We are checking metrology repeatability before we call it a process shift.
Customer quality lead	What are you comparing?
Lithography engineer	The same layer across the last three lots, the reference wafer, reticle history, exposure dose, focus data, and CD-SEM repeat runs.
Customer quality lead	Can you state whether product performance is affected?
Lithography engineer	Not yet. We can say the drift is within electrical guardband so far, but we are not closing the excursion until SPC and yield correlation are complete.
Customer quality lead	When will we have a decision?
Lithography engineer	By 5 p.m. tomorrow, we will provide either a release recommendation or a containment plan with affected-lot IDs.

Coach notes

- The learner distinguishes measurement repeatability, process shift, electrical impact, and customer disposition.
- The dialogue trains a precise but cautious answer: what is known, what is being checked, and when the decision comes.

Target collocations

- review SPC charts
- confirm metrology repeatability
- separate signal from noise
- contain affected lots

3. Particle Excursion After Maintenance**Setting**

Production wants to restart a tool after maintenance, but defect maps show a new particle signature.

Speaker	Line
Production planner	The tool is back up. Can we load the backlog now?
Manufacturing quality engineer	Not until we close the restart checks. The monitor wafer shows a particle signature that was not present before maintenance.
Production planner	If we wait, the area will miss the shift target.
Manufacturing quality engineer	I understand. The tradeoff is that restarting too early could contaminate multiple high-value lots.
Production planner	What do you need before release?
Manufacturing quality engineer	A clean monitor run, chamber history, maintenance notes, and a lot list for any material exposed during the suspect window.
Production planner	Can we at least run engineering material?
Manufacturing quality engineer	Possibly, if the module owner approves the route and quality agrees that the risk is contained.

Coach notes

- The learner uses contamination-control language without blaming the maintenance team.
- The practical move is to define the restart condition, not simply defend quality in general terms.

Target collocations

- quarantine suspect material
- check chamber history
- contain affected lots
- recover tool uptime

4. Tool Matching Under Capacity Pressure**Setting**

A bottleneck tool is down, and operations wants to move production to an alternate tool that is almost matched.

Speaker	Line
Operations director	We need to move all lots to Tool B. The matched-tool report looked close enough.
Module process owner	Tool B is close for monitor wafers, but product-lot data are still limited for this layer.
Operations director	How much risk are we really talking about?
Module process owner	The main risks are uniformity, selectivity, and downstream CMP margin. If those shift, yield loss may appear several steps later.
Operations director	What is your recommendation?
Module process owner	Move low-risk lots first, run enhanced metrology, and keep critical customer lots on hold until the first product split clears.
Operations director	Give me language for the morning standup.
Module process owner	Say Tool B is under controlled qualification, not fully released for unrestricted product movement.

Coach notes

- The learner explains why almost matched is not the same as unrestricted production release.
- The line 'under controlled qualification' gives leaders a concise phrase for operations updates.

Target collocations

- match a tool
- move lots to the matched tool
- run split lots
- qualify a recipe

5. Reliability Qualification vs Early Shipment

Setting

A business unit wants to ship early units after electrical test, before reliability stress is complete.

Speaker	Line
Business unit manager	Electrical test passed. Can we ship early samples while reliability finishes?
Product engineer	We can discuss sample release, but electrical pass is not the same as reliability qualification.
Business unit manager	The customer only needs a few units for bring-up.
Product engineer	Then we should label them clearly as engineering samples, define use limits, and avoid treating them as qualified product.
Business unit manager	What is the unresolved risk?
Product engineer	Package interaction, burn-in results, early-life failure rate, and bin stability are still open.
Business unit manager	What can I tell sales?
Product engineer	Tell them sample release may be possible with restrictions, but production shipment waits for qualification review.

Coach notes

- The learner separates sample release, production shipment, electrical test, and reliability qualification.
- This is useful for sales and business conversations where 'passed test' is often overextended.

Target collocations

- screen for early-life failure
- bin devices by speed and power
- hold shipment
- perform failure analysis

6. Foundry Capacity and Tape-Out Commitment

Setting

A customer asks for a guaranteed tape-out and wafer-start date while PDK updates and foundry capacity are still moving.

Speaker	Line
Customer program manager	We need a firm wafer-start date before our executive review. Can you guarantee the slot?
Foundry coordinator	I can confirm the current allocation request, but I cannot guarantee the slot until the tape-out package and change freeze are complete.
Customer program manager	What is blocking the commitment?
Foundry coordinator	PDK version signoff, mask data checks, final DRC closure, and capacity allocation approval.
Customer program manager	That sounds like too many caveats.
Foundry coordinator	The caveats are the conditions for a reliable commitment. If any of them move, the wafer-start date can move with them.
Customer program manager	What should our executive slide say?
Foundry coordinator	Say the target slot is requested, with commitment pending PDK signoff, mask package lock, and foundry allocation confirmation.

Coach notes

- The learner protects the relationship by giving a usable target while refusing a false guarantee.
- The dialogue models conditional commitment language common in foundry and customer-program work.

Target collocations

- freeze the mask set
- release the PDK
- lock the tape-out package
- allocate wafer starts

Specialized Nomenclature Expansion

Use this expansion set for learners who already know the general module terms and need the more specific nouns, acronyms, and measurement language that appear in fab, test, packaging, reliability, and customer-quality conversations.

Fab logistics

Term	Working meaning
FOUP	Front opening unified pod used to transport and protect wafers in automated fab environments.
lot traveler	Record or system route showing where the lot goes, what has been done, and what instructions apply.
hold code	System code that explains why material is blocked from movement or shipment.
WIP	Work in process; material currently moving through manufacturing, test, assembly, or disposition.
queue time	Time a lot waits between process steps; excessive queue time can affect quality or cycle time.
lot genealogy	Traceable history of tools, materials, routes, rework, holds, and related lots.

Process control

Term	Working meaning
control wafer	Wafer used to monitor process or tool behavior without risking production material.
split lot	Lot divided or compared across conditions to test a process variable or disposition path.
golden tool	Reference tool whose performance is treated as the comparison point for matching.
chamber matching	Effort to align performance across chambers in the same or similar equipment.
inline monitor	Measurement taken during manufacturing to catch drift before final test or yield loss.
PCM	Process control monitor structures or measurements used to evaluate process health.

Lithography

Term	Working meaning
overlay	Alignment accuracy between patterned layers on the wafer.
dose	Exposure energy applied during lithography.
focus	Exposure focus condition that affects printed feature quality.
OPC	Optical proximity correction used to adjust mask patterns for printing behavior.
CD-SEM	Critical-dimension scanning electron microscope used to measure small patterned features.
scatterometry	Optical metrology method used to infer feature profiles, dimensions, or film characteristics.

Films and etch

Term	Working meaning
film thickness	Measured thickness of a deposited or grown layer.
sheet resistance	Electrical resistance measurement used to monitor thin films or implants.
selectivity	How much faster one material is removed than another during etch or CMP.
uniformity	Degree to which a process result is consistent across wafer, lot, tool, or chamber.
end-point detection	Method for determining when an etch or process step has reached the target condition.
slurry	Abrasive chemical mixture used in CMP.
post-CMP clean	Cleaning step used to remove residue, particles, or contamination after CMP.

Test and sort

Term	Working meaning
wafer sort	Electrical testing of die while still on the wafer.
die sort	Classification of die after wafer-level testing.
probe card	Test interface that contacts wafer pads during wafer sort.
parametric test	Electrical measurement of device or process parameters, often used to monitor margins.
guardband	Extra margin used to reduce risk when specification, process, or use conditions vary.

Reliability

Term	Working meaning
infant mortality	Early-life failures that appear soon after device use or stress.
FIT rate	Failures in time; reliability measure often expressed as failures per billion device hours.
electromigration	Reliability failure mechanism caused by metal movement under current stress.
TDDDB	Time-dependent dielectric breakdown; reliability mechanism affecting insulating layers.
HCI	Hot carrier injection; reliability mechanism that can degrade transistor performance.
NBTI	Negative-bias temperature instability; reliability mechanism affecting transistor threshold behavior.

Packaging

Term	Working meaning
wire bond	Electrical connection made by bonding fine wires between die and package leads or substrate.
flip chip	Package approach where die are connected face-down through bumps.
underfill	Material placed under flip-chip die to improve mechanical reliability.
bump	Conductive connection point used in advanced packages or wafer-level packaging.
TSV	Through-silicon via used to connect vertically through silicon in advanced packages.
substrate	Package platform that supports the die and routes signals to the board.

Quality and customer

Term	Working meaning
MRB	Material review board that decides disposition for nonconforming or suspect material.
deviation	Approved exception from a normal requirement, route, specification, or process condition.
rework	Additional approved processing intended to bring material back into requirement.
scrap	Disposition for material that cannot be used or recovered acceptably.
FA	Failure analysis; structured investigation of why a device, die, package, or system failed.
decapsulation	Removal of package material to inspect die, bonds, or physical evidence during FA.

Assessment and Coaching

Performance rubric

Skill	Developing	Proficient	Strong
Terminology	Recognizes terms but uses them loosely.	Uses field terms accurately in context.	Defines terms, connects them to evidence, and explains decision impact.
Pushback	Disagrees vaguely or avoids disagreement.	Names concern with evidence and next step.	Balances urgency, relationship, risk, owner, and decision rights.
Scenario judgment	Focuses on one stakeholder's preference.	Identifies constraint, risk, and process.	Guides the group toward a documented, realistic decision.
Written output	Writes general summaries.	Produces clear notes with facts and owner.	Creates concise, decision-ready workplace communication.

Source orientation

- Company process-control plans, fab SOPs, and manufacturing quality procedures.
- SEMI, JEDEC, AEC-Q, and customer qualification expectations where applicable.
- Foundry documentation, PDK release notes, customer quality agreements, and approved communication procedures.
- The learner's own company policies, SOPs, contracts, systems, templates, and approved communication standards.