When the pot is below the 300 threshold, auto/PS5 mode is on, SEL id high and Dx = SxA. Above 300, Dx=SxB and manual vehicle signals are routed

Board 2 channel 1 test

Pot position	mode	SEL reading	S1A reading(manual)	S1B reading	D1
0	PS5	3.3	0.95mV	2	2
1060	Manual	0.08mV	0.97	2	0.98
2000	Manual	0.05mV	1.74	2	1.75
4095	manual	0	3.3	2	3.3

Board 2 channel 2 test

Pot position	mode	SEL reading	S2A reading(manual)	S2B reading	D2
0	PS5	3.3	0.49mV	2	2
1060	Man	0.09mV	0.98	2	0.979
2000	Man	0.06mV	1.74	2	1.735
4095	man	0	3.3	2	3.3

Channel 3

Pot position	mode	SEL reading	S3A reading(manual)	S3B reading	D3
0	PS5	3.3	0.53mV	2	2
1060	Man	0.10mV	0.975	2	0.978V
2000	Man	0.06mV	1.73	2	1.75V
4095	man	0	3.3	2	3.3

Board 2 channel 4 test

Pot position	mode	SEL reading	S4A reading(manual)	S4B reading	D4
0	PS5	3.28	0.49mV	2	2
1060	Man	0.1mV	0.98	2	0.98
2000	Man	0.06mV	1.73	2	1.73
4095	man	0	3.3	2	3.3

Board 3 channel 1

Pot position	mode	SEL reading	S1A reading(manual)	S1B reading	D1

0	PS5	3.3	0.54mV	1.31	1~3mV
1060	Man	0.09mV	0.983	1.31	1~3mV
2000	Man	0.06mV	1.74	1.31	1~3mV
4095	man	0	3.3	1.31	1~3mV

Channel 2

Pot position	mode	SEL reading	S2A reading(manual)	S2B reading	D2
0	PS5	3.3	0.51mV	1.3	1.31
1060	Man	0.1mV	0.974	1.3	0.973
2000	Man	0.08mV	1.75	1.3	1.75
4095	man	0	3.3	1.3	3.3

Channel 3

Pot position	mode	SEL reading	S3A reading(manual)	S3B reading	D3
0	PS5	3.3	0.53m	1.3	1.3
1060	Man	0.11m	0.978V	1.3	0.975
2000	Man	0.08m	1.73	1.3	1.76
4095	man	0	3.3	1.3	3.3

Channel 4

Pot position	mode	SEL reading	S4A reading(manual)	S4B reading	D4
0	PS5	3.3V	0.5mV	1.3	1.3
1060	Man	0.11m	0.982	1.3	0.955
2000	Man	0.09m	1.74	1.3	1.74
4095	man	0	3.3	1.3	3.3