Command: SET-ATTR-LAN

Message category: Network Maintenance

Application: Add/Drop, Rings

Definition:

Set local area network (LAN) alarm attributes.

Restrictions:

All parameters in this command are position-defined.

Function:

To set the attributes of alarm indicators for the LAN.

Command Format:

SET-ATTR-LAN:[tid]:aidlan:[ctag]::[ntfcncde],[condlan],,,:,[act],[deact];

Command Parameters			
PARAMETER	EXPLANATION		
[tid]	Identification of the target NE (120		
	characters). The NE SID code is the		
	recommended value. The default value is null.		
aidlan	Access identification code that identifies a LAN.		
	The value can be preceded by AID=, but this is		
	not required. Valid values are:		
	LANA Associated with NEPA LANB Reserved		
	for future use		
[ctag]	Correlation tag (16 characters) that links an		
	input command with associated output		
	responses. The default is 0.		
[ntfcncde]	Notification code associated with an alarm		
	condition. Valid values are:		
	CR Critical alarm MJ Major alarm MN Minor		
	alarm NA Not alarmed; reported via report		
	event NR Not reported when event occurs;		
	information retained in NE		
[condlan]	Condition type of the LAN. The value can be		
(see NOTE)	preceded by CONDTYPE=, but this is not		
	required. Grouping is allowed. Valid values are:		
	CARLOS Loss of carrier. Generated when a		
	carrier-lost indication is sensed by the LAN		

	controller during frame transmission. When this
	loss is reported, an alarm is immediately
	deployed and not cleared until either a good
	frame is received or a good transmission
	occurs. DUPADR Duplicate address error.
	Generated at LAN initialization if a duplicate
	address check fails. (This check verifies that
	the address being used does not exist on the
	network.) The alarm is cleared during a system
	cold or warm restart.
	The condition types are listed in Table <u>E</u> with
	Alcatel factory default attributes.
[act]	Activation time, in half seconds (020), for
	declaring an alarm condition. Default can be
	specified with the CUSTDFLT AID.
[deact]	Deactivation time, in seconds (020), for
	declaring an alarm condition cleared. Default
	can be specified with the CUSTDFLT AID.
NOTE: A null entry defaults	to all values for this parameter.

Table E. LAN Alarm Conditions and Alcatel Factory Default Attributes

ALARM	DESCRIPTION	DEFAULTS		
CONDITION		NTFCTNCDE	ACT TIME	DEACT TIME
LAN:				
CARLOS	Loss of carrier	MN	5	10
DUPADR	Duplicate address	MN	5	10
	error			

Response Format:

Acknowledgment:

If, in less than 2 seconds, a normal or error response cannot be sent, the following acknowledgment response is sent:

```
IP <ctag>
```

After the above response, a new command input may be generated.

Normal Response:

```
sid yy-mm-dd hh:mm:ss

M c COMPLD
   /* SET-ATTR-LAN:[tid]:aidlan:[ctag]::[ntfcncde],[condlan],,,:, */
   /* [act],[deact] */
   /* optional free format text */
;
```

Error Response:

```
sid yy-mm-dd hh:mm:ss

M c DENY
   /* SET-ATTR-LAN:[tid]:aidlan:[ctag]::[ntfcncde],[condlan],,,:, */
   /* [act],[deact] */
   errcde
;
```

Response Parameters		
PARAMETER	EXPLANATION	
sid	Source NE identification	
yy-mm-dd	Year (2 digits), month, and day	
hh:mm:ss	Hour (0023), minute, and second	
М	Message generated in response to an input	
	command	
С	If provided, ctag, otherwise 0	
COMPLD	Completed	
DENY	Input command is denied	
/* */	Enclosed are human readable comments -	
	unspecified format	
errcde	Error code (see Appendix C)	

Example:

Sets the attributes of a duplicate address error alarm for LANA. This minor level alarm has an activation time of 5 seconds and a deactivation time of 15 seconds.

```
SET-ATTR-LAN:RAL:LANA:45::MN,DUPADR,,,:,5,15;
```

```
RAL 99-11-24 11:27:30
M 45 COMPLD
/* SET-ATTR-LAN:RAL:LANA:45::MN,DUPADR,,,:,5,15 */
```

Related Commands:

RTRV-ALM-LAN RTRV-ATTR-LAN RTRV-COND-LAN