Command: SET-PMMODE-STS1

Message category: System Maintenance

Application: Add/Drop, Rings

Definition:

Set performance monitoring modes of an STS1 path.

Restrictions:

All parameters in this command are position-defined. A DENY response is generated if the AID specifies a drop side STS1 whose parent equipment COMPAT value is not LIF901 or LIFB01, or if the specified instance is unassigned.

Function:

To set STS1 performance monitoring modes associated with a STS1 path that terminates on a LIF901 or LIFB01.

Command Format:

SET-PMMODE-STS1:[tid]:aidstsp_pmmode:[ctag]::[locn],[pmtypests],[pmstate],

[pmdaystart];

Command Parameters		
PARAMETER	EXPLANATION	
[tid]	Identification of the target NE (120 characters). The NE SID code is the recommended value. The default value is null.	
aidstsp_pmmode	Access identification code that identifies a DS1. The value can be preceded by AID=, but this is not required. Enter one of the following formats, replacing lowercase parameters with the values given: dgx-STS1-1 where: dgx = DG1, DG2, DG3 ALL AII LIF901 and LIFB01 equipped drop group cards CUSTDFLT Customer-defined defaults	
[ctag]	Correlation tag (16 characters) that links an input command with associated output responses. The default is 0.	
[locn]	Location where performance monitoring is	

	reported. Grouping is allowed. Valid values are:
	FEND Far end NEND Near end BOTH Both
	locations (default)
[pmtypests]	STS1 performance monitoring type. The value
	can be preceded by MONTYPE=, but this is not
	required. Valid values are:
	P Transport Path performance monitoring
	parameters
[pmstate]	Whether the specified PM type was directed to
	turn ON (Alcatel factory default) or OFF
[pmdaystart]	Hour (023) to start accumulating daily PM
	counts. Alcatel factory default is 0 (midnight).
	The defaults can be specified with the
	CUSTDFLT AID.

Response Format:

Acknowledgment:

If, in less than 2 seconds, a normal or error response cannot be sent, the following acknowledgment response is sent:

```
IP <ctag>
```

After the above response, a new command input may be generated.

Normal Response:

```
sid yy-mm-dd hh:mm:ss

M c COMPLD
   /* SET-PMMODE-STS1:[tid]:aidstsp_pmmode:[ctag]::[locn] */
:
```

Error Response:

```
sid yy-mm-dd hh:mm:ss

M c DENY
   /* SET-PMMODE-STS1:[tid]:aidstsp_pmmode:[ctag]::[locn] */
   errcde
:
```

Response Parameters	
PARAMETER	EXPLANATION
sid	Source NE identification
yy-mm-dd	Year (2 digits), month, and day
hh:mm:ss	Hour (0023), minute, and second
M	Message generated in response to an input

	command
С	If provided, ctag, otherwise 0
COMPLD	Completed
DENY	Input command is denied
/* */	Enclosed are human readable comments - unspecified format
errcde	Error code (see Appendix <u>C</u>)

Example:

Set the performance monitoring mode for STS1 in drop group 1 at the near end for PM path monitoring to be turned on at 8:00 p.m.

SET-PMMODE-STS1:RALGH:DG1-STS1-1:90::NEND,P,ON,20;

```
RALGH 99-11-24 12:50:30
M 90 COMPLD
    /* SET-PMMODE-STS1:RALGH:DG1-STS1-1:90::NEND,P,ON,20 */;
```

Related Commands:

RTRV-PMMODE-STS1