NTP-003

CAB101 Coax Patch Panel and Heat Baffle Assembly Installation

This NTP lists the charts used for the physical installation of Alcatel's CAB101 Coax Patch Panel and Heat Baffle assembly.

Installation procedures are detailed in charts using a step-by-step format.

Procedure

- 1. Unpacking and Inspection Chart 1
- Installing CAB101 in a Frame Chart <u>5</u>
- Installing DS3 or STS1 Cable Assemblies CAB101 Chart 6