### **Command: ED-STS3C**

Message category: Memory Administration

Application: Add/Drop, Rings

#### **Definition:**

Edit STS3C.

#### **Restrictions:**

All parameters in this command are position-defined except the *sts\_nblk* parameters, which are name-defined.

### **Function:**

To edit the provisioning data associated with an assigned STS3C path.

#### **Command Format:**

ED-STS3C:[tid]:aidstsp:[ctag]::[sts3cptype],[frc\_alcldflt]:[sts\_nblk]:[pst][,];

Command Parameters	
PARAMETER	EXPLANATION
[tid]	Identification of the target NE (120
	characters). The NE SID code is the
	recommended value. The default value is null.
aidstsp	Access identification code that identifies a
	STS3C path. The value can be preceded by
	AID=, but this is not required. Grouping is
	allowed. Enter one of the following formats,
	replacing lowercase parameters with the values
	given:
	lgx-STS3C-r Line group STS3C path
	where:
	lgx = LG1, LG2
	r = 1, 4, 7, 10
	dgx-STS3C-1 Drop group STS3C path where:
	dgx = DG1, DG2, DG3 CUSTDFLT
	Customer-defined defaults
[ctag]	Correlation tag (16 characters) that links an
	input command with associated output
	responses. The default is 0.

[sts3cptype]	STS3C payload type. Valid values are:
	STS3C STS3C payload ATM ATM payload
[frc_alcldflt]	Reset Customer-defined defaults to Alcatel
	factory defaults. Valid for AID of CUSTDFLT
	only. Valid values are:
	Y Reset N Don't reset
	If FRC_ALCLDFT is not specified in the
	ED-STS3C command, it is assumed to have a
[sts_nblk]	value of N.
	Named parameter block for STS3C. The block
	consists of the following parameters in any order, separated by commas. Each parameter
	name is followed by an equal sign and a valid
	value.
	ALWPMREPT =
	Whether Performance Monitoring Reports are
	allowed by customer-defined default. Valid for
	AID of CUSTDFLT only. Valid values are: Y
	Enabled N Disabled
	AUTORINGAIS=
	Auto transmit AIS on STS BERP-HT (line group
	only). Valid values are: Y Enabled (initial
	database value) N Disabled
	EXPTRC= Expected path trace string. 0 to 62
	characters.
	IPM = Whether intermediate performance
	monitoring is enabled for non-terminated
	STS3C paths. When enabled, the following PM
	types are monitored, in addition to pointer
	justification count: CVP, ESP, SESP, UASP and
F-4	FCP. Valid values are: Y Enabled N Disabled
[sts_nblk]	PDI_SWITCH= Payload defect indication
(cont)	switching enabled (line group only). Valid values are: Y Enabled N Disabled
	ERDI= Whether Enhanced Remote Defect
	Indicator is generated or detected. Valid values
	are: Y Generate/detect N Don't generate/detect
	(default)
	<b>NOTE:</b> ERDI is available for the following units:
	HIF603, HIFB01, HIFG01, LIF404.
	SIGLBLMON= Signal label value (119) for
	monitoring. A value of 1 indicates a nonspecific
	payload.
	SSRXMODE= STS SPE pointer receive
	overwrite mode. Valid values are: THROUGH
	No translation (default) SONET Translates a
	received STM1 payload to STS3c payload SDH

	Translates a received STS3c payload to STM1
	payload
[pst]	Desired primary state (condition) of the object entity. A null value indicates no change in value after command is executed. A customer-defined default cannot be specified. Valid values are:  IS In-Service (normal -NR, or abnormal -ANR is implied and determined by the NE) OOS Out-Of-Service (out-of-service due to provisioning memory-administration operations
	is implied) MA Memory Administration (OOS-MA is implied)

# **Response Format:**

### **Acknowledgment:**

If, in less than 2 seconds, a normal or error response cannot be sent, the following acknowledgment response is sent:

```
IP <ctag>
```

After the above response, a new command input may be generated.

#### **Normal Response:**

```
sid yy-mm-dd hh:mm:ss

M c COMPLD
   /* ED-STS3C:[tid]:aidstsp:[ctag]:::[sts_nblk]:[pst][,] */
:
```

# **Error Response:**

```
sid yy-mm-dd hh:mm:ss

M c DENY
   /* ED-STS3C:[tid]:aidstsp:[ctag]:::[sts_nblk]:[pst][,] */
   errcde
;
```

Response Parameters		
PARAMETER	EXPLANATION	
sid	Source NE identification	
yy-mm-dd	Year (2 digits), month, and day	
hh:mm:ss	Hour (0023), minute, and second	
M	Message generated in response to an input	
	command	

С	If provided, ctag, otherwise 0
COMPLD	Completed
DENY	Input command is denied
	Enclosed are human readable comments - unspecified format
errcde	Error code (See Appendix <u>C</u> )

# **Example:**

Edit STS3C line group 1, path 1 to enable Intermediate Performance Monitoring and place the path out-of-service for memory administration (OOS-MA).

```
ED-STS3C:RALGH:LG1-STS3C-1:11:::IPM=Y:OOS;
```

```
RALGH 99-11-02 12:57:23
M 11 COMPLD
    /* ED-STS3C:RALGH:LG1-STS3C-1:11:::IPM=Y:OOS */;
```

#### **Related Commands:**

DLT-STS3C ENT-STS3C RTRV-STS3C