

Register map

Created with [Corsair](#) v1.0.4.

Conventions

Access mode	Description
rw	Read and Write
rw1c	Read and Write 1 to Clear
rw1s	Read and Write 1 to Set
ro	Read Only
roc	Read Only to Clear
roll	Read Only / Latch Low
rolh	Read Only / Latch High
wo	Write only
wosc	Write Only / Self Clear

Register map summary

Base address: 0x00000000


Name	Address	Description
UFLASH_KEY1	0x00000000	Unlock key for User Flash region
UFLASH_KEY2	0x00000004	Unlock key for Text Flash region
UFLASH_KEY3	0x00000008	Unlock key for Boot Flash region
UFLASH_CR	0x0000000c	Flash Control Register
UFLASH_SR	0x00000010	Flash Status Register
UFLASH_XADR	0x00000014	Flash X Address Register
UFLASH_YADR	0x00000018	Flash Y Address Register
UFLASH_DOR	0x0000001c	Flash data out Register
UFLASH_DIR	0x00000020	Flash data in Register

UFLASH_KEY1

Unlock key for User Flash region

Address offset: 0x00000000

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
KEY	31:0	wo	0x00000000	32-bit unlock key value(0x57494E44 - WIND)


[Back to Register map.](#)

UFLASH_KEY2

Unlock key for Text Flash region

Address offset: 0x00000004

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
KEY	31:0	wo	0x00000000	32-bit unlock key value


[Back to Register map.](#)

UFLASH_KEY3

Unlock key for Boot Flash region

Address offset: 0x00000008

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
KEY	31:0	wo	0x00000000	32-bit unlock key value


[Back to Register map.](#)

UFLASH_CR

Flash Control Register

Address offset: 0x0000000c

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
-	31:8	-	0x000000	Reserved
MODE	7:6	rw	0x0	Flash operation mode
ERASE_EN	5	rw	0x0	Erase enable
READ_EN	4	rw	0x0	Read enable
PROG_EN	3	rw	0x0	Program enable
BOOT_EN	2	rw	0x0	Enable access to Boot region
TEXT_EN	1	rw	0x0	Enable access to Text region
USER_EN	0	rw	0x0	Enable access to User region

Enumerated values for UFLASH_CR.MODE.

Name	Value	Description
READ	0x0	Read mode
PROGRAM	0x1	Program mode
ERASE	0x2	Erase mode
IDLE	0x3	Idle mode


[Back to Register map.](#)

UFLASH_SR

Flash Status Register

Address offset: 0x00000010

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
------	------	------	-------	-------------

Name	Bits	Mode	Reset	Description
-	31:7	-	0x000000	Reserved
ERASE_DONE	6	ro	0x0	Erase operation finished
PROG_DONE	5	ro	0x0	Program operation finished
RD_DONE	4	ro	0x0	Read operation finished
ERRA_OVF	3	ro	0x0	Error address overflow
ERRA_BOOT	2	ro	0x0	Error unauthorized access to Boot region
ERRA_TEXT	1	ro	0x0	Error unauthorized access to Text region
ERRA_USER	0	ro	0x0	Error unauthorized access to User region


[Back to Register map.](#)

UFLASH_XADR

Flash X Address Register

Address offset: 0x000000014

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
-	31:16	-	0x0000	Reserved
XADR	15:0	rw	0x0000	Flash X address (row / page select)


[Back to Register map.](#)

UFLASH_YADR

Flash Y Address Register

Address offset: 0x000000018

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
------	------	------	-------	-------------

Name	Bits	Mode	Reset	Description
-	31:8	-	0x0000000	Reserved
YADR	7:0	rw	0x00	Flash Y address (column / word select)


[Back to Register map.](#)

UFLASH_DOR

Flash data out Register

Address offset: 0x00000001c

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
DO	31:0	ro	0x00000000	32BIT READ DATA


[Back to Register map.](#)

UFLASH_DIR

Flash data in Register

Address offset: 0x000000020

Reset value: 0x00000000



Name	Bits	Mode	Reset	Description
DI	31:0	wo	0x00000000	32BIT PROGRAM DATA

[Back to Register map.](#)