

BASE LAYER - macOS

Physical keycaps and flashed firmware are aligned.



MEDIA + KNOB

PB plays or pauses media.

Turn the knob for system volume. Press the knob to mute.

NAVIGATION

Right column: Del, PgUp, PgDn, End.

Hold Fn: Left = Home and Right = End.

KEYCAP LEGENDS


WIN keycap = Command. ALT keycap = Option.

The single bottom-right Fn key opens Layer 2.

RGB sleeps after 20 minutes and wakes on input.

FN LAYER - hold Fn

Highlighted keys change function; pale keys keep their Base action.



● macOS / system
 ● media
 ● RGB
 ● navigation
 ● bootloader

SYSTEM + MEDIA

F1-F4: display, Mission Control, Spotlight.
 F7-F12: previous, play/pause, next, mute, volume down/up.
 Space: Emoji & Symbols. N: toggle NKRO.

RGB CONTROLS

Esc toggles RGB. F5/F6 or Q/W adjust brightness.
 A/S saturation. Z/X hue. PgUp/PgDn speed.
 Up/Down changes effect. Knob adjusts brightness.

NAVIGATION + FLASHING

Left = Home. Right = End.
 Fn + backslash enters the STM32 DFU bootloader. Use it only when flashing firmware.