## Modular Photoreactor Assembly Instructions

Assembly Instruction
Photoreactor Corpus
90x90x140mm

Daniel Kowalczyk

Institute of Chemical Engineering Ulm University

ORGANIZATION

## INSTRUCTIONS

- 1) LED Module assembly: slide the cooler with mounted LED into the 3D-printed holder. Fix the cooler with 4 M3 screws (length adjusted to the thickness of the cooler) and 4 M3 nuts as shown in the depiction of the setup.
- 2) Corpus assembly: place 6 M3 nuts in the slits of the side parts of the corpus. Fix the back part of the corpus with 4 M3 screws (length: 30 mm) according to the graphical assembly instruction. Fix the fan (120x120mm) to the back part of the corpus with 4 M3 screws (length: 70 mm) according to the graphical assembly instruction.