## **Assembly Instructions**

Institute of Chemical Mobile Cover Multi-Batch **INSTRUCTIONS** TITLE ORGANIZATION Screening Photoreactor Engineering Ulm University 1) Mount the fans (fan\_update.txt) at the back part of the cover using 4 M3 (25 mm) screws and corresponding nuts. 2) Use the 3D printed connector and 2 M3 (8 mm) screws and corresponding nuts tor connect all parts (top, sides, back and front part). Daniel Kowalczyk DESIGNER