## Modular Photoreactor Assembly Instructions

CIOI AS	ssembly instructi	UHS		
TITLE	assembly instruction LED Cooler	ORGANIZATION	Institute of Chemical Engineering Ulm University	INSTRUCTIONS
				<ol> <li>Cut 3 M3 threads (depht: 12 mm) along the LED mountir holes as depicted in the 3D figure</li> <li>Apply heatconducting paste to the surface of the cooler of</li> </ol>
				which the LED will be paced  3) Place the LED on the cooler and fix it with 3 M3 (length:
SIGNER	Daniel Kowlaczyk			mm)