FlyCapture2 C 2.4.3.10

Generated by Doxygen 1.7.5

Sat Feb 9 2013 05:06:35

Contents

1	Data	Structu	ıre Index		1
	1.1	Data S	tructures		1
2	File	Index			3
	2.1	File Lis	t		3
3	Data	Structu	ıre Docum	nentation	5
	3.1	fc2AVI	Option Stru	uct Reference	5
		3.1.1	Field Doo	eumentation	5
			3.1.1.1	frameRate	5
			3.1.1.2	reserved	5
	3.2	fc2Can	neraInfo St	ruct Reference	6
		3.2.1	Field Doo	cumentation	7
			3.2.1.1	applicationIPAddress	7
			3.2.1.2	applicationPort	7
			3.2.1.3	bayerTileFormat	7
			3.2.1.4	busNumber	7
			3.2.1.5	ccpStatus	7
			3.2.1.6	configROM	7
			3.2.1.7	defaultGateway	7
			3.2.1.8	driverName	7
			3.2.1.9	driverType	7
			3.2.1.10	firmwareBuildTime	7
			3.2.1.11	firmwareVersion	7
			3.2.1.12	gigEMajorVersion	7
			2 2 1 12	gigEMinor\/orgion	Ω

ii CONTENTS

		3.2.1.14	iidcVer	8
		3.2.1.15	interfaceType	8
		3.2.1.16	ipAddress	8
		3.2.1.17	isColorCamera	8
		3.2.1.18	macAddress	8
		3.2.1.19	maximumBusSpeed	8
		3.2.1.20	modelName	8
		3.2.1.21	nodeNumber	8
		3.2.1.22	pcieBusSpeed	8
		3.2.1.23	reserved	8
		3.2.1.24	sensorInfo	8
		3.2.1.25	sensorResolution	8
		3.2.1.26	serialNumber	8
		3.2.1.27	subnetMask	8
		3.2.1.28	userDefinedName	8
		3.2.1.29	vendorName	8
		3.2.1.30	xmlURL1	8
		3.2.1.31	xmlURL2	8
3.3	fc2Cor	nfig Struct I	Reference	8
	3.3.1	Field Doo	cumentation	9
		3.3.1.1	asyncBusSpeed	9
		3.3.1.2	bandwidthAllocation	9
		3.3.1.3	grabMode	9
		3.3.1.4	grabTimeout	9
		3.3.1.5	isochBusSpeed	9
		3.3.1.6	minNumImageNotifications	9
		3.3.1.7	numBuffers	9
		3.3.1.8	numImageNotifications	9
		3.3.1.9	registerTimeout	9
		3.3.1.10	registerTimeoutRetries	9
		3.3.1.11	reserved	9
3.4	fc2Cor	nfigROM S	truct Reference	9
	3.4.1	Field Doo	cumentation	0
		3.4.1.1	chipldHi	0

CONTENTS iii

		3.4.1.2	chipIdLo
		3.4.1.3	nodeVendorld
		3.4.1.4	pszKeyword
		3.4.1.5	reserved
		3.4.1.6	unitSpecId
		3.4.1.7	unitSubSWVer
		3.4.1.8	unitSWVer
		3.4.1.9	vendorUniqueInfo_0
		3.4.1.10	vendorUniqueInfo_1
		3.4.1.11	vendorUniqueInfo_2
		3.4.1.12	vendorUniqueInfo_3
3.5	fc2Eml	beddedIma	ageInfo Struct Reference
	3.5.1	Field Doo	cumentation
		3.5.1.1	brightness
		3.5.1.2	exposure
		3.5.1.3	frameCounter
		3.5.1.4	gain
		3.5.1.5	GPIOPinState
		3.5.1.6	ROIPosition
		3.5.1.7	shutter
		3.5.1.8	strobePattern
		3.5.1.9	timestamp
		3.5.1.10	whiteBalance
3.6	fc2Eml	beddedIma	ageInfoProperty Struct Reference
	3.6.1	Field Doo	cumentation
		3.6.1.1	available
		3.6.1.2	onOff
3.7	fc2For	mat7lmage	eSettings Struct Reference
	3.7.1	Field Doo	cumentation
		3.7.1.1	height
		3.7.1.2	mode
		3.7.1.3	offsetX
		3.7.1.4	offsetY
		3.7.1.5	pixelFormat

iv CONTENTS

		3.7.1.6	reserved	13
		3.7.1.7	$ \text{width} \ \dots $	13
3.8	fc2Forr	mat7Info S	truct Reference	13
	3.8.1	Field Doo	cumentation	14
		3.8.1.1	imageHStepSize	14
		3.8.1.2	imageVStepSize	14
		3.8.1.3	maxHeight	14
		3.8.1.4	maxPacketSize	14
		3.8.1.5	maxWidth	14
		3.8.1.6	minPacketSize	14
		3.8.1.7	mode	14
		3.8.1.8	offsetHStepSize	14
		3.8.1.9	offsetVStepSize	14
		3.8.1.10	packetSize	14
		3.8.1.11	percentage	14
		3.8.1.12	pixelFormatBitField	14
		3.8.1.13	reserved	14
		3.8.1.14	vendorPixelFormatBitField	14
3.9	fc2Forr	mat7Packe	stInfo Struct Reference	14
	3.9.1	Field Doo	sumentation	14
		3.9.1.1	maxBytesPerPacket	15
		3.9.1.2	recommendedBytesPerPacket	15
		3.9.1.3	reserved	15
		3.9.1.4	unitBytesPerPacket	15
3.10	fc2GigI	EConfig St	ruct Reference	15
	3.10.1	Field Doo	sumentation	15
		3.10.1.1	enablePacketResend	15
		3.10.1.2	maxPacketsToResend	15
		3.10.1.3	reserved	15
		3.10.1.4	timeoutForPacketResend	15
3.11	fc2GigI	ElmageSe	ttings Struct Reference	16
	3.11.1	Field Doo	cumentation	16
		3.11.1.1	height	16
		3.11.1.2	offsetX	16

CONTENTS

	3.11.1.3	offsetY	16
	3.11.1.4	pixelFormat	16
	3.11.1.5	reserved	16
	3.11.1.6	width	16
3.12 fc2GigI	ElmageSe	ttingsInfo Struct Reference	16
3.12.1	Field Doo	cumentation	17
	3.12.1.1	imageHStepSize	17
	3.12.1.2	imageVStepSize	17
	3.12.1.3	maxHeight	17
	3.12.1.4	maxWidth	17
	3.12.1.5	offsetHStepSize	17
	3.12.1.6	offsetVStepSize	17
	3.12.1.7	pixelFormatBitField	17
	3.12.1.8	reserved	17
	3.12.1.9	vendorPixelFormatBitField	17
3.13 fc2GigI	EProperty	Struct Reference	17
3.13.1	Field Doo	cumentation	17
	3.13.1.1	isReadable	17
	3.13.1.2	isWritable	17
	3.13.1.3	max	17
	3.13.1.4	$min \ldots \ldots \ldots \ldots \ldots$	17
	3.13.1.5	propType	18
	3.13.1.6	reserved	18
	3.13.1.7	value	18
3.14 fc2GigI	EStreamC	hannel Struct Reference	18
3.14.1	Field Doo	cumentation	18
	3.14.1.1	destinationlpAddress	18
	3.14.1.2	doNotFragment	19
	3.14.1.3	hostPost	19
	3.14.1.4	interPacketDelay	19
	3.14.1.5	networkInterfaceIndex	19
	3.14.1.6	packetSize	19
	3.14.1.7	reserved	19
	3.14.1.8	sourcePort	19

vi CONTENTS

3.15 fc2H26	64Option Struct Reference
3.15.1	Field Documentation
	3.15.1.1 bitrate
	3.15.1.2 frameRate
	3.15.1.3 height
	3.15.1.4 reserved
	3.15.1.5 width
3.16 fc2lma	ge Struct Reference
3.16.1	Field Documentation
	3.16.1.1 bayerFormat
	3.16.1.2 cols
	3.16.1.3 dataSize
	3.16.1.4 format
	3.16.1.5 imageImpl
	3.16.1.6 pData
	3.16.1.7 receivedDataSize
	3.16.1.8 rows
	3.16.1.9 stride
3.17 fc2lma	geMetadata Struct Reference
3.17.1	Field Documentation
	3.17.1.1 embeddedBrightness
	3.17.1.2 embeddedExposure
	3.17.1.3 embeddedFrameCounter
	3.17.1.4 embeddedGain
	3.17.1.5 embeddedGPIOPinState
	3.17.1.6 embeddedROIPosition
	3.17.1.7 embeddedShutter
	3.17.1.8 embeddedStrobePattern
	3.17.1.9 embeddedTimeStamp
	3.17.1.10 embeddedWhiteBalance
	3.17.1.11 reserved
3.18 fc2Inte	rnalContext Struct Reference
3.18.1	Field Documentation
	3.18.1.1 pBusMgr

CONTENTS vii

		3.18.1.2	pCamera	 22
3.19	fc2Inte	rnalGuiCo	ntext Struct Reference	 22
	3.19.1	Field Doo	cumentation	 22
		3.19.1.1	pCameraControlDlg	 22
		3.19.1.2	pCameraSelectionDlg	 22
3.20	fc2Inte	rnallmage(Callback Struct Reference	 23
	3.20.1	Field Doo	cumentation	 23
		3.20.1.1	pCallback	 23
		3.20.1.2	pCallbackData	 23
3.21	fc2IPA	ddress Str	uct Reference	 23
	3.21.1	Field Doo	cumentation	 23
		3.21.1.1	octets	 24
3.22	fc2JPE	GOption S	Struct Reference	 24
	3.22.1	Field Doo	cumentation	 24
		3.22.1.1	progressive	 24
		3.22.1.2	quality	 24
		3.22.1.3	reserved	 24
3.23	fc2JPG	2Option S	struct Reference	 24
	3.23.1	Field Doo	cumentation	 24
		3.23.1.1	quality	 24
		3.23.1.2	reserved	 24
3.24	fc2LUT	Data Struc	ct Reference	 25
	3.24.1	Field Doo	cumentation	 25
		3.24.1.1	enabled	 25
		3.24.1.2	inputBitDepth	 25
		3.24.1.3	numBanks	 25
		3.24.1.4	numChannels	 25
		3.24.1.5	numEntries	 25
		3.24.1.6	outputBitDepth	 25
		3.24.1.7	reserved	 25
		3.24.1.8	supported	 25
3.25	fc2MA0	CAddress	Struct Reference	 25
	3.25.1	Field Doo	cumentation	 25
		3.25.1.1	octets	 26

viii CONTENTS

3.26	fc2MJF	GOption S	Struct Reference	 26
	3.26.1	Field Doo	cumentation	 26
		3.26.1.1	frameRate	 26
		3.26.1.2	quality	 26
		3.26.1.3	reserved	 26
3.27	fc2PGN	MOption St	truct Reference	 26
	3.27.1	Field Doo	sumentation	 26
		3.27.1.1	binaryFile	 26
		3.27.1.2	reserved	 26
3.28	fc2PGF	RGuid Stru	ct Reference	 27
	3.28.1	Detailed I	Description	 27
	3.28.2	Field Doo	cumentation	 27
		3.28.2.1	value	 27
3.29	fc2PN0	Option St	ruct Reference	 27
	3.29.1	Field Doo	cumentation	 27
		3.29.1.1	compressionLevel	 27
		3.29.1.2	interlaced	 27
		3.29.1.3	reserved	 27
3.30	fc2PPN	Option St	ruct Reference	 28
	3.30.1	Field Doo	sumentation	 28
		3.30.1.1	binaryFile	 28
		3.30.1.2	reserved	 28
3.31	fc2Stro	beControl	Struct Reference	 28
	3.31.1	Field Doo	cumentation	 28
		3.31.1.1	delay	 28
		3.31.1.2	duration	 28
		3.31.1.3	onOff	 28
		3.31.1.4	polarity	 28
		3.31.1.5	reserved	 28
		3.31.1.6	source	 28
3.32	fc2Stro	beInfo Str	uct Reference	 29
	3.32.1	Field Doo	sumentation	 29
		3.32.1.1	maxValue	 29
		3.32.1.2	minValue	 29

CONTENTS ix

		3.32.1.3	onOffSupported	 . 29
		3.32.1.4	polaritySupported	 . 29
		3.32.1.5	present	 . 29
		3.32.1.6	readOutSupported	 . 29
		3.32.1.7	reserved	 . 29
		3.32.1.8	source	 . 29
3.33	fc2Syst	emInfo Str	ruct Reference	 . 29
	3.33.1	Field Doc	umentation	 . 30
		3.33.1.1	byteOrder	 . 30
		3.33.1.2	cpuDescription	 . 30
		3.33.1.3	driverList	 . 30
		3.33.1.4	gpuDescription	 . 30
		3.33.1.5	libraryList	 . 30
		3.33.1.6	numCpuCores	 . 30
		3.33.1.7	osDescription	 . 30
		3.33.1.8	osType	 . 30
		3.33.1.9	reserved	 . 30
		3.33.1.10	screenHeight	 . 30
		3.33.1.11	screenWidth	 . 30
		3.33.1.12	sysMemSize	 . 30
3.34	fc2TIFF	Option Str	ruct Reference	 . 30
	3.34.1	Field Doc	umentation	 . 31
		3.34.1.1	compression	 . 31
		3.34.1.2	reserved	 . 31
3.35	fc2Time	Stamp St	ruct Reference	 . 31
	3.35.1	Field Doc	umentation	 . 31
		3.35.1.1	cycleCount	 . 31
		3.35.1.2	cycleOffset	 . 31
		3.35.1.3	cycleSeconds	 . 31
		3.35.1.4	microSeconds	 . 31
		3.35.1.5	reserved	 . 31
		3.35.1.6	seconds	 . 31
3.36	fc2Trigg	gerDelay S	truct Reference	 . 31
	3.36.1	Field Doc	umentation	 . 32

x CONTENTS

	3.36.1.1 absControl
	3.36.1.2 absValue
	3.36.1.3 autoManualMode
	3.36.1.4 onePush
	3.36.1.5 onOff
	3.36.1.6 present
	3.36.1.7 reserved
	3.36.1.8 type
	3.36.1.9 valueA
	3.36.1.10 valueB
3.37 fc2Trig	ggerDelayInfo Struct Reference
3.37.1	Field Documentation
	3.37.1.1 absMax
	3.37.1.2 absMin
	3.37.1.3 absValSupported
	3.37.1.4 autoSupported
	3.37.1.5 manualSupported
	3.37.1.6 max
	3.37.1.7 min
	3.37.1.8 onePushSupported
	3.37.1.9 onOffSupported
	3.37.1.10 present
	3.37.1.11 pUnitAbbr
	3.37.1.12 pUnits
	3.37.1.13 readOutSupported
	3.37.1.14 reserved
	3.37.1.15 type
3.38 fc2Trig	ggerMode Struct Reference
3.38.1	Field Documentation
	3.38.1.1 mode
	3.38.1.2 onOff
	3.38.1.3 parameter
	3.38.1.4 polarity
	3.38.1.5 reserved

CONTENTS xi

			3.38.1.6	source	34
	3.39	fc2Trigg	gerModeIn	fo Struct Reference	34
		3.39.1	Field Doo	eumentation	35
			3.39.1.1	modeMask	35
			3.39.1.2	onOffSupported	35
			3.39.1.3	polaritySupported	35
			3.39.1.4	present	35
			3.39.1.5	readOutSupported	35
			3.39.1.6	reserved	35
			3.39.1.7	softwareTriggerSupported	35
			3.39.1.8	sourceMask	35
			3.39.1.9	valueReadable	35
	3.40	fc2Vers	sion Struct	Reference	35
		3.40.1	Field Doo	cumentation	35
			3.40.1.1	build	35
			3.40.1.2	major	35
			3.40.1.3	minor	35
			3.40.1.4	type	35
4			entation	Ella Defense	37
	4.1			File Reference	37
		4.1.1		Documentation	46
			4.1.1.1	fc2AVIAppend	46
			4.1.1.2	fc2AVIClose	46
			4.1.1.3	fc2AVIOpen	
			4.1.1.4	fc2CalculateImageStatistics	
			4.1.1.5	fc2Connect	47
			4.1.1.6	fc2ConvertImage	48
			4.1.1.7	fc2ConvertImageTo	48
			4.1.1.8	fc2CreateAVI	48
			4.1.1.9	fc2CreateContext	48
			4.1.1.10	fc2CreateGigEContext	49
					40
			4.1.1.11	fc2CreateImage	49

xii CONTENTS

4.1.1.13	fc2DestroyAVI	50
4.1.1.14	fc2DestroyContext	50
4.1.1.15	fc2DestroyImage	50
4.1.1.16	fc2DestroyImageStatistics	51
4.1.1.17	fc2DetermineBitsPerPixel	51
4.1.1.18	fc2Disconnect	51
4.1.1.19	fc2DiscoverGigECameras	52
4.1.1.20	fc2EnableLUT	52
4.1.1.21	fc2ErrorToDescription	52
4.1.1.22	fc2FireBusReset	53
4.1.1.23	fc2FireSoftwareTrigger	53
4.1.1.24	fc2FireSoftwareTriggerBroadcast	53
4.1.1.25	fc2ForceAllIPAddressesAutomatically	53
4.1.1.26	fc2ForceIPAddressAutomatically	54
4.1.1.27	fc2ForceIPAddressToCamera	54
4.1.1.28	fc2GetActiveLUTBank	54
4.1.1.29	fc2GetCameraFromIndex	55
4.1.1.30	fc2GetCameraFromSerialNumber	55
4.1.1.31	fc2GetCameraInfo	56
4.1.1.32	fc2GetCameraSerialNumberFromIndex	56
4.1.1.33	fc2GetConfiguration	56
4.1.1.34	fc2GetCycleTime	57
4.1.1.35	fc2GetDefaultColorProcessing	57
4.1.1.36	fc2GetDefaultOutputFormat	57
4.1.1.37	fc2GetDeviceFromIndex	57
4.1.1.38	fc2GetEmbeddedImageInfo	58
4.1.1.39	fc2GetFormat7Configuration	58
4.1.1.40	fc2GetFormat7Info	59
4.1.1.41	fc2GetGigEConfig	59
4.1.1.42	fc2GetGigEImageBinningSettings	59
4.1.1.43	fc2GetGigEImageSettings	59
4.1.1.44	fc2GetGigEImageSettingsInfo	59
4.1.1.45	fc2GetGigEImagingMode	59
4.1.1.46	fc2GetGigEProperty	59

CONTENTS xiii

4.1.1.47	fc2GetGigEStreamChannelInfo 60
4.1.1.48	fc2GetGPIOPinDirection 60
4.1.1.49	fc2GetImageData 60
4.1.1.50	fc2GetImageStatistics 61
4.1.1.51	fc2GetImageTimeStamp 61
4.1.1.52	fc2GetInterfaceTypeFromGuid 62
4.1.1.53	fc2GetLibraryVersion 62
4.1.1.54	fc2GetLUTBankInfo 62
4.1.1.55	fc2GetLUTChannel 63
4.1.1.56	fc2GetLUTInfo
4.1.1.57	fc2GetMemoryChannel 63
4.1.1.58	fc2GetMemoryChannelInfo 64
4.1.1.59	fc2GetNumOfCameras
4.1.1.60	fc2GetNumOfDevices 64
4.1.1.61	fc2GetNumStreamChannels 65
4.1.1.62	fc2GetProperty 65
4.1.1.63	fc2GetPropertyInfo
4.1.1.64	fc2GetRegisterString 65
4.1.1.65	fc2GetStrobe
4.1.1.66	fc2GetStrobeInfo
4.1.1.67	fc2GetSystemInfo
4.1.1.68	fc2GetTriggerDelay 67
4.1.1.69	fc2GetTriggerDelayInfo 67
4.1.1.70	fc2GetTriggerMode 67
4.1.1.71	fc2GetTriggerModeInfo
4.1.1.72	fc2GetVideoModeAndFrameRate 68
4.1.1.73	fc2GetVideoModeAndFrameRateInfo 68
4.1.1.74	fc2H264Open
4.1.1.75	fc2lsCameraControlable 69
4.1.1.76	fc2LaunchBrowser 69
4.1.1.77	fc2LaunchCommand
4.1.1.78	fc2LaunchCommandAsync 70
4.1.1.79	fc2LaunchHelp
4.1.1.80	fc2MJPGOpen

xiv CONTENTS

4.1.1.81	fc2QueryGigEImagingMode 71
4.1.1.82	fc2ReadGVCPMemory
4.1.1.83	fc2ReadGVCPRegister
4.1.1.84	fc2ReadGVCPRegisterBlock
4.1.1.85	fc2ReadRegister
4.1.1.86	fc2ReadRegisterBlock
4.1.1.87	fc2RegisterCallback
4.1.1.88	fc2RescanBus
4.1.1.89	fc2RestoreFromMemoryChannel
4.1.1.90	fc2RetrieveBuffer
4.1.1.91	fc2SaveImage
4.1.1.92	fc2SaveImageWithOption
4.1.1.93	fc2SaveToMemoryChannel
4.1.1.94	fc2SetActiveLUTBank
4.1.1.95	fc2SetCallback
4.1.1.96	fc2SetConfiguration
4.1.1.97	fc2SetDefaultColorProcessing
4.1.1.98	fc2SetDefaultOutputFormat
4.1.1.99	fc2SetEmbeddedImageInfo
4.1.1.100	fc2SetFormat7Configuration
4.1.1.101	fc2SetFormat7ConfigurationPacket
4.1.1.102	fc2SetGigEConfig
4.1.1.103	fc2SetGigEImageBinningSettings
4.1.1.104	fc2SetGigEImageSettings
4.1.1.105	fc2SetGigEImagingMode
4.1.1.106	fc2SetGigEProperty
4.1.1.107	fc2SetGigEStreamChannelInfo
4.1.1.108	fc2SetGPIOPinDirection
4.1.1.109	fc2SetGPIOPinDirectionBroadcast 79
4.1.1.110	fc2SetImageData 79
4.1.1.111	fc2SetImageDimensions 80
4.1.1.112	fc2SetLUTChannel
4.1.1.113	fc2SetProperty 80
4.1.1.114	fc2SetPropertyBroadcast

CONTENTS xv

		4.1.1.115	fc2SetStrobe	81
		4.1.1.116	fc2SetStrobeBroadcast	82
		4.1.1.117	fc2SetTriggerDelay	82
		4.1.1.118	fc2SetTriggerDelayBroadcast	82
		4.1.1.119	fc2SetTriggerMode	83
		4.1.1.120	fc2SetTriggerModeBroadcast	83
		4.1.1.121	fc2SetUserBuffers	83
		4.1.1.122	fc2SetVideoModeAndFrameRate	84
		4.1.1.123	fc2StartCapture	84
		4.1.1.124	fc2StartCaptureCallback	84
		4.1.1.125	fc2StartSyncCapture	85
		4.1.1.126	fc2StartSyncCaptureCallback	85
		4.1.1.127	fc2StopCapture	85
		4.1.1.128	fc2UnregisterCallback	86
		4.1.1.129	fc2ValidateFormat7Settings	86
		4.1.1.130	fc2WriteGVCPMemory	86
		4.1.1.131	fc2WriteGVCPRegister	87
		4.1.1.132	fc2WriteGVCPRegisterBlock	87
		4.1.1.133	fc2WriteGVCPRegisterBroadcast	87
		4.1.1.134	fc2WriteRegister	88
		4.1.1.135	fc2WriteRegisterBlock	88
		4.1.1.136	fc2WriteRegisterBroadcast	89
4.2	FlyCap	ture2Defs_	_C.h File Reference	89
	4.2.1	Define Do	ocumentation	93
		4.2.1.1	FALSE	93
		4.2.1.2	FULL_32BIT_VALUE	93
		4.2.1.3	MAX_STRING_LENGTH	93
		4.2.1.4	TRUE	93
	4.2.2	Typedef [Documentation	94
		4.2.2.1	BOOL	94
		4.2.2.2	fc2AsyncCommandCallback	94
		4.2.2.3	fc2AVIContext	94
		4.2.2.4	fc2BusEventCallback	94
		4.2.2.5	fc2CallbackHandle	94

xvi CONTENTS

		4.2.2.6	fc2Context
		4.2.2.7	fc2GuiContext
		4.2.2.8	fc2ImageEventCallback
		4.2.2.9	fc2ImageImpl
		4.2.2.10	fc2ImageStatisticsContext
	4.2.3	Enumera	tion Type Documentation
		4.2.3.1	fc2BandwidthAllocation
		4.2.3.2	fc2BayerTileFormat
		4.2.3.3	fc2BusCallbackType
		4.2.3.4	fc2BusSpeed
		4.2.3.5	fc2ByteOrder
		4.2.3.6	fc2ColorProcessingAlgorithm 96
		4.2.3.7	fc2DriverType
		4.2.3.8	fc2Error
		4.2.3.9	fc2FrameRate
		4.2.3.10	fc2GigEPropertyType
		4.2.3.11	fc2GrabMode
		4.2.3.12	fc2GrabTimeout
		4.2.3.13	fc2ImageFileFormat
		4.2.3.14	fc2InterfaceType
		4.2.3.15	fc2Mode
		4.2.3.16	fc2OSType
		4.2.3.17	fc2PCleBusSpeed
		4.2.3.18	fc2PixelFormat
		4.2.3.19	fc2PropertyType
		4.2.3.20	fc2StatisticsChannel
		4.2.3.21	fc2TIFFCompressionMethod
		4.2.3.22	fc2VideoMode
4.3	FlyCap	ture2GUI_	C.h File Reference
	4.3.1	Function	Documentation
		4.3.1.1	fc2CreateGUIContext
		4.3.1.2	fc2DestroyGUIContext
		4.3.1.3	fc2Disonnect
		4.3.1.4	fc2GUIConnect

CONTENTS xvii

		4.3.1.5	fc2Hide
		4.3.1.6	fc2lsVisible
		4.3.1.7	fc2Show
		4.3.1.8	fc2ShowModal
4.4	FlyCap	oture2Inter	nal_C.h File Reference
	4.4.1	Function	Documentation
		4.4.1.1	IsContextValid
		4.4.1.2	IsGuiContextValid
		4.4.1.3	SyncCppImageToStruct
4.5	FlyCap	oture2Platf	orm_C.h File Reference
	4.5.1	Define D	ocumentation
		4.5.1.1	FLYCAPTURE2_C_API
		4.5.1.2	FLYCAPTURE2_C_CALL_CONVEN
4.6	MultiS	yncLibrary	_C.h File Reference
	4.6.1	Function	Documentation
		4.6.1.1	syncCreateContext
		4.6.1.2	syncDestroyContext
		4.6.1.3	syncDisableCrossPCSynchronization 109
		4.6.1.4	syncEnableCrossPCSynchronization 109
		4.6.1.5	syncGetStatus
		4.6.1.6	syncGetTimeSinceSynced
		4.6.1.7	synclsTimingBusConnected
		4.6.1.8	syncQueryCrossPCSynchronizationSetting 110
		4.6.1.9	syncRescanMasterTimingBus
		4.6.1.10	syncStart
		4.6.1.11	syncStop
4.7	MultiS	yncLibrary	Defs_C.h File Reference
	4.7.1	Define D	ocumentation
		4.7.1.1	FALSE
		4.7.1.2	FULL_32BIT_VALUE
		4.7.1.3	MAX_STRING_LENGTH112
		4.7.1.4	TRUE
	4.7.2	Typedef	Documentation
		4.7.2.1	BOOL

xviii CONTE	NTS
-------------	-----

		4.7.2.2	syncContext
	4.7.3	Enumera	tion Type Documentation
		4.7.3.1	syncError
		4.7.3.2	syncMessage
4.8	MultiSy	yncLibrary	Platform_C.h File Reference
	4.8.1	Define D	ocumentation
		4.8.1.1	MULTISYNCLIBRARY_C_API
		4.8.1.2	MULTISYNCLIBRARY_C_CALL_CONVEN 113

Chapter 1

Data Structure Index

1.1 Data Structures

ere are the data structures with brief descriptions.
fc2AVIOption
fc2CameraInfo
fc2Config
fc2ConfigROM
fc2EmbeddedImageInfo
fc2EmbeddedImageInfoProperty
fc2Format7ImageSettings
fc2Format7Info
fc2Format7PacketInfo
fc2GigEConfig
fc2GigEImageSettings
fc2GigEImageSettingsInfo
fc2GigEProperty
fc2GigEStreamChannel
fc2H264Option
fc2Image
fc2ImageMetadata
fc2InternalContext
fc2InternalGuiContext
fc2InternalImageCallback
fc2IPAddress
fc2JPEGOption
fc2JPG2Option
fc2LUTData
fc2MACAddress
fc2MJPGOption
fc2PGMOption
fc2PGRGuid
A GUID to the camera

fc2PNGOption																			27
fc2PPMOption																			28
fc2StrobeControl																			28
fc2StrobeInfo .																			29
fc2SystemInfo .																			29
fc2TIFFOption																			30
fc2TimeStamp																			31
fc2TriggerDelay																			31
fc2TriggerDelayIr	nfo)																	32
fc2TriggerMode																			34
fc2TriggerModeIr																			
fc2Version																			35

Chapter 2

File Index

2.1 File List

Here is a list of all files with brief descriptions:

FlyCapture2_C.h												37
FlyCapture2Defs_C.h												89
FlyCapture2GUI_C.h												104
FlyCapture2Internal_C.h												107
FlyCapture2Platform_C.h												107
MultiSyncLibrary_C.h												107
MultiSyncLibraryDefs_C.h												111
MultiSvncLibrarvPlatform C.h												113

4 File Index

Chapter 3

Data Structure Documentation

3.1 fc2AVIOption Struct Reference

Data Fields


- float frameRate
- unsigned int reserved [256]
- 3.1.1 Field Documentation
- 3.1.1.1 float frameRate
- 3.1.1.2 unsigned int reserved[256]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.2 fc2CameraInfo Struct Reference

Collaboration diagram for fc2CameraInfo:



Data Fields

- unsigned int serialNumber
- fc2InterfaceType interfaceType
- fc2DriverType driverType
- BOOL isColorCamera
- char modelName [MAX STRING LENGTH]
- char vendorName [MAX STRING LENGTH]
- char sensorInfo [MAX STRING LENGTH]
- char sensorResolution [MAX_STRING_LENGTH]
- char driverName [MAX_STRING_LENGTH]
- char firmwareVersion [MAX_STRING_LENGTH]
- char firmwareBuildTime [MAX STRING LENGTH]
- fc2BusSpeed maximumBusSpeed
- fc2PCIeBusSpeed pcieBusSpeed
- · fc2BayerTileFormat bayerTileFormat
- unsigned short busNumber
- unsigned short nodeNumber
- · unsigned int iidcVer
- fc2ConfigROM configROM
- unsigned int gigEMajorVersion
- unsigned int gigEMinorVersion
- char userDefinedName [MAX_STRING_LENGTH]
- char xmlURL1 [MAX_STRING_LENGTH]
- char xmlURL2 [MAX STRING LENGTH]

- fc2MACAddress macAddress
- fc2IPAddress ipAddress
- fc2IPAddress subnetMask
- fc2IPAddress defaultGateway
- unsigned int ccpStatus

Status/Content of CCP register.

- unsigned int applicationIPAddress
 - Local Application IP Address.
- unsigned int applicationPort

Local Application port.

• unsigned int reserved [16]

3.2.1 Field Documentation

3.2.1.1 unsigned int applicationIPAddress

Local Application IP Address.

3.2.1.2 unsigned int applicationPort

Local Application port.

- 3.2.1.3 fc2BayerTileFormat bayerTileFormat
- 3.2.1.4 unsigned short busNumber
- 3.2.1.5 unsigned int ccpStatus

Status/Content of CCP register.

- 3.2.1.6 fc2ConfigROM configROM
- 3.2.1.7 fc2IPAddress defaultGateway
- 3.2.1.8 char driverName[MAX_STRING_LENGTH]
- 3.2.1.9 fc2DriverType driverType
- 3.2.1.10 char firmwareBuildTime[MAX_STRING_LENGTH]
- 3.2.1.11 char firmwareVersion[MAX_STRING_LENGTH]
- 3.2.1.12 unsigned int gigEMajorVersion

3.2.1.13	unsigned int gigEMinorVersion
3.2.1.14	unsigned int iidcVer
3.2.1.15	fc2InterfaceType interfaceType
3.2.1.16	fc2IPAddress ipAddress
3.2.1.17	BOOL isColorCamera
3.2.1.18	fc2MACAddress macAddress
3.2.1.19	fc2BusSpeed maximumBusSpeed
3.2.1.20	char modelName[MAX_STRING_LENGTH]
3.2.1.21	unsigned short nodeNumber
3.2.1.22	fc2PCleBusSpeed pcieBusSpeed
3.2.1.23	unsigned int reserved[16]
3.2.1.24	char sensorInfo[MAX_STRING_LENGTH]
3.2.1.25	${\bf char\ sensorResolution} [{\bf MAX_STRING_LENGTH}]$
3.2.1.26	unsigned int serialNumber
3.2.1.27	fc2IPAddress subnetMask
3.2.1.28	char userDefinedName[MAX_STRING_LENGTH]
3.2.1.29	char vendorName[MAX_STRING_LENGTH]
3.2.1.30	char xmIURL1[MAX_STRING_LENGTH]
3.2.1.31	char xmIURL2[MAX_STRING_LENGTH]

• FlyCapture2Defs_C.h

3.3 fc2Config Struct Reference

Data Fields

• unsigned int numBuffers

- unsigned int numImageNotifications
- unsigned int minNumImageNotifications
- int grabTimeout
- fc2GrabMode grabMode
- · fc2BusSpeed isochBusSpeed
- fc2BusSpeed asyncBusSpeed
- · fc2BandwidthAllocation bandwidthAllocation
- unsigned int registerTimeoutRetries
- unsigned int registerTimeout
- unsigned int reserved [16]
- 3.3.1 Field Documentation
- 3.3.1.1 fc2BusSpeed asyncBusSpeed
- 3.3.1.2 fc2BandwidthAllocation bandwidthAllocation
- 3.3.1.3 fc2GrabMode grabMode
- 3.3.1.4 int grabTimeout
- 3.3.1.5 fc2BusSpeed isochBusSpeed
- 3.3.1.6 unsigned int minNumImageNotifications
- 3.3.1.7 unsigned int numBuffers
- 3.3.1.8 unsigned int numImageNotifications
- 3.3.1.9 unsigned int registerTimeout
- 3.3.1.10 unsigned int registerTimeoutRetries
- 3.3.1.11 unsigned int reserved[16]

• FlyCapture2Defs_C.h

3.4 fc2ConfigROM Struct Reference

Data Fields


- · unsigned int nodeVendorld
- · unsigned int chipIdHi

- unsigned int chipIdLo
- unsigned int unitSpecId
- unsigned int unitSWVer
- unsigned int unitSubSWVer
- unsigned int vendorUniqueInfo_0
- unsigned int vendorUniqueInfo_1
- unsigned int vendorUniqueInfo_2
- unsigned int vendorUniqueInfo_3
- char pszKeyword [MAX_STRING_LENGTH]
- unsigned int reserved [16]
- 3.4.1 Field Documentation
- 3.4.1.1 unsigned int chipIdHi
- 3.4.1.2 unsigned int chipIdLo
- 3.4.1.3 unsigned int nodeVendorld
- 3.4.1.4 char pszKeyword[MAX_STRING_LENGTH]
- 3.4.1.5 unsigned int reserved[16]
- 3.4.1.6 unsigned int unitSpecId
- 3.4.1.7 unsigned int unitSubSWVer
- 3.4.1.8 unsigned int unitSWVer
- 3.4.1.9 unsigned int vendorUniqueInfo_0
- 3.4.1.10 unsigned int vendorUniqueInfo_1
- 3.4.1.11 unsigned int vendorUniqueInfo_2
- $3.4.1.12 \quad unsigned \ int \ vendor Unique Info_3$

• FlyCapture2Defs_C.h

3.5 fc2EmbeddedImageInfo Struct Reference

Collaboration diagram for fc2EmbeddedImageInfo:



Data Fields

- fc2EmbeddedImageInfoProperty timestamp
- fc2EmbeddedImageInfoProperty gain
- fc2EmbeddedImageInfoProperty shutter
- fc2EmbeddedImageInfoProperty brightness
- fc2EmbeddedImageInfoProperty exposure
- fc2EmbeddedImageInfoProperty whiteBalance
- fc2EmbeddedImageInfoProperty frameCounter
- fc2EmbeddedImageInfoProperty strobePattern
- $\bullet \ \ fc 2 Embedded Image Info Property\ GPIOP in State \\$
- fc2EmbeddedImageInfoProperty ROIPosition

3.5.1 Field Documentation

3.5.1.1 fc2EmbeddedImageInfoProperty brightness

- 3.5.1.2 fc2EmbeddedImageInfoProperty exposure
 3.5.1.3 fc2EmbeddedImageInfoProperty frameCounter
 3.5.1.4 fc2EmbeddedImageInfoProperty gain
 3.5.1.5 fc2EmbeddedImageInfoProperty GPIOPinState
 3.5.1.6 fc2EmbeddedImageInfoProperty ROIPosition
 3.5.1.7 fc2EmbeddedImageInfoProperty shutter
- 3.5.1.8 fc2EmbeddedImageInfoProperty strobePattern
 3.5.1.9 fc2EmbeddedImageInfoProperty timestamp

3.5.1.10 fc2EmbeddedImageInfoProperty whiteBalance

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.6 fc2EmbeddedImageInfoProperty Struct Reference

Data Fields

- · BOOL available
- BOOL onOff
- 3.6.1 Field Documentation
- 3.6.1.1 BOOL available
- 3.6.1.2 BOOL onOff

The documentation for this struct was generated from the following file:

• FlyCapture2Defs C.h

3.7 fc2Format7ImageSettings Struct Reference

Data Fields

· fc2Mode mode

- unsigned int offsetX
- unsigned int offsetY
- unsigned int width
- · unsigned int height
- · fc2PixelFormat pixelFormat
- unsigned int reserved [8]
- 3.7.1 Field Documentation
- 3.7.1.1 unsigned int height
- 3.7.1.2 fc2Mode mode
- 3.7.1.3 unsigned int offsetX
- 3.7.1.4 unsigned int offsetY
- 3.7.1.5 fc2PixelFormat pixelFormat
- 3.7.1.6 unsigned int reserved[8]
- 3.7.1.7 unsigned int width

• FlyCapture2Defs_C.h

3.8 fc2Format7Info Struct Reference

Data Fields

- fc2Mode mode
- unsigned int maxWidth
- · unsigned int maxHeight
- unsigned int offsetHStepSize
- unsigned int offsetVStepSize
- unsigned int imageHStepSize
- unsigned int imageVStepSize
- unsigned int pixelFormatBitField
- · unsigned int vendorPixelFormatBitField
- unsigned int packetSize
- unsigned int minPacketSize
- unsigned int maxPacketSize
- float percentage
- unsigned int reserved [16]

3.8.1	Field Documentation
3.8.1.1	unsigned int imageHStepSize
3.8.1.2	unsigned int imageVStepSize
3.8.1.3	unsigned int maxHeight
3.8.1.4	unsigned int maxPacketSize
3.8.1.5	unsigned int maxWidth
3.8.1.6	unsigned int minPacketSize
3.8.1.7	fc2Mode mode
3.8.1.8	unsigned int offsetHStepSize
3.8.1.9	unsigned int offsetVStepSize

- 3.8.1.11 float percentage
- 3.8.1.12 unsigned int pixelFormatBitField
- 3.8.1.13 unsigned int reserved[16]

3.8.1.10 unsigned int packetSize

3.8.1.14 unsigned int vendorPixelFormatBitField

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.9 fc2Format7PacketInfo Struct Reference

Data Fields

- · unsigned int recommendedBytesPerPacket
- unsigned int maxBytesPerPacket
- unsigned int unitBytesPerPacket
- unsigned int reserved [8]

3.9.1 Field Documentation

- 3.9.1.1 unsigned int maxBytesPerPacket
- 3.9.1.2 unsigned int recommendedBytesPerPacket
- 3.9.1.3 unsigned int reserved[8]
- 3.9.1.4 unsigned int unitBytesPerPacket

• FlyCapture2Defs_C.h

3.10 fc2GigEConfig Struct Reference

Data Fields

• BOOL enablePacketResend

Turn on/off packet resend functionality.

• unsigned int timeoutForPacketResend

The number of miliseconds to wait for each requested packet.

unsigned int maxPacketsToResend

The max number of packets that can be requested to be resend.

• unsigned int reserved [8]

3.10.1 Field Documentation

3.10.1.1 BOOL enablePacketResend

Turn on/off packet resend functionality.

3.10.1.2 unsigned int maxPacketsToResend

The max number of packets that can be requested to be resend.

3.10.1.3 unsigned int reserved[8]

3.10.1.4 unsigned int timeoutForPacketResend

The number of miliseconds to wait for each requested packet.

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.11 fc2GigElmageSettings Struct Reference

Data Fields

- · unsigned int offsetX
- · unsigned int offsetY
- · unsigned int width
- · unsigned int height
- fc2PixelFormat pixelFormat
- unsigned int reserved [8]

3.11.1 Field Documentation

- 3.11.1.1 unsigned int height
- 3.11.1.2 unsigned int offsetX
- 3.11.1.3 unsigned int offsetY
- 3.11.1.4 fc2PixelFormat pixelFormat
- 3.11.1.5 unsigned int reserved[8]
- 3.11.1.6 unsigned int width

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.12 fc2GigElmageSettingsInfo Struct Reference

Data Fields

- unsigned int maxWidth
- · unsigned int maxHeight
- · unsigned int offsetHStepSize
- unsigned int offsetVStepSize
- unsigned int imageHStepSize
- unsigned int imageVStepSize
- · unsigned int pixelFormatBitField
- · unsigned int vendorPixelFormatBitField
- unsigned int reserved [16]

3.12.1	Field Documentation
3.12.1.1	unsigned int imageHStepSize
3.12.1.2	unsigned int imageVStepSize
3.12.1.3	unsigned int maxHeight
3.12.1.4	unsigned int maxWidth
3.12.1.5	unsigned int offsetHStepSize
3.12.1.6	unsigned int offsetVStepSize
3.12.1.7	unsigned int pixelFormatBitField
3.12.1.8	unsigned int reserved[16]

3.12.1.9 unsigned int vendorPixelFormatBitField

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.13 fc2GigEProperty Struct Reference

- fc2GigEPropertyType propType
- BOOL isReadable
- BOOL isWritable
- unsigned int min
- unsigned int max
- unsigned int value
- unsigned int reserved [8]
- 3.13.1 Field Documentation
- 3.13.1.1 BOOL is Readable
- 3.13.1.2 BOOL is Writable
- 3.13.1.3 unsigned int max
- 3.13.1.4 unsigned int min


- 3.13.1.5 fc2GigEPropertyType propType
- 3.13.1.6 unsigned int reserved[8]
- 3.13.1.7 unsigned int value

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.14 fc2GigEStreamChannel Struct Reference

Collaboration diagram for fc2GigEStreamChannel:



Data Fields

- unsigned int networkInterfaceIndex
- unsigned int hostPost
- BOOL doNotFragment
- unsigned int packetSize
- unsigned int interPacketDelay
- fc2IPAddress destinationIpAddress
- unsigned int sourcePort
- unsigned int reserved [8]

3.14.1 Field Documentation

3.14.1.1 fc2IPAddress destinationIpAddress

- 3.14.1.2 BOOL doNotFragment
- 3.14.1.3 unsigned int hostPost
- 3.14.1.4 unsigned int interPacketDelay
- 3.14.1.5 unsigned int networkInterfaceIndex
- 3.14.1.6 unsigned int packetSize
- 3.14.1.7 unsigned int reserved[8]
- 3.14.1.8 unsigned int sourcePort

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.15 fc2H264Option Struct Reference

Data Fields

- float frameRate
- unsigned int width
- · unsigned int height
- · unsigned int bitrate
- unsigned int reserved [256]
- 3.15.1 Field Documentation
- 3.15.1.1 unsigned int bitrate
- 3.15.1.2 float frameRate
- 3.15.1.3 unsigned int height
- 3.15.1.4 unsigned int reserved[256]
- 3.15.1.5 unsigned int width

The documentation for this struct was generated from the following file:

3.16 fc2Image Struct Reference

Data Fields

- · unsigned int rows
- · unsigned int cols
- unsigned int stride
- unsigned char * pData
- unsigned int dataSize
- unsigned int receivedDataSize
- · fc2PixelFormat format
- fc2BayerTileFormat bayerFormat
- fc2lmagelmpl imagelmpl

3.16.1 Field Documentation

- 3.16.1.1 fc2BayerTileFormat bayerFormat
- 3.16.1.2 unsigned int cols
- 3.16.1.3 unsigned int dataSize
- 3.16.1.4 fc2PixelFormat format
- 3.16.1.5 fc2lmagelmpl imagelmpl
- 3.16.1.6 unsigned char* pData
- 3.16.1.7 unsigned int receivedDataSize
- 3.16.1.8 unsigned int rows
- 3.16.1.9 unsigned int stride

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.17 fc2ImageMetadata Struct Reference

- unsigned int embeddedTimeStamp
- unsigned int embeddedGain
- · unsigned int embeddedShutter

- unsigned int embeddedBrightness
- unsigned int embeddedExposure
- unsigned int embeddedWhiteBalance
- unsigned int embeddedFrameCounter
- unsigned int embeddedStrobePattern
- unsigned int embeddedGPIOPinState
- unsigned int embeddedROIPosition
- unsigned int reserved [31]

3.17.1 Field Documentation

- 3.17.1.1 unsigned int embeddedBrightness
- 3.17.1.2 unsigned int embeddedExposure
- 3.17.1.3 unsigned int embeddedFrameCounter
- 3.17.1.4 unsigned int embeddedGain
- 3.17.1.5 unsigned int embeddedGPIOPinState
- 3.17.1.6 unsigned int embeddedROIPosition
- 3.17.1.7 unsigned int embeddedShutter
- 3.17.1.8 unsigned int embeddedStrobePattern
- 3.17.1.9 unsigned int embeddedTimeStamp
- 3.17.1.10 unsigned int embeddedWhiteBalance
- 3.17.1.11 unsigned int reserved[31]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.18 fc2InternalContext Struct Reference

- FlyCapture2::BusManager * pBusMgr
- FlyCapture2::CameraBase * pCamera

3.18.1 Field Documentation

3.18.1.1 FlyCapture2::BusManager* pBusMgr

3.18.1.2 FlyCapture2::CameraBase* pCamera

The documentation for this struct was generated from the following file:

• FlyCapture2Internal_C.h

3.19 fc2InternalGuiContext Struct Reference

Data Fields

- FlyCapture2::CameraSelectionDlg * pCameraSelectionDlg
- FlyCapture2::CameraControlDlg * pCameraControlDlg

3.19.1 Field Documentation


- 3.19.1.1 FlyCapture2::CameraControlDlg* pCameraControlDlg
- $3.19.1.2 \quad \textbf{FlyCapture2::CameraSelectionDlg} * \textbf{pCameraSelectionDlg}$

The documentation for this struct was generated from the following file:

• FlyCapture2Internal_C.h

3.20 fc2InternalImageCallback Struct Reference

Collaboration diagram for fc2InternalImageCallback:



Data Fields

- fc2ImageEventCallback pCallback
- void * pCallbackData

3.20.1 Field Documentation

3.20.1.1 fc2ImageEventCallback pCallback

3.20.1.2 void* pCallbackData

The documentation for this struct was generated from the following file:

• FlyCapture2Internal_C.h

3.21 fc2IPAddress Struct Reference

Data Fields

• unsigned char octets [4]

3.21.1 Field Documentation

3.21.1.1 unsigned char octets[4]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.22 fc2JPEGOption Struct Reference

Data Fields

- BOOL progressive
- · unsigned int quality
- unsigned int reserved [16]
- 3.22.1 Field Documentation
- 3.22.1.1 BOOL progressive
- 3.22.1.2 unsigned int quality
- 3.22.1.3 unsigned int reserved[16]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.23 fc2JPG2Option Struct Reference

Data Fields

- · unsigned int quality
- unsigned int reserved [16]
- 3.23.1 Field Documentation
- 3.23.1.1 unsigned int quality
- 3.23.1.2 unsigned int reserved[16]

The documentation for this struct was generated from the following file:

3.24 fc2LUTData Struct Reference

Data Fields

- BOOL supported
- BOOL enabled
- unsigned int numBanks
- unsigned int numChannels
- unsigned int inputBitDepth
- unsigned int outputBitDepth
- unsigned int numEntries
- unsigned int reserved [8]
- 3.24.1 Field Documentation
- 3.24.1.1 BOOL enabled
- 3.24.1.2 unsigned int inputBitDepth
- 3.24.1.3 unsigned int numBanks
- 3.24.1.4 unsigned int numChannels
- 3.24.1.5 unsigned int numEntries
- 3.24.1.6 unsigned int outputBitDepth
- 3.24.1.7 unsigned int reserved[8]
- 3.24.1.8 BOOL supported

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.25 fc2MACAddress Struct Reference

Data Fields

• unsigned char octets [6]

3.25.1 Field Documentation

3.25.1.1 unsigned char octets[6]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.26 fc2MJPGOption Struct Reference

Data Fields

- float frameRate
- · unsigned int quality
- unsigned int reserved [256]
- 3.26.1 Field Documentation
- 3.26.1.1 float frameRate
- 3.26.1.2 unsigned int quality
- 3.26.1.3 unsigned int reserved[256]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.27 fc2PGMOption Struct Reference

Data Fields

- BOOL binaryFile
- unsigned int reserved [16]
- 3.27.1 Field Documentation
- 3.27.1.1 BOOL binaryFile
- 3.27.1.2 unsigned int reserved[16]

The documentation for this struct was generated from the following file:

3.28 fc2PGRGuid Struct Reference

A GUID to the camera.

Data Fields

• unsigned int value [4]

3.28.1 Detailed Description

A GUID to the camera.

It is used to uniquely identify a camera.

3.28.2 Field Documentation

3.28.2.1 unsigned int value[4]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.29 fc2PNGOption Struct Reference

Data Fields

- BOOL interlaced
- unsigned int compressionLevel
- unsigned int reserved [16]

3.29.1 Field Documentation

3.29.1.1 unsigned int compressionLevel

3.29.1.2 BOOL interlaced

3.29.1.3 unsigned int reserved[16]

The documentation for this struct was generated from the following file:

3.30 fc2PPMOption Struct Reference

Data Fields

- · BOOL binaryFile
- unsigned int reserved [16]
- 3.30.1 Field Documentation
- 3.30.1.1 BOOL binaryFile
- 3.30.1.2 unsigned int reserved[16]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.31 fc2StrobeControl Struct Reference

Data Fields

- unsigned int source
- BOOL onOff
- · unsigned int polarity
- · float delay
- float duration
- unsigned int reserved [8]
- 3.31.1 Field Documentation
- 3.31.1.1 float delay
- 3.31.1.2 float duration
- 3.31.1.3 BOOL onOff
- 3.31.1.4 unsigned int polarity
- 3.31.1.5 unsigned int reserved[8]
- 3.31.1.6 unsigned int source

The documentation for this struct was generated from the following file:

3.32 fc2Strobelnfo Struct Reference

Data Fields

- · unsigned int source
- BOOL present
- BOOL readOutSupported
- BOOL onOffSupported
- BOOL polaritySupported
- float minValue
- float maxValue
- unsigned int reserved [8]
- 3.32.1 Field Documentation
- 3.32.1.1 float maxValue
- 3.32.1.2 float minValue
- 3.32.1.3 BOOL on Off Supported
- 3.32.1.4 BOOL polaritySupported
- 3.32.1.5 BOOL present
- 3.32.1.6 BOOL readOutSupported
- 3.32.1.7 unsigned int reserved[8]
- 3.32.1.8 unsigned int source

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.33 fc2SystemInfo Struct Reference

- fc2OSType osType
- char osDescription [MAX_STRING_LENGTH]
- fc2ByteOrder byteOrder
- size_t sysMemSize
- char cpuDescription [MAX_STRING_LENGTH]
- size t numCpuCores

- char driverList [MAX_STRING_LENGTH]
- char libraryList [MAX_STRING_LENGTH]
- char gpuDescription [MAX_STRING_LENGTH]
- · size_t screenWidth
- size_t screenHeight
- unsigned int reserved [16]
- 3.33.1 Field Documentation
- 3.33.1.1 fc2ByteOrder byteOrder
- 3.33.1.2 char cpuDescription[MAX_STRING_LENGTH]
- 3.33.1.3 char driverList[MAX_STRING_LENGTH]
- 3.33.1.4 char gpuDescription[MAX_STRING_LENGTH]
- 3.33.1.5 char libraryList[MAX_STRING_LENGTH]
- 3.33.1.6 size_t numCpuCores
- 3.33.1.7 char osDescription[MAX_STRING_LENGTH]
- 3.33.1.8 fc2OSType osType
- 3.33.1.9 unsigned int reserved[16]
- 3.33.1.10 size_t screenHeight
- 3.33.1.11 size_t screenWidth
- 3.33.1.12 size_t sysMemSize

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.34 fc2TIFFOption Struct Reference

- fc2TIFFCompressionMethod compression
- unsigned int reserved [16]

3.34.1 Field Documentation

3.34.1.1 fc2TIFFCompressionMethod compression

3.34.1.2 unsigned int reserved[16]

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.35 fc2TimeStamp Struct Reference

Data Fields

- long long seconds
- · unsigned int microSeconds
- unsigned int cycleSeconds
- unsigned int cycleCount
- unsigned int cycleOffset
- unsigned int reserved [8]

3.35.1 Field Documentation

- 3.35.1.1 unsigned int cycleCount
- 3.35.1.2 unsigned int cycleOffset
- 3.35.1.3 unsigned int cycleSeconds
- 3.35.1.4 unsigned int microSeconds
- 3.35.1.5 unsigned int reserved[8]
- 3.35.1.6 long long seconds

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.36 fc2TriggerDelay Struct Reference

Data Fields

fc2PropertyType type

- BOOL present
- BOOL absControl
- BOOL onePush
- BOOL onOff
- BOOL autoManualMode
- · unsigned int valueA
- unsigned int valueB
- float absValue
- unsigned int reserved [8]
- 3.36.1 Field Documentation
- 3.36.1.1 BOOL absControl
- 3.36.1.2 float absValue
- 3.36.1.3 BOOL autoManualMode
- 3.36.1.4 BOOL onePush
- 3.36.1.5 BOOL on Off
- 3.36.1.6 BOOL present
- 3.36.1.7 unsigned int reserved[8]
- 3.36.1.8 fc2PropertyType type
- 3.36.1.9 unsigned int valueA
- 3.36.1.10 unsigned int valueB

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.37 fc2TriggerDelayInfo Struct Reference

- fc2PropertyType type
- BOOL present
- BOOL autoSupported
- · BOOL manualSupported
- · BOOL onOffSupported

- BOOL onePushSupported
- BOOL absValSupported
- BOOL readOutSupported
- unsigned int min
- · unsigned int max
- float absMin
- float absMax
- char pUnits [MAX STRING LENGTH]
- char pUnitAbbr [MAX_STRING_LENGTH]
- unsigned int reserved [8]
- 3.37.1 Field Documentation
- 3.37.1.1 float absMax
- 3.37.1.2 float absMin
- 3.37.1.3 BOOL absValSupported
- 3.37.1.4 BOOL autoSupported
- 3.37.1.5 BOOL manual Supported
- 3.37.1.6 unsigned int max
- 3.37.1.7 unsigned int min
- 3.37.1.8 BOOL onePushSupported
- 3.37.1.9 BOOL on Off Supported
- 3.37.1.10 BOOL present
- 3.37.1.11 char pUnitAbbr[MAX_STRING_LENGTH]
- 3.37.1.12 char pUnits[MAX_STRING_LENGTH]
- 3.37.1.13 BOOL readOutSupported
- 3.37.1.14 unsigned int reserved[8]
- 3.37.1.15 fc2PropertyType type

The documentation for this struct was generated from the following file:

3.38 fc2TriggerMode Struct Reference

Data Fields

- BOOL onOff
- · unsigned int polarity
- · unsigned int source
- unsigned int mode
- unsigned int parameter
- unsigned int reserved [8]
- 3.38.1 Field Documentation
- 3.38.1.1 unsigned int mode
- 3.38.1.2 BOOL on Off
- 3.38.1.3 unsigned int parameter
- 3.38.1.4 unsigned int polarity
- 3.38.1.5 unsigned int reserved[8]
- 3.38.1.6 unsigned int source

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.39 fc2TriggerModeInfo Struct Reference

- BOOL present
- BOOL readOutSupported
- BOOL onOffSupported
- BOOL polaritySupported
- BOOL valueReadable
- unsigned int sourceMask
- · BOOL softwareTriggerSupported
- unsigned int modeMask
- unsigned int reserved [8]

3.39.1	Field Documentation
3.39.1.1	unsigned int modeMask
3.39.1.2	BOOL onOffSupported
3.39.1.3	BOOL polaritySupported
3.39.1.4	BOOL present
3.39.1.5	BOOL readOutSupported
3.39.1.6	unsigned int reserved[8]
3.39.1.7	BOOL softwareTriggerSupported
3.39.1.8	unsigned int sourceMask

The documentation for this struct was generated from the following file:

• FlyCapture2Defs_C.h

3.39.1.9 BOOL valueReadable

3.40 fc2Version Struct Reference

Data Fields

- · unsigned int major
- unsigned int minor
- unsigned int type
- unsigned int build

3.40.1 Field Documentation

- 3.40.1.1 unsigned int build
- 3.40.1.2 unsigned int major
- 3.40.1.3 unsigned int minor
- 3.40.1.4 unsigned int type

The documentation for this struct was generated from the following file:

Chapter 4

File Documentation

4.1 FlyCapture2_C.h File Reference

Functions

- FLYCAPTURE2_C_API fc2Error fc2CreateContext (fc2Context *pContext)
 Create a FC2 context for IIDC camaera.
- FLYCAPTURE2_C_API fc2Error fc2CreateGigEContext (fc2Context *p-Context)

Create a FC2 context for a GigE Vision camera.

- FLYCAPTURE2_C_API fc2Error fc2DestroyContext (fc2Context context)

 Destroy the FC2 context.
- FLYCAPTURE2_C_API fc2Error fc2FireBusReset (fc2Context context, fc2PGR-Guid *pGuid)

Fire a bus reset.

FLYCAPTURE2_C_API fc2Error fc2GetNumOfCameras (fc2Context context, unsigned int *pNumCameras)

Gets the number of cameras attached to the PC.

FLYCAPTURE2_C_API fc2Error fc2IsCameraControlable (fc2Context context, fc2PGRGuid *pGuid, BOOL *pControlable)

Query whether a GigE camera is controlable.

 FLYCAPTURE2_C_API fc2Error fc2GetCameraFromIndex (fc2Context context, unsigned int index, fc2PGRGuid *pGuid)

Gets the PGRGuid for a camera on the PC.

 FLYCAPTURE2_C_API fc2Error fc2GetCameraFromSerialNumber (fc2Context context, unsigned int serialNumber, fc2PGRGuid *pGuid)

Gets the PGRGuid for a camera on the PC.

 FLYCAPTURE2_C_API fc2Error fc2GetCameraSerialNumberFromIndex (fc2-Context context, unsigned int index, unsigned int *pSerialNumber)

Gets the serial number of the camera with the specified index.

FLYCAPTURE2_C_API fc2Error fc2GetInterfaceTypeFromGuid (fc2Context context, fc2PGRGuid *pGuid, fc2InterfaceType *pInterfaceType)

Gets the interface type associated with a PGRGuid.

FLYCAPTURE2_C_API fc2Error fc2GetNumOfDevices (fc2Context context, unsigned int *pNumDevices)

Gets the number of devices.

• FLYCAPTURE2_C_API fc2Error fc2GetDeviceFromIndex (fc2Context context, unsigned int index, fc2PGRGuid *pGuid)

Gets the PGRGuid for a device.

FLYCAPTURE2_C_API fc2Error fc2RegisterCallback (fc2Context context, fc2-BusEventCallback enumCallback, fc2BusCallbackType callbackType, void *p-Parameter, fc2CallbackHandle *pCallbackHandle)

Register a callback function that will be called when the specified callback event oc-

 FLYCAPTURE2_C_API fc2Error fc2UnregisterCallback (fc2Context context, fc2-CallbackHandle callbackHandle)

Unregister a callback function.

FLYCAPTURE2_C_API fc2Error fc2RescanBus (fc2Context context)

Force a rescan of the buses.

FLYCAPTURE2_C_API fc2Error fc2ForceIPAddressToCamera (fc2Context context, fc2MACAddress macAddress, fc2IPAddress ipAddress, fc2IPAddress subnetMask, fc2IPAddress defaultGateway)

Force the camera with the specific MAC address to the specified IP address, subnet mask and default gateway.

• FLYCAPTURE2 C API fc2Error fc2ForceAllIPAddressesAutomatically ()

Force all cameras on the network to be assigned sequential IP addresses on the same subnet as the network adapters that they are connected to.

 FLYCAPTURE2_C_API fc2Error fc2ForceIPAddressAutomatically (unsigned int serialNumber)

Force a cameras on the network to be assigned sequential IP addresses on the same subnet as the network adapters that it is connected to.

FLYCAPTURE2_C_API fc2Error fc2DiscoverGigECameras (fc2Context context, fc2CameraInfo *gigECameras, unsigned int *arraySize)

Discover all cameras connected to the network even if they reside on a different subnet.

 FLYCAPTURE2_C_API fc2Error fc2WriteRegister (fc2Context context, unsigned int address, unsigned int value)

Write to the specified register on the camera.

 FLYCAPTURE2_C_API fc2Error fc2WriteRegisterBroadcast (fc2Context context, unsigned int address, unsigned int value)

Write to the specified register on the camera with broadcast.

 FLYCAPTURE2_C_API fc2Error fc2ReadRegister (fc2Context context, unsigned int address, unsigned int *pValue)

Read the specified register from the camera.

• FLYCAPTURE2_C_API fc2Error fc2WriteRegisterBlock (fc2Context context, unsigned short addressHigh, unsigned int addressLow, const unsigned int *pBuffer, unsigned int length)

Write to the specified register block on the camera.

FLYCAPTURE2_C_API fc2Error fc2ReadRegisterBlock (fc2Context context, unsigned short addressHigh, unsigned int addressLow, unsigned int *pBuffer, unsigned int length)

Write to the specified register block on the camera.

 FLYCAPTURE2_C_API fc2Error fc2Connect (fc2Context context, fc2PGRGuid *guid)

Connects the camera object to the camera specified by the GUID.

• FLYCAPTURE2 C API fc2Error fc2Disconnect (fc2Context context)

Disconnects the fc2Context from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetCallback (fc2Context context, fc2Image-EventCallback pCallbackFn, void *pCallbackData)

Sets the callback data to be used on completion of image transfer.

• FLYCAPTURE2 C API fc2Error fc2StartCapture (fc2Context context)

Starts isochronous image capture.

FLYCAPTURE2_C_API fc2Error fc2StartCaptureCallback (fc2Context context, fc2ImageEventCallback pCallbackFn, void *pCallbackData)

Starts isochronous image capture.

 FLYCAPTURE2_C_API fc2Error fc2StartSyncCapture (unsigned int num-Cameras, fc2Context *pContexts)

Starts synchronized isochronous image capture on multiple cameras.

 FLYCAPTURE2_C_API fc2Error fc2StartSyncCaptureCallback (unsigned int numCameras, fc2Context *pContexts, fc2ImageEventCallback *pCallbackFns, void **pCallbackDataArray)

Starts synchronized isochronous image capture on multiple cameras.

 FLYCAPTURE2_C_API fc2Error fc2RetrieveBuffer (fc2Context context, fc2lmage *plmage)

Retrieves the the next image object containing the next image.

FLYCAPTURE2_C_API fc2Error fc2StopCapture (fc2Context context)

Stops isochronous image transfer and cleans up all associated resources.

FLYCAPTURE2_C_API fc2Error fc2SetUserBuffers (fc2Context context, unsigned char *const ppMemBuffers, int size, int nNumBuffers)

Specify user allocated buffers to use as image data buffers.

 FLYCAPTURE2_C_API fc2Error fc2GetConfiguration (fc2Context context, fc2-Config *config)

Get the configuration associated with the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetConfiguration (fc2Context context, fc2-Config *config)

Set the configuration associated with the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetCameraInfo (fc2Context context, fc2-CameraInfo *pCameraInfo)

Retrieves information from the camera such as serial number, model name and other camera information.

 FLYCAPTURE2_C_API fc2Error fc2GetPropertyInfo (fc2Context context, fc2-PropertyInfo *propInfo) Retrieves information about the specified camera property.

 FLYCAPTURE2_C_API fc2Error fc2GetProperty (fc2Context context, fc2-Property *prop)

Reads the settings for the specified property from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetProperty (fc2Context context, fc2-Property *prop)

Writes the settings for the specified property to the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetPropertyBroadcast (fc2Context context, fc2Property *prop)

Writes the settings for the specified property to the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetGPIOPinDirection (fc2Context context, unsigned int pin, unsigned int *pDirection)

Get the GPIO pin direction for the specified pin.

 FLYCAPTURE2_C_API fc2Error fc2SetGPIOPinDirection (fc2Context context, unsigned int pin, unsigned int direction)

Set the GPIO pin direction for the specified pin.

 FLYCAPTURE2_C_API fc2Error fc2SetGPIOPinDirectionBroadcast (fc2Context context, unsigned int pin, unsigned int direction)

Set the GPIO pin direction for the specified pin.

 FLYCAPTURE2_C_API fc2Error fc2GetTriggerModeInfo (fc2Context context, fc2TriggerModeInfo *triggerModeInfo)

Retrieve trigger information from the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetTriggerMode (fc2Context context, fc2-TriggerMode *triggerMode)

Retrieve current trigger settings from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetTriggerMode (fc2Context context, fc2-TriggerMode *triggerMode)

Set the specified trigger settings to the camera.

FLYCAPTURE2_C_API fc2Error fc2SetTriggerModeBroadcast (fc2Context context, fc2TriggerMode *triggerMode)

Set the specified trigger settings to the camera.

- FLYCAPTURE2 C API fc2Error fc2FireSoftwareTrigger (fc2Context context)
- FLYCAPTURE2_C_API fc2Error fc2FireSoftwareTriggerBroadcast (fc2Context context)

Fire the software trigger according to the DCAM specifications.

FLYCAPTURE2_C_API fc2Error fc2GetTriggerDelayInfo (fc2Context context, fc2TriggerDelayInfo *triggerDelayInfo)

Retrieve trigger delay information from the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetTriggerDelay (fc2Context context, fc2-TriggerDelay *triggerDelay)

Retrieve current trigger delay settings from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetTriggerDelay (fc2Context context, fc2-TriggerDelay *triggerDelay)

Set the specified trigger delay settings to the camera.

FLYCAPTURE2_C_API fc2Error fc2SetTriggerDelayBroadcast (fc2Context context, fc2TriggerDelay *triggerDelay)

Set the specified trigger delay settings to the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetStrobeInfo (fc2Context context, fc2-StrobeInfo *strobeInfo)

Retrieve strobe information from the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetStrobe (fc2Context context, fc2Strobe-Control *strobeControl)

Retrieve current strobe settings from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetStrobe (fc2Context context, fc2Strobe-Control *strobeControl)

Set current strobe settings to the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetStrobeBroadcast (fc2Context context, fc2StrobeControl *strobeControl)

Set current strobe settings to the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetVideoModeAndFrameRateInfo (fc2-Context context, fc2VideoMode videoMode, fc2FrameRate frameRate, BOOL *pSupported)

Query the camera to determine if the specified video mode and frame rate is supported.

 FLYCAPTURE2_C_API fc2Error fc2GetVideoModeAndFrameRate (fc2Context context, fc2VideoMode *videoMode, fc2FrameRate *frameRate)

Get the current video mode and frame rate from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetVideoModeAndFrameRate (fc2Context context, fc2VideoMode videoMode, fc2FrameRate frameRate)

Set the specified video mode and frame rate to the camera.

 FLYCAPTURE2_C_API fc2Error fc2GetFormat7Info (fc2Context context, fc2-Format7Info *info, BOOL *pSupported)

Retrieve the availability of Format7 custom image mode and the camera capabilities for the specified Format7 mode.

FLYCAPTURE2_C_API fc2Error fc2ValidateFormat7Settings (fc2Context context, fc2Format7ImageSettings *imageSettings, BOOL *settingsAreValid, fc2Format7PacketInfo *packetInfo)

Validates Format7ImageSettings structure and returns valid packet size information if the image settings are valid.

FLYCAPTURE2_C_API fc2Error fc2GetFormat7Configuration (fc2Context context, fc2Format7ImageSettings *imageSettings, unsigned int *packetSize, float *percentage)

Get the current Format7 configuration from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SetFormat7ConfigurationPacket (fc2Context context, fc2Format7ImageSettings *imageSettings, unsigned int packetSize)

Set the current Format7 configuration to the camera.

FLYCAPTURE2_C_API fc2Error fc2SetFormat7Configuration (fc2Context context, fc2Format7ImageSettings *imageSettings, float percentSpeed)

Set the current Format7 configuration to the camera.

FLYCAPTURE2_C_API fc2Error fc2WriteGVCPRegister (fc2Context context, unsigned int address, unsigned int value)

Write a GVCP register.

42

• FLYCAPTURE2_C_API fc2Error fc2WriteGVCPRegisterBroadcast (fc2Context context, unsigned int address, unsigned int value)

Write a GVCP register with broadcast.

FLYCAPTURE2_C_API fc2Error fc2ReadGVCPRegister (fc2Context context, unsigned int address, unsigned int *pValue)

Read a GVCP register.

FLYCAPTURE2_C_API fc2Error fc2WriteGVCPRegisterBlock (fc2Context context, unsigned int address, const unsigned int *pBuffer, unsigned int length)

Write a GVCP register block.

• FLYCAPTURE2_C_API fc2Error fc2ReadGVCPRegisterBlock (fc2Context context, unsigned int address, unsigned int *pBuffer, unsigned int length)

Read a GVCP register block.

FLYCAPTURE2_C_API fc2Error fc2WriteGVCPMemory (fc2Context context, unsigned int address, const unsigned char *pBuffer, unsigned int length)

Write a GVCP memory block.

FLYCAPTURE2_C_API fc2Error fc2ReadGVCPMemory (fc2Context context, unsigned int address, unsigned char *pBuffer, unsigned int length)

Read a GVCP memory block.

FLYCAPTURE2_C_API fc2Error fc2GetGigEProperty (fc2Context context, fc2-GigEProperty *pGigEProp)

Get the specified GigEProperty.

 FLYCAPTURE2_C_API fc2Error fc2SetGigEProperty (fc2Context context, const fc2GigEProperty *pGigEProp)

Set the specified GigEProperty.

- FLYCAPTURE2_C_API fc2Error fc2QueryGigEImagingMode (fc2Context context, fc2Mode mode, BOOL *isSupported)
- FLYCAPTURE2_C_API fc2Error fc2GetGigEImagingMode (fc2Context context, fc2Mode *mode)
- FLYCAPTURE2_C_API fc2Error fc2SetGigEImagingMode (fc2Context context, fc2Mode mode)
- FLYCAPTURE2_C_API fc2Error fc2GetGigEImageSettingsInfo (fc2Context context, fc2GigEImageSettingsInfo *pInfo)
- FLYCAPTURE2_C_API fc2Error fc2GetGigEImageSettings (fc2Context context, fc2GigEImageSettings *pImageSettings)
- FLYCAPTURE2_C_API fc2Error fc2SetGigEImageSettings (fc2Context context, const fc2GigEImageSettings *pImageSettings)
- FLYCAPTURE2_C_API fc2Error fc2GetGigEConfig (fc2Context context, fc2Gig-EConfig *pConfig)
- FLYCAPTURE2_C_API fc2Error fc2SetGigEConfig (fc2Context context, const fc2GigEConfig *pConfig)
- FLYCAPTURE2_C_API fc2Error fc2GetGigEImageBinningSettings (fc2Context context, unsigned int *horzBinnningValue, unsigned int *vertBinnningValue)

- FLYCAPTURE2_C_API fc2Error fc2SetGigEImageBinningSettings (fc2Context context, unsigned int horzBinnningValue, unsigned int vertBinnningValue)
- FLYCAPTURE2_C_API fc2Error fc2GetNumStreamChannels (fc2Context context, unsigned int *numChannels)
- FLYCAPTURE2_C_API fc2Error fc2GetGigEStreamChannelInfo (fc2Context context, unsigned int channel, fc2GigEStreamChannel *pChannel)
- FLYCAPTURE2_C_API fc2Error fc2SetGigEStreamChannelInfo (fc2Context context, unsigned int channel, fc2GigEStreamChannel *pChannel)
- FLYCAPTURE2_C_API fc2Error fc2GetLUTInfo (fc2Context context, fc2LUT-Data *pData)

Query if LUT support is available on the camera.

FLYCAPTURE2_C_API fc2Error fc2GetLUTBankInfo (fc2Context context, unsigned int bank, BOOL *pReadSupported, BOOL *pWriteSupported)

Query the read/write status of a single LUT bank.

FLYCAPTURE2_C_API fc2Error fc2GetActiveLUTBank (fc2Context context, unsigned int *pActiveBank)

Get the LUT bank that is currently being used.

FLYCAPTURE2_C_API fc2Error fc2SetActiveLUTBank (fc2Context context, unsigned int activeBank)

Set the LUT bank that will be used.

- FLYCAPTURE2_C_API fc2Error fc2EnableLUT (fc2Context context, BOOL on)

 Enable or disable LUT functionality on the camera.
- FLYCAPTURE2_C_API fc2Error fc2GetLUTChannel (fc2Context context, unsigned int bank, unsigned int channel, unsigned int sizeEntries, unsigned int *p-Entries)

Get the LUT channel settings from the camera.

FLYCAPTURE2_C_API fc2Error fc2SetLUTChannel (fc2Context context, unsigned int bank, unsigned int channel, unsigned int sizeEntries, unsigned int *p-Entries)

Set the LUT channel settings to the camera.

FLYCAPTURE2_C_API fc2Error fc2GetMemoryChannel (fc2Context context, unsigned int *pCurrentChannel)

Retrieve the current memory channel from the camera.

 FLYCAPTURE2_C_API fc2Error fc2SaveToMemoryChannel (fc2Context context, unsigned int channel)

Save the current settings to the specfied current memory channel.

 FLYCAPTURE2_C_API fc2Error fc2RestoreFromMemoryChannel (fc2Context context, unsigned int channel)

Restore the specfied current memory channel.

• FLYCAPTURE2_C_API fc2Error fc2GetMemoryChannelInfo (fc2Context context, unsigned int *pNumChannels)

Query the camera for memory channel support.

FLYCAPTURE2_C_API fc2Error fc2GetEmbeddedImageInfo (fc2Context context, fc2EmbeddedImageInfo *pInfo)

Get the current status of the embedded image information register, as well as the availability of each embedded property.

FLYCAPTURE2_C_API fc2Error fc2SetEmbeddedImageInfo (fc2Context context, fc2EmbeddedImageInfo *pInfo)

Sets the on/off values of the embedded image information structure to the camera.

 FLYCAPTURE2_C_API const char * fc2GetRegisterString (unsigned int register-Val)

Returns a text representation of the register value.

- FLYCAPTURE2_C_API fc2Error fc2CreateImage (fc2Image *pImage)
 Create a fc2Image.
- FLYCAPTURE2_C_API fc2Error fc2DestroyImage (fc2Image *image)
 Destroy the fc2Image.
- FLYCAPTURE2_C_API fc2Error fc2SetDefaultColorProcessing (fc2Color-ProcessingAlgorithm defaultMethod)

Set the default color processing algorithm.

 FLYCAPTURE2_C_API fc2Error fc2GetDefaultColorProcessing (fc2Color-ProcessingAlgorithm *pDefaultMethod)

Get the default color processing algorithm.

FLYCAPTURE2_C_API fc2Error fc2SetDefaultOutputFormat (fc2PixelFormat format)

Set the default output pixel format.

FLYCAPTURE2_C_API fc2Error fc2GetDefaultOutputFormat (fc2PixelFormat *pFormat)

Get the default output pixel format.

FLYCAPTURE2_C_API fc2Error fc2DetermineBitsPerPixel (fc2PixelFormat format, unsigned int *pBitsPerPixel)

Calculate the bits per pixel for the specified pixel format.

 FLYCAPTURE2_C_API fc2Error fc2SaveImage (fc2Image *pImage, const char *pFilename, fc2ImageFileFormat format)

Save the image to the specified file name with the file format specified.

FLYCAPTURE2_C_API fc2Error fc2SaveImageWithOption (fc2Image *pImage, const char *pFilename, fc2ImageFileFormat format, void *pOption)

Save the image to the specified file name with the file format specified.

- FLYCAPTURE2_C_API fc2Error fc2ConvertImage (fc2Image *pImageIn, fc2-Image *pImageOut)
- FLYCAPTURE2_C_API fc2Error fc2ConvertImageTo (fc2PixelFormat format, fc2Image *pImageIn, fc2Image *pImageOut)

Converts the current image buffer to the specified output format and stores the result in the specified image.

FLYCAPTURE2_C_API fc2Error fc2GetImageData (fc2Image *pImage, unsigned char **ppData)

Get a pointer to the data associated with the image.

• FLYCAPTURE2_C_API fc2Error fc2SetImageData (fc2Image *pImage, const unsigned char *pData, unsigned int dataSize)

Set the data of the Image object.

FLYCAPTURE2_C_API fc2Error fc2SetImageDimensions (fc2Image *pImage, unsigned int rows, unsigned int cols, unsigned int stride, fc2PixelFormat pixelFormat, fc2BayerTileFormat bayerFormat)

Sets the dimensions of the image object.

FLYCAPTURE2_C_API fc2TimeStamp fc2GetImageTimeStamp (fc2Image *p-Image)

Get the timestamp data associated with the image.

FLYCAPTURE2_C_API fc2Error fc2CalculateImageStatistics (fc2Image *p-Image, fc2ImageStatisticsContext *pImageStatisticsContext)

Calculate statistics associated with the image.

 FLYCAPTURE2_C_API fc2Error fc2CreateImageStatistics (fc2ImageStatistics-Context *pImageStatisticsContext)

Create a statistics context.

 FLYCAPTURE2_C_API fc2Error fc2DestroyImageStatistics (fc2ImageStatistics-Context imageStatisticsContext)

Destroy a statistics context.

 FLYCAPTURE2_C_API fc2Error fc2GetImageStatistics (fc2ImageStatistics-Context imageStatisticsContext, fc2StatisticsChannel channel, unsigned int *p-RangeMin, unsigned int *pRangeMax, unsigned int *pPixelValueMin, unsigned int *pPixelValueMax, unsigned int *pNumPixelValues, float *pPixelValueMean, int **ppHistogram)

Get all statistics for the image.

- FLYCAPTURE2_C_API fc2Error fc2CreateAVI (fc2AVIContext *pAVIContext)
 Create a AVI context.
- FLYCAPTURE2_C_API fc2Error fc2AVIOpen (fc2AVIContext AVIContext, const char *pFileName, fc2AVIOption *pOption)

Open an AVI file in preparation for writing Images to disk.

 FLYCAPTURE2_C_API fc2Error fc2MJPGOpen (fc2AVIContext AVIContext, const char *pFileName, fc2MJPGOption *pOption)

Open an MJPEG file in preparation for writing Images to disk.

• FLYCAPTURE2_C_API fc2Error fc2H264Open (fc2AVIContext AVIContext, const char *pFileName, fc2H264Option *pOption)

Open an H.264 file in preparation for writing Images to disk.

 FLYCAPTURE2_C_API fc2Error fc2AVIAppend (fc2AVIContext AVIContext, fc2-Image *pImage)

Append an image to the AVI file.

- FLYCAPTURE2_C_API fc2Error fc2AVIClose (fc2AVIContext AVIContext)
 Close the AVI file.
- FLYCAPTURE2_C_API fc2Error fc2DestroyAVI (fc2AVIContext AVIContext)
 Destroy a AVI context.
- FLYCAPTURE2_C_API fc2Error fc2GetSystemInfo (fc2SystemInfo *pSystemInfo)

Get system information.

- FLYCAPTURE2_C_API fc2Error fc2GetLibraryVersion (fc2Version *pVersion)
 Get library version.
- FLYCAPTURE2_C_API fc2Error fc2LaunchBrowser (const char *pAddress)

 Launch a URL in the system default browser.
- FLYCAPTURE2 C API fc2Error fc2LaunchHelp (const char *pFileName)

Open a CHM file in the system default CHM viewer.

 FLYCAPTURE2_C_API fc2Error fc2LaunchCommand (const char *p-Command)

Execute a command in the terminal.

• FLYCAPTURE2_C_API fc2Error fc2LaunchCommandAsync (const char *p-Command, fc2AsyncCommandCallback pCallback, void *pUserData)

Execute a command in the terminal.

- FLYCAPTURE2_C_API const char * fc2ErrorToDescription (fc2Error error)

 Get a string representation of an error.
- FLYCAPTURE2_C_API fc2Error fc2GetCycleTime (fc2Context context, fc2Time-Stamp *pTimeStamp)

Get cycle time from camera.

4.1.1 Function Documentation

4.1.1.1 FLYCAPTURE2_C_API fc2Error fc2AVIAppend (fc2AVIContext AVIContext, fc2Image * plmage)

Append an image to the AVI file.

Parameters

AVIContext	The AVI context to use.
plmage	The image to append.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.2 FLYCAPTURE2_C_API fc2Error fc2AVIClose (fc2AVIContext AVIContext)

Close the AVI file.

Parameters

AVIContext	The AVI context to use.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.3 FLYCAPTURE2_C_API fc2Error fc2AVIOpen (fc2AVIContext AVIContext, const char * pFileName, fc2AVIOption * pOption)

Open an AVI file in preparation for writing Images to disk.

The size of AVI files is limited to 2GB. The filenames are automatically generated using the filename specified.

Parameters

ĺ	AVIContext	The AVI context to use.
	pFileName	The filename of the AVI file.
Ī	pOption	Options to apply to the AVI file.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.4 FLYCAPTURE2_C_API fc2Error fc2CalculateImageStatistics (fc2Image * pImage, fc2ImageStatisticsContext * pImageStatisticsContext)

Calculate statistics associated with the image.

In order to collect statistics for a particular channel, the enabled flag for the channel must be set to true. Statistics can only be collected for images in Mono8, Mono16, RGB, RGBU, BGR and BGRU.

Parameters

plmage	The fc2Image to be used.
plmage-	The fc2ImageStatisticsContext to hold the statistics.
Statistics-	
Context	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.5 FLYCAPTURE2_C_API fc2Error fc2Connect (fc2Context context, fc2PGRGuid * guid)

Connects the camera object to the camera specified by the GUID.

Parameters

con	text	The fc2Context to be used.
g	guid	The unique identifier for a specific camera on the PC.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.6 FLYCAPTURE2_C_API fc2Error fc2ConvertImage (fc2Image * pImageIn, fc2Image * pImageOut)

Parameters

plmageIn	
plmageOut	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.7 FLYCAPTURE2_C_API fc2Error fc2ConvertImageTo (fc2PixelFormat format, fc2Image * plmageOut)

Converts the current image buffer to the specified output format and stores the result in the specified image.

The destination image does not need to be configured in any way before the call is made.

Parameters

format	Output format of the converted image.
plmageIn	Input image.
plmageOut	Output image.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.8 FLYCAPTURE2_C_API fc2Error fc2CreateAVI (fc2AVIContext * pAVIContext)

Create a AVI context.

Parameters

pAVIContext	A AVI context.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.9 FLYCAPTURE2_C_API fc2Error fc2CreateContext (fc2Context * pContext)

Create a FC2 context for IIDC camaera.

This call must be made before any other calls that use a context will succeed.

Parameters

pContext	A pointer to the fc2Context to be created.
----------	--

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.10 FLYCAPTURE2_C_API fc2Error fc2CreateGigEContext (fc2Context * pContext)

Create a FC2 context for a GigE Vision camera.

This call must be made before any other calls that use a context will succeed.

Parameters

```
pContext | A pointer to the fc2Context to be created.
```

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.11 FLYCAPTURE2_C_API fc2Error fc2CreateImage (fc2Image * plmage)

Create a fc2Image.

If externally allocated memory is to be used for the converted image, simply assigning the pData member of the fc2Image structure is insufficient. fc2SetImageData() should be called in order to populate the fc2Image structure correctly.

Parameters

,	D:: : : : : : : : : : : : : : : : : : :
l nimage	Pointer to image to be created.
piinago	1 onto to image to be created.

See also

fc2SetImageData()

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.12 FLYCAPTURE2_C_API fc2Error fc2CreateImageStatistics (fc2ImageStatisticsContext * plmageStatisticsContext)

Create a statistics context.

Parameters

plmage-	A statistics context.
Statistics-	
Context	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.13 FLYCAPTURE2_C_API fc2Error fc2DestroyAVI (fc2AVIContext AVIContext)

Destroy a AVI context.

Parameters

AVIContext	A AVI context.
------------	----------------

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.14 FLYCAPTURE2_C_API fc2Error fc2DestroyContext (fc2Context context)

Destroy the FC2 context.

This must be called when the user is finished with the context in order to prevent memory leaks.

Parameters

context	The context to be destroyed.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.15 FLYCAPTURE2_C_API fc2Error fc2DestroyImage (fc2Image * image)

Destroy the fc2Image.

Parameters

image	Pointer to image to be destroyed.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.16 FLYCAPTURE2_C_API fc2Error fc2DestroyImageStatistics (fc2ImageStatisticsContext imageStatisticsContext)

Destroy a statistics context.

Parameters

image-	A statistics context.
Statistics-	
Context	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.17 FLYCAPTURE2_C_API fc2Error fc2DetermineBitsPerPixel (fc2PixelFormat format, unsigned int * pBitsPerPixel)

Calculate the bits per pixel for the specified pixel format.

Parameters

format	The pixel format.
pBitsPer-	The bits per pixel.
Pixel	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.18 FLYCAPTURE2_C_API fc2Error fc2Disconnect (fc2Context context)

Disconnects the fc2Context from the camera.

Parameters

context	The fc2Context to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.19 FLYCAPTURE2_C_API fc2Error fc2DiscoverGigECameras (fc2Context context, fc2CameraInfo * gigECameras, unsigned int * arraySize)

Discover all cameras connected to the network even if they reside on a different subnet.

This is useful in situations where a GigE camera is using Persistent IP and the application's subnet is different from the device subnet. After discovering the camera, it is easy to use ForceIPAddressToCamera() to set a different IP configuration.

Parameters

	context	The fc2Context to be used.
	gigE-	Pointer to an array of CameraInfo structures.
	Cameras	
Ī	arraySize	Size of the array. Number of discovered cameras is returned in the
		same value.

Returns

An Error indicating the success or failure of the function. If the error is PGRERR-OR_BUFFER_TOO_SMALL then arraySize will contain the minimum size needed for gigECameras array.

4.1.1.20 FLYCAPTURE2_C_API fc2Error fc2EnableLUT (fc2Context context, BOOL on)

Enable or disable LUT functionality on the camera.

Parameters

context	The fc2Context to be used.
on	Whether to enable or disable LUT.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.21 FLYCAPTURE2_C_API const char* fc2ErrorToDescription (fc2Error error)

Get a string representation of an error.

Parameters

error	Error to be parsed.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.22 FLYCAPTURE2_C_API fc2Error fc2FireBusReset (fc2Context context, fc2PGRGuid * pGuid)

Fire a bus reset.

The actual bus reset is only fired for the specified 1394 bus, but it will effectively cause a global bus reset for the library.

Parameters

context	The fc2Context to be used.
pGuid	PGRGuid of the camera or the device to cause bus reset.

Returns

An Error indicating the success or failure of the function.

4.1.1.23 FLYCAPTURE2_C_API fc2Error fc2FireSoftwareTrigger (fc2Context context)

Parameters

context	The fc2Context to be used.
---------	----------------------------

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.24 FLYCAPTURE2_C_API fc2Error fc2FireSoftwareTriggerBroadcast (fc2Context context)

Fire the software trigger according to the DCAM specifications.

Parameters

context	The fc2Context to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.25 FLYCAPTURE2_C_API fc2Error fc2ForceAllIPAddressesAutomatically ()

Force all cameras on the network to be assigned sequential IP addresses on the same subnet as the netowrk adapters that they are connected to.

This is useful in situations where a GigE Vision cameras are using Persistent IP addresses and the application's subnet is different from the devices.

An Error indicating the success or failure of the function.

4.1.1.26 FLYCAPTURE2_C_API fc2Error fc2ForcelPAddressAutomatically (unsigned int serialNumber)

Force a cameras on the network to be assigned sequential IP addresses on the same subnet as the netowrk adapters that it is connected to.

This is useful in situations where a GigE Vision cameras is using Persistent IP addresses and the application's subnet is different from the device.

Returns

An Error indicating the success or failure of the function.

4.1.1.27 FLYCAPTURE2_C_API fc2Error fc2ForcelPAddressToCamera (fc2Context context, fc2MACAddress macAddress, fc2IPAddress ipAddress, fc2IPAddress subnetMask, fc2IPAddress defaultGateway)

Force the camera with the specific MAC address to the specified IP address, subnet mask and default gateway.

This is useful in situations where a GigE Vision camera is using Persistent IP and the application's subnet is different from the device subnet.

Parameters

context	The fc2Context to be used.
macAddress	MAC address of the camera.
ipAddress	IP address to set on the camera.
subnetMask	Subnet mask to set on the camera.
default-	Default gateway to set on the camera.
Gateway	

Returns

An Error indicating the success or failure of the function.

4.1.1.28 FLYCAPTURE2_C_API fc2Error fc2GetActiveLUTBank (fc2Context context, unsigned int * pActiveBank)

Get the LUT bank that is currently being used.

For cameras with PGR LUT, the active bank is always 0.

Parameters

context	The fc2Context to be used.
pActiveBank	The currently active bank.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.29 FLYCAPTURE2_C_API fc2Error fc2GetCameraFromIndex (fc2Context context, unsigned int index, fc2PGRGuid * pGuid)

Gets the PGRGuid for a camera on the PC.

It uniquely identifies the camera specified by the index and is used to identify the camera during a fc2Connect() call.

Parameters

context	The fc2Context to be used.
index	Zero based index of camera.
pGuid	Unique PGRGuid for the camera.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.30 FLYCAPTURE2_C_API fc2Error fc2GetCameraFromSerialNumber (fc2Context context, unsigned int serialNumber, fc2PGRGuid * pGuid)

Gets the PGRGuid for a camera on the PC.

It uniquely identifies the camera specified by the serial number and is used to identify the camera during a fc2Connect() call.

Parameters

context	The fc2Context to be used.
serial-	Serial number of camera.
Number	
pGuid	Unique PGRGuid for the camera.

Returns

4.1.1.31 FLYCAPTURE2_C_API fc2Error fc2GetCameraInfo (fc2Context context, fc2CameraInfo * pCameraInfo)

Retrieves information from the camera such as serial number, model name and other camera information.

Parameters

context	The fc2Context to be used.
pCameraInfo	Pointer to the camera information structure to be filled.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.32 FLYCAPTURE2_C_API fc2Error fc2GetCameraSerialNumberFromIndex (fc2Context context, unsigned int index, unsigned int * pSerialNumber)

Gets the serial number of the camera with the specified index.

Parameters

context	The fc2Context to be used.
index	Zero based index of desired camera.
pSerial-	Serial number of camera.
Number	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.33 FLYCAPTURE2_C_API fc2Error fc2GetConfiguration (fc2Context context, fc2Config * config)

Get the configuration associated with the camera.

Parameters

context	The fc2Context to be used.
config	Pointer to the configuration structure to be filled.

Returns

4.1.1.34 FLYCAPTURE2_C_API fc2Error fc2GetCycleTime (fc2Context context, fc2TimeStamp * pTimeStamp)

Get cycle time from camera.

Parameters

Timestamp	struct.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.35 FLYCAPTURE2_C_API fc2Error fc2GetDefaultColorProcessing (fc2ColorProcessingAlgorithm * pDefaultMethod)

Get the default color processing algorithm.

Parameters

pDefault-	The default color processing algorithm.
Method	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.36 FLYCAPTURE2_C_API fc2Error fc2GetDefaultOutputFormat (fc2PixelFormat * pFormat)

Get the default output pixel format.

Parameters

pFormat	The default pixel format.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.37 FLYCAPTURE2_C_API fc2Error fc2GetDeviceFromIndex (fc2Context context, unsigned int index, fc2PGRGuid * pGuid)

Gets the PGRGuid for a device.

It uniquely identifies the device specified by the index.

Parameters

context	The fc2Context to be used.
index	Zero based index of device.
pGuid	Unique PGRGuid for the device.

See also

fc2GetNumOfDevices()

Returns

An Error indicating the success or failure of the function.

4.1.1.38 FLYCAPTURE2_C_API fc2Error fc2GetEmbeddedImageInfo (fc2Context context, fc2EmbeddedImageInfo * pInfo)

Get the current status of the embedded image information register, as well as the availability of each embedded property.

Parameters

conte	t The fc2Context to be used.	
plr	Structure to be filled.	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.39 FLYCAPTURE2_C_API fc2Error fc2GetFormat7Configuration (fc2Context context, fc2Format7ImageSettings * imageSettings, unsigned int * packetSize, float * percentage)

Get the current Format7 configuration from the camera.

This call will only succeed if the camera is already in Format7.

context	The fc2Context to be used.
image-	Current image settings.
Settings	
packetSize	Current packet size.
percentage	Current packet size as a percentage.

A fc2Error indicating the success or failure of the function.

4.1.1.40 FLYCAPTURE2_C_API fc2Error fc2GetFormat7Info (fc2Context context, fc2Format7Info * info, BOOL * pSupported)

Retrieve the availability of Format7 custom image mode and the camera capabilities for the specified Format7 mode.

The mode must be specified in the Format7Info structure in order for the function to succeed.

Parameters

	context	The fc2Context to be used.
	info	Structure to be filled with the capabilities of the specified mode and the
		current state in the specified mode.
Ī	pSupported	Whether the specified mode is supported.

Returns

A fc2Error indicating the success or failure of the function.

- 4.1.1.41 FLYCAPTURE2_C_API fc2Error fc2GetGigEConfig (fc2Context context, fc2GigEConfig * pConfig)
- 4.1.1.42 FLYCAPTURE2_C_API fc2Error fc2GetGigEImageBinningSettings (fc2Context context, unsigned int * horzBinnningValue, unsigned int * vertBinnningValue)
- 4.1.1.43 FLYCAPTURE2_C_API fc2Error fc2GetGigEImageSettings (fc2Context context, fc2GigEImageSettings * plmageSettings)
- 4.1.1.44 FLYCAPTURE2_C_API fc2Error fc2GetGigEImageSettingsInfo (fc2Context context, fc2GigEImageSettingsInfo * plnfo)
- 4.1.1.45 FLYCAPTURE2_C_API fc2Error fc2GetGigEImagingMode (fc2Context context, fc2Mode \ast mode)
- 4.1.1.46 FLYCAPTURE2_C_API fc2Error fc2GetGigEProperty (fc2Context context, fc2GigEProperty * pGigEProp)

Get the specified GigEProperty.

The GigEPropertyType field must be set in order for this function to succeed.

Parameters

context	The fc2Context to be used.
pGigEProp	The GigE property to get.

Generated on Sat Feb 9 2013 05:06:35 for FlyCapture2 C by Doxygen

An Error indicating the success or failure of the function.

- 4.1.1.47 FLYCAPTURE2_C_API fc2Error fc2GetGigEStreamChannelInfo (fc2Context context, unsigned int channel, fc2GigEStreamChannel * pChannel)
- 4.1.1.48 FLYCAPTURE2_C_API fc2Error fc2GetGPIOPinDirection (fc2Context context, unsigned int pin, unsigned int * pDirection)

Get the GPIO pin direction for the specified pin.

This is not a required call when using the trigger or strobe functions as the pin direction is set automatically internally.

Parameters

context	The fc2Context to be used.
pin	Pin to get the direction for.
pDirection	Direction of the pin. 0 for input, 1 for output.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.49 FLYCAPTURE2_C_API fc2Error fc2GetImageData (fc2Image * pImage, unsigned char ** ppData)

Get a pointer to the data associated with the image.

This function is considered unsafe. The pointer returned could be invalidated if the buffer is resized or released. The pointer may also be invalidated if the Image object is passed to fc2RetrieveBuffer().

plmage	The fc2Image to be used.
ppData	A pointer to the image data.

A fc2Error indicating the success or failure of the function.

4.1.1.50 FLYCAPTURE2_C_API fc2Error fc2GetImageStatistics (fc2ImageStatistics-Context imageStatisticsContext, fc2StatisticsChannel channel, unsigned int * pRangeMin, unsigned int * pRangeMax, unsigned int * pPixelValueMin, unsigned int * pPixelValueMax, unsigned int * pNumPixelValues, float * pPixelValueMean, int ** ppHistogram)

Get all statistics for the image.

Parameters

image-	The statistics context.
Statistics-	
Context	
channel	The statistics channel.
pRangeMin	The minimum possible value.
pRangeMax	The maximum possible value.
pPixelValue-	The minimum pixel value.
Min	
pPixelValue-	The maximum pixel value.
Max	
pNumPixel-	The number of unique pixel values.
Values	
pPixelValue-	The mean of the image.
Mean	
ppHistogram	Pointer to an array containing the histogram.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.51 FLYCAPTURE2_C_API fc2TimeStamp fc2GetImageTimeStamp (fc2Image * pImage)

Get the timestamp data associated with the image.

Parameters

plmage The fc2Image to be used.

Returns

Timestamp data associated with the image.

4.1.1.52 FLYCAPTURE2_C_API fc2Error fc2GetInterfaceTypeFromGuid (fc2Context context, fc2PGRGuid * pGuid, fc2InterfaceType * pInterfaceType)

Gets the interface type associated with a PGRGuid.

This is useful in situations where there is a need to enumerate all cameras for a particular interface.

Parameters

cont	ext	The fc2Context to be used.
pG	uid	The PGRGuid to get the interface for.
pInterfa	ce-	The interface type of the PGRGuid.
Ty	ре	

Returns

4.1.1.53 FLYCAPTURE2_C_API fc2Error fc2GetLibraryVersion (fc2Version * pVersion)

Get library version.

Parameters

|--|

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.54 FLYCAPTURE2_C_API fc2Error fc2GetLUTBankInfo (fc2Context context, unsigned int bank, BOOL * pReadSupported, BOOL * pWriteSupported)

Query the read/write status of a single LUT bank.

context	The fc2Context to be used.
bank	The bank to query.
pRead-	Whether reading from the bank is supported.
Supported	
pWrite-	Whether writing to the bank is supported.
Supported	

A fc2Error indicating the success or failure of the function.

4.1.1.55 FLYCAPTURE2_C_API fc2Error fc2GetLUTChannel (fc2Context context, unsigned int bank, unsigned int channel, unsigned int sizeEntries, unsigned int * pEntries*)

Get the LUT channel settings from the camera.

Parameters

context	The fc2Context to be used.
bank	Bank to retrieve.
channel	Channel to retrieve.
sizeEntries	Number of entries in LUT table to read.
pEntries	Array to store LUT entries.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.56 FLYCAPTURE2_C_API fc2Error fc2GetLUTInfo (fc2Context context, fc2LUTData * pData)

Query if LUT support is available on the camera.

Note that some cameras may report support for the LUT and return an inputBitDepth of 0. In these cases use log2(numEntries) for the inputBitDepth.

Parameters

contex	The fc2Context to be used.
pData	The LUT structure to be filled.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.57 FLYCAPTURE2_C_API fc2Error fc2GetMemoryChannel (fc2Context context, unsigned int * pCurrentChannel)

Retrieve the current memory channel from the camera.

Parameters

context	The fc2Context to be used.
pCurrent-	Current memory channel.
Channel	

Generated on Sat Feb 9 2013 05:06:35 for FlyCapture2 C by Doxygen

File Documentation

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.58 FLYCAPTURE2_C_API fc2Error fc2GetMemoryChannelInfo (fc2Context context, unsigned int * pNumChannels)

Query the camera for memory channel support.

If the number of channels is 0, then memory channel support is not available.

Parameters

context	The fc2Context to be used.
pNum-	Number of memory channels supported.
Channels	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.59 FLYCAPTURE2_C_API fc2Error fc2GetNumOfCameras (fc2Context context, unsigned int * pNumCameras)

Gets the number of cameras attached to the PC.

Parameters

context	The fc2Context to be used.
pNum-	Number of cameras detected.
Cameras	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.60 FLYCAPTURE2_C_API fc2Error fc2GetNumOfDevices (fc2Context context, unsigned int * pNumDevices)

Gets the number of devices.

This may include hubs, host controllers and other hardware devices (including cameras).

context	The fc2Context to be used.
pNum-	The number of devices found.
Devices	

An Error indicating the success or failure of the function.

- 4.1.1.61 FLYCAPTURE2_C_API fc2Error fc2GetNumStreamChannels (fc2Context context, unsigned int * numChannels)
- 4.1.1.62 FLYCAPTURE2_C_API fc2Error fc2GetProperty (fc2Context context, fc2Property * prop)

Reads the settings for the specified property from the camera.

The property type must be specified in the fc2Property structure passed into the function in order for the function to succeed. If auto is on, the integer and abs values returned may not be consistent with each other.

Parameters

context	The fc2Context to be used.
prop	Pointer to the Property structure to be filled.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.63 FLYCAPTURE2_C_API fc2Error fc2GetPropertyInfo (fc2Context context, fc2PropertyInfo * propInfo)

Retrieves information about the specified camera property.

The property type must be specified in the fc2PropertyInfo structure passed into the function in order for the function to succeed.

Parameters

context	The fc2Context to be used.
propInfo	Pointer to the PropertyInfo structure to be filled.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.64 FLYCAPTURE2_C_API const char* fc2GetRegisterString (unsigned int registerVal)

Returns a text representation of the register value.

Parameters

registerVal The register val	ue to query.
------------------------------	--------------

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.65 FLYCAPTURE2_C_API fc2Error fc2GetStrobe (fc2Context context, fc2StrobeControl * strobeControl)

Retrieve current strobe settings from the camera.

The strobe pin must be specified in the structure before being passed in to the function.

Parameters

context	The fc2Context to be used.
strobe-	Structure to receive strobe settings.
Control	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.66 FLYCAPTURE2_C_API fc2Error fc2GetStrobelnfo (fc2Context context, fc2Strobelnfo * strobelnfo)

Retrieve strobe information from the camera.

Parameters

	context	The fc2Context to be used.
ĺ	strobelnfo	Structure to receive strobe information.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.67 FLYCAPTURE2_C_API fc2Error fc2GetSystemInfo (fc2SystemInfo * pSystemInfo)

Get system information.

pSystemInfo	Structure to receive system information.

A fc2Error indicating the success or failure of the function.

4.1.1.68 FLYCAPTURE2_C_API fc2Error fc2GetTriggerDelay (fc2Context context, fc2TriggerDelay * triggerDelay)

Retrieve current trigger delay settings from the camera.

Parameters

ĺ	context	The fc2Context to be used.
	triggerDelay	Structure to receive trigger delay settings.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.69 FLYCAPTURE2_C_API fc2Error fc2GetTriggerDelayInfo (fc2Context context, fc2TriggerDelayInfo * triggerDelayInfo)

Retrieve trigger delay information from the camera.

Parameters

context	The fc2Context to be used.
triggerDelay-	Structure to receive trigger delay information.
Info	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.70 FLYCAPTURE2_C_API fc2Error fc2GetTriggerMode (fc2Context context, fc2TriggerMode * triggerMode)

Retrieve current trigger settings from the camera.

Parameters

context	The fc2Context to be used.
triggerMode	Structure to receive trigger mode settings.

Returns

4.1.1.71 FLYCAPTURE2_C_API fc2Error fc2GetTriggerModeInfo (fc2Context context, fc2TriggerModeInfo * triggerModeInfo)

Retrieve trigger information from the camera.

Parameters

context	The fc2Context to be used.
triggerMode-	Structure to receive trigger information.
Info	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.72 FLYCAPTURE2_C_API fc2Error fc2GetVideoModeAndFrameRate (fc2Context context, fc2VideoMode * videoMode, fc2FrameRate * frameRate)

Get the current video mode and frame rate from the camera.

If the camera is in Format7, the video mode will be VIDEOMODE_FORMAT7 and the frame rate will be FRAMERATE_FORMAT7.

Parameters

context	The fc2Context to be used.
videoMode	Current video mode.
frameRate	Current frame rate.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.73 FLYCAPTURE2_C_API fc2Error fc2GetVideoModeAndFrameRateInfo (fc2Context context, fc2VideoMode videoMode, fc2FrameRate frameRate, BOOL * pSupported)

Query the camera to determine if the specified video mode and frame rate is supported.

	context	The fc2Context to be used.
	videoMode	Video mode to check.
	frameRate	Frame rate to check.
Ì	pSupported	Whether the video mode and frame rate is supported.

A fc2Error indicating the success or failure of the function.

4.1.1.74 FLYCAPTURE2_C_API fc2Error fc2H264Open (fc2AVIContext AVIContext, const char * pFileName, fc2H264Option * pOption)

Open an H.264 file in preparation for writing Images to disk.

The size of AVI files is limited to 2GB. The filenames are automatically generated using the filename specified.

Parameters

AVIContext	The AVI context to use.
pFileName	The filename of the AVI file.
pOption	Options to apply to the AVI file.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.75 FLYCAPTURE2_C_API fc2Error fc2IsCameraControlable (fc2Context context, fc2PGRGuid * pGuid, BOOL * pControlable)

Query whether a GigE camera is controlable.

Parameters

context	The fc2Context to be used.
pGuid	Unique PGRGuid for the camera.
pControlable	True indicates camera is controllable

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.76 FLYCAPTURE2_C_API fc2Error fc2LaunchBrowser (const char * pAddress)

Launch a URL in the system default browser.

pAddress	URL to open in browser.

A fc2Error indicating the success or failure of the function.

4.1.1.77 FLYCAPTURE2_C_API fc2Error fc2LaunchCommand (const char * pCommand)

Execute a command in the terminal.

This is a blocking call that will return when the command completes.

Parameters

pCommand	Command to execute.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.78 FLYCAPTURE2_C_API fc2Error fc2LaunchCommandAsync (const char * pCommand, fc2AsyncCommandCallback pCallback, void * pUserData)

Execute a command in the terminal.

This is a non-blocking call that will return immediately. The return value of the command can be retrieved in the callback.

Parameters

pCommand	Command to execute.
pCallback	Callback to fire when command is complete.
pUserData	Data pointer to pass to callback.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.79 FLYCAPTURE2_C_API fc2Error fc2LaunchHelp (const char * pFileName)

Open a CHM file in the system default CHM viewer.

Parameters

pFileName Filename of CHM file to open.

Returns

4.1.1.80 FLYCAPTURE2_C_API fc2Error fc2MJPGOpen (fc2AVIContext AVIContext, const char * pFileName, fc2MJPGOption * pOption)

Open an MJPEG file in preparation for writing Images to disk.

The size of AVI files is limited to 2GB. The filenames are automatically generated using the filename specified.

Parameters

AVIContext	The AVI context to use.
pFileName	The filename of the AVI file.
pOption	Options to apply to the AVI file.

Returns

A fc2Error indicating the success or failure of the function.

- 4.1.1.81 FLYCAPTURE2_C_API fc2Error fc2QueryGigElmagingMode (fc2Context context, fc2Mode mode, BOOL * isSupported)
- 4.1.1.82 FLYCAPTURE2_C_API fc2Error fc2ReadGVCPMemory (fc2Context context, unsigned int address, unsigned char * pBuffer, unsigned int length)

Read a GVCP memory block.

Parameters

context	The fc2Context to be used.
address	GVCP address to be read from.
pBuffer	Array containing data to be written.
length	Size of array, in quadlets.

Returns

An Error indicating the success or failure of the function.

4.1.1.83 FLYCAPTURE2_C_API fc2Error fc2ReadGVCPRegister (fc2Context context, unsigned int address, unsigned int * pValue)

Read a GVCP register.

context	The fc2Context to be used.
address	GVCP address to be read from.
pValue	The value that is read.

72 File Documentation

Returns

An Error indicating the success or failure of the function.

4.1.1.84 FLYCAPTURE2_C_API fc2Error fc2ReadGVCPRegisterBlock (fc2Context context, unsigned int address, unsigned int * pBuffer, unsigned int length)

Read a GVCP register block.

Parameters

context	The fc2Context to be used.
address	GVCP address to be read from.
pBuffer	Array containing data to be written.
length	Size of array, in quadlets.

Returns

An Error indicating the success or failure of the function.

4.1.1.85 FLYCAPTURE2_C_API fc2Error fc2ReadRegister (fc2Context context, unsigned int address, unsigned int * pValue)

Read the specified register from the camera.

Parameters

context	The fc2Context to be used.
address	DCAM address to be read from.
pValue	The value that is read.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.86 FLYCAPTURE2_C_API fc2Error fc2ReadRegisterBlock (fc2Context context, unsigned short addressHigh, unsigned int addressLow, unsigned int * pBuffer, unsigned int length)

Write to the specified register block on the camera.

Parameters

context	The fc2Context to be used.
addressHigh	Top 16 bits of the 48 bit absolute address to read from.
addressLow	Bottom 32 bits of the 48 bits absolute address to read from.
pBuffer	Array to store read data.
length	Size of array, in quadlets.

Generated on Sat Feb 9 2013 05:06:35 for FlyCapture2 C by Doxygen

A fc2Error indicating the success or failure of the function.

4.1.1.87 FLYCAPTURE2_C_API fc2Error fc2RegisterCallback (fc2Context context, fc2BusEventCallback enumCallback, fc2BusCallbackType callbackType, void * pParameter, fc2CallbackHandle * pCallbackHandle)

Register a callback function that will be called when the specified callback event occurs.

Parameters

context	The fc2Context to be used.
enum-	Pointer to function that will receive the callback.
Callback	
callbackType	Type of callback to register for.
pParameter	Callback parameter to be passed to callback.
pCallback-	Unique callback handle used for unregistering callback.
Handle	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.88 FLYCAPTURE2_C_API fc2Error fc2RescanBus (fc2Context context)

Force a rescan of the buses.

This does not trigger a bus reset. However, any current connections to a Camera object will be invalidated.

Returns

An Error indicating the success or failure of the function.

4.1.1.89 FLYCAPTURE2_C_API fc2Error fc2RestoreFromMemoryChannel (fc2Context context, unsigned int channel)

Restore the specfied current memory channel.

context	The fc2Context to be used.
channel	Memory channel to restore from.

A fc2Error indicating the success or failure of the function.

4.1.1.90 FLYCAPTURE2_C_API fc2Error fc2RetrieveBuffer (fc2Context context, fc2Image * plmage)

Retrieves the the next image object containing the next image.

Parameters

context	The fc2Context to be used.
plmage	Pointer to fc2Image to store image data.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.91 FLYCAPTURE2_C_API fc2Error fc2SaveImage (fc2Image * pImage, const char * pFilename, fc2ImageFileFormat format)

Save the image to the specified file name with the file format specified.

Parameters

plmage	The fc2Image to be used.
pFilename	Filename to save image with.
format	File format to save in.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.92 FLYCAPTURE2_C_API fc2Error fc2SaveImageWithOption (fc2Image * pImage, const char * pFilename, fc2ImageFileFormat format, void * pOption)

Save the image to the specified file name with the file format specified.

plmage	The fc2Image to be used.
pFilename	Filename to save image with.
format	File format to save in.
pOption	Options for saving image.

A fc2Error indicating the success or failure of the function.

4.1.1.93 FLYCAPTURE2_C_API fc2Error fc2SaveToMemoryChannel (fc2Context context, unsigned int channel)

Save the current settings to the specfied current memory channel.

Parameters

context	The fc2Context to be used.
channel	Memory channel to save to.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.94 FLYCAPTURE2_C_API fc2Error fc2SetActiveLUTBank (fc2Context context, unsigned int activeBank)

Set the LUT bank that will be used.

Parameters

	context	The fc2Context to be used.
a	ctiveBank	The bank to be set as active.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.95 FLYCAPTURE2_C_API fc2Error fc2SetCallback (fc2Context context, fc2ImageEventCallback pCallbackFn, void * pCallbackData)

Sets the callback data to be used on completion of image transfer.

To clear the current stored callback data, pass in NULL for both callback arguments.

context	The fc2Context to be used.
pCallbackFn	A function to be called when a new image is received.
pCallback-	A pointer to data that can be passed to the callback function.
Data	

A fc2Error indicating the success or failure of the function.

4.1.1.96 FLYCAPTURE2_C_API fc2Error fc2SetConfiguration (fc2Context context, fc2Config * config)

Set the configuration associated with the camera.

Parameters

context	The fc2Context to be used.
config	Pointer to the configuration structure to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.97 FLYCAPTURE2_C_API fc2Error fc2SetDefaultColorProcessing (fc2ColorProcessingAlgorithm defaultMethod)

Set the default color processing algorithm.

This method will be used for any image with the DEFAULT algorithm set. The method used is determined at the time of the Convert() call, therefore the most recent execution of this function will take precedence. The default setting is shared within the current process.

Parameters

default-	The color processing algorithm to set.
Method	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.98 FLYCAPTURE2_C_API fc2Error fc2SetDefaultOutputFormat (fc2PixelFormat format)

Set the default output pixel format.

This format will be used for any call to Convert() that does not specify an output format. The format used will be determined at the time of the Convert() call, therefore the most recent execution of this function will take precedence. The default is shared within the current process.

Parameters

format	The output pixel format to set.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.99 FLYCAPTURE2_C_API fc2Error fc2SetEmbeddedImageInfo (fc2Context context, fc2EmbeddedImageInfo * pInfo)

Sets the on/off values of the embedded image information structure to the camera.

Parameters

context	The fc2Context to be used.
pInfo	Structure to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.100 FLYCAPTURE2_C_API fc2Error fc2SetFormat7Configuration (fc2Context context, fc2Format7ImageSettings * imageSettings, float percentSpeed)

Set the current Format7 configuration to the camera.

Parameters

context	The fc2Context to be used.
image-	Image settings to be written to the camera.
Settings	
percent-	Packet size as a percentage to be written to the camera.
Speed	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.101 FLYCAPTURE2_C_API fc2Error fc2SetFormat7ConfigurationPacket (fc2Context context, fc2Format7ImageSettings * imageSettings, unsigned int packetSize)

Set the current Format7 configuration to the camera.

Parameters

	context	The fc2Context to be used.
ſ	image-	Image settings to be written to the camera.
	Settings	
ſ	packetSize	Packet size to be written to the camera.

Returns

A fc2Error indicating the success or failure of the function.

- 4.1.1.102 FLYCAPTURE2_C_API fc2Error fc2SetGigEConfig (fc2Context context, const fc2GigEConfig * pConfig)
- 4.1.1.103 FLYCAPTURE2_C_API fc2Error fc2SetGigEImageBinningSettings (fc2Context context, unsigned int horzBinnningValue, unsigned int vertBinnningValue)
- 4.1.1.104 FLYCAPTURE2_C_API fc2Error fc2SetGigEImageSettings (fc2Context context, const fc2GigEImageSettings * plmageSettings)
- 4.1.1.105 FLYCAPTURE2_C_API fc2Error fc2SetGigElmagingMode (fc2Context context, fc2Mode mode)
- 4.1.1.106 FLYCAPTURE2_C_API fc2Error fc2SetGigEProperty (fc2Context context, const fc2GigEProperty * pGigEProp)

Set the specified GigEProperty.

The GigEPropertyType field must be set in order for this function to succeed.

Parameters

context	The fc2Context to be used.
pGigEProp	The GigE property to set.

Returns

An Error indicating the success or failure of the function.

- 4.1.1.107 FLYCAPTURE2_C_API fc2Error fc2SetGigEStreamChannelInfo (fc2Context context, unsigned int channel, fc2GigEStreamChannel * pChannel)
- 4.1.1.108 FLYCAPTURE2_C_API fc2Error fc2SetGPIOPinDirection (fc2Context context, unsigned int pin, unsigned int direction)

Set the GPIO pin direction for the specified pin.

This is useful if there is a need to set the pin into an input pin (i.e. to read the voltage)

off the pin without setting it as a trigger source. This is not a required call when using the trigger or strobe functions as the pin direction is set automatically internally.

Parameters

ĺ	context	The fc2Context to be used.
	pin	Pin to get the direction for.
	direction	Direction of the pin. 0 for input, 1 for output.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.109 FLYCAPTURE2_C_API fc2Error fc2SetGPIOPinDirectionBroadcast (fc2Context context, unsigned int pin, unsigned int direction)

Set the GPIO pin direction for the specified pin.

This is useful if there is a need to set the pin into an input pin (i.e. to read the voltage) off the pin without setting it as a trigger source. This is not a required call when using the trigger or strobe functions as the pin direction is set automatically internally.

Parameters

conte	ext :	The fc2Context to be used.
p	oin I	Pin to get the direction for.
direction	on I	Direction of the pin. 0 for input, 1 for output.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.110 FLYCAPTURE2_C_API fc2Error fc2SetImageData (fc2Image * pImage, const unsigned char * pData, unsigned int dataSize)

Set the data of the Image object.

Ownership of the image buffer is not transferred to the Image object. It is the user's responsibility to delete the buffer when it is no longer in use.

plmage	The fc2Image to be used.
pData	Pointer to the image buffer.
dataSize	Size of the image buffer.

A fc2Error indicating the success or failure of the function.

4.1.1.111 FLYCAPTURE2_C_API fc2Error fc2SetImageDimensions (fc2Image * pImage, unsigned int rows, unsigned int cols, unsigned int stride, fc2PixelFormat pixelFormat, fc2BayerTileFormat bayerFormat)

Sets the dimensions of the image object.

Parameters

plmage	The fc2Image to be used.
rows	Number of rows to set.
cols	Number of cols to set.
stride	Stride to set.
pixelFormat	Pixel format to set.
bayerFormat	Bayer tile format to set.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.112 FLYCAPTURE2_C_API fc2Error fc2SetLUTChannel (fc2Context context, unsigned int bank, unsigned int channel, unsigned int sizeEntries, unsigned int * pEntries*)

Set the LUT channel settings to the camera.

Parameters

context	The fc2Context to be used.
bank	Bank to set.
channel	Channel to set.
sizeEntries	Number of entries in LUT table to write. This must be the same size as
	numEntries returned by GetLutInfo().
pEntries	Array containing LUT entries to write.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.113 FLYCAPTURE2_C_API fc2Error fc2SetProperty (fc2Context context, fc2Property * prop)

Writes the settings for the specified property to the camera.

The property type must be specified in the Property structure passed into the function in order for the function to succeed. The absControl flag controls whether the absolute or integer value is written to the camera.

Parameters

context	The fc2Context to be used.
prop	Pointer to the Property structure to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.114 FLYCAPTURE2_C_API fc2Error fc2SetPropertyBroadcast (fc2Context context, fc2Property * prop)

Writes the settings for the specified property to the camera.

The property type must be specified in the Property structure passed into the function in order for the function to succeed. The absControl flag controls whether the absolute or integer value is written to the camera.

Parameters

context	The fc2Context to be used.
prop	Pointer to the Property structure to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.115 FLYCAPTURE2_C_API fc2Error fc2SetStrobe (fc2Context context, fc2StrobeControl * strobeControl)

Set current strobe settings to the camera.

The strobe pin must be specified in the structure before being passed in to the function.

Parameters

context	The fc2Context to be used.
strobe-	Structure providing strobe settings.
Control	

Returns

4.1.1.116 FLYCAPTURE2_C_API fc2Error fc2SetStrobeBroadcast (fc2Context context, fc2StrobeControl * strobeControl)

Set current strobe settings to the camera.

The strobe pin must be specified in the structure before being passed in to the function.

Parameters

context	The fc2Context to be used.
strobe-	Structure providing strobe settings.
Control	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.117 FLYCAPTURE2_C_API fc2Error fc2SetTriggerDelay (fc2Context context, fc2TriggerDelay * triggerDelay)

Set the specified trigger delay settings to the camera.

Parameters

context	The fc2Context to be used.
triggerDelay	Structure providing trigger delay settings.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.118 FLYCAPTURE2_C_API fc2Error fc2SetTriggerDelayBroadcast (fc2Context context, fc2TriggerDelay * triggerDelay)

Set the specified trigger delay settings to the camera.

Parameters

context	The fc2Context to be used.
triggerDelay	Structure providing trigger delay settings.

Returns

4.1.1.119 FLYCAPTURE2_C_API fc2Error fc2SetTriggerMode (fc2Context context, fc2TriggerMode * triggerMode)

Set the specified trigger settings to the camera.

Parameters

ĺ	context	The fc2Context to be used.
I	triggerMode	Structure providing trigger mode settings.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.120 FLYCAPTURE2_C_API fc2Error fc2SetTriggerModeBroadcast (fc2Context context, fc2TriggerMode * triggerMode)

Set the specified trigger settings to the camera.

Parameters

context	The fc2Context to be used.
triggerMode	Structure providing trigger mode settings.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.121 FLYCAPTURE2_C_API fc2Error fc2SetUserBuffers (fc2Context context, unsigned char *const ppMemBuffers, int size, int nNumBuffers)

Specify user allocated buffers to use as image data buffers.

Parameters

context	The fc2Context to be used.
ррМет-	Pointer to memory buffers to be written to. The size of the data should
Buffers	be equal to (size * numBuffers) or larger.
size	The size of each buffer (in bytes).
nNum-	Number of buffers in the array.
Buffers	

Returns

4.1.1.122 FLYCAPTURE2_C_API fc2Error fc2SetVideoModeAndFrameRate (fc2Context context, fc2VideoMode videoMode, fc2FrameRate frameRate)

Set the specified video mode and frame rate to the camera.

It is not possible to set the camera to VIDEOMODE_FORMAT7 or FRAMERATE_FO-RMAT7. Use the Format7 functions to set the camera into Format7.

Parameters

	context	The fc2Context to be used.
	videoMode	Video mode to set to camera.
ſ	frameRate	Frame rate to set to camera.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.123 FLYCAPTURE2_C_API fc2Error fc2StartCapture (fc2Context context)

Starts isochronous image capture.

It will use either the current video mode or the most recently set video mode of the camera.

Parameters

context The fc2Context to be used.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.124 FLYCAPTURE2_C_API fc2Error fc2StartCaptureCallback (fc2Context context, fc2ImageEventCallback pCallbackFn, void * pCallbackData)

Starts isochronous image capture.

It will use either the current video mode or the most recently set video mode of the camera. The callback function is called when a new image is received from the camera.

context	The fc2Context to be used.
pCallbackFn	A function to be called when a new image is received.
pCallback-	A pointer to data that can be passed to the callback function. A NULL
Data	pointer is acceptable.

A fc2Error indicating the success or failure of the function.

4.1.1.125 FLYCAPTURE2_C_API fc2Error fc2StartSyncCapture (unsigned int *numCameras*, fc2Context * *pContexts*)

Starts synchronized isochronous image capture on multiple cameras.

Parameters

	num-	Number of fc2Contexts in the ppCameras array.
	Cameras	
Ī	pContexts	Array of fc2Contexts.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.126 FLYCAPTURE2_C_API fc2Error fc2StartSyncCaptureCallback (unsigned int numCameras, fc2Context * pContexts, fc2ImageEventCallback * pCallbackFns, void ** pCallbackDataArray)

Starts synchronized isochronous image capture on multiple cameras.

Parameters

num-	Number of fc2Contexts in the ppCameras array.
Cameras	
pContexts	Array of fc2Contexts.
pCallback-	Array of callback functions for each camera.
Fns	
pCallback-	Array of callback data pointers.
DataArray	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.127 FLYCAPTURE2_C_API fc2Error fc2StopCapture (fc2Context context)

Stops isochronous image transfer and cleans up all associated resources.

context	The fc2Context to be used.

A fc2Error indicating the success or failure of the function.

4.1.1.128 FLYCAPTURE2_C_API fc2Error fc2UnregisterCallback (fc2Context context, fc2CallbackHandle callbackHandle)

Unregister a callback function.

Parameters

	context	The fc2Context to be used.
Ī	callback-	Unique callback handle.
	Handle	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.129 FLYCAPTURE2_C_API fc2Error fc2ValidateFormat7Settings (fc2Context context, fc2Format7ImageSettings * imageSettings, BOOL * settingsAreValid, fc2Format7PacketInfo * packetInfo)

Validates Format7ImageSettings structure and returns valid packet size information if the image settings are valid.

The current image settings are cached while validation is taking place. The cached settings are restored when validation is complete.

Parameters

context	The fc2Context to be used.
image-	Structure containing the image settings.
Settings	
settingsAre-	Whether the settings are valid.
Valid	
packetInfo	Packet size information that can be used to determine a valid packet
	size.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.130 FLYCAPTURE2_C_API fc2Error fc2WriteGVCPMemory (fc2Context context, unsigned int address, const unsigned char * pBuffer, unsigned int length)

Write a GVCP memory block.

Parameters

context	The fc2Context to be used.
address	GVCP address to be write to.
pBuffer	Array containing data to be written.
length	Size of array, in quadlets.

Returns

An Error indicating the success or failure of the function.

4.1.1.131 FLYCAPTURE2_C_API fc2Error fc2WriteGVCPRegister (fc2Context context, unsigned int address, unsigned int value)

Write a GVCP register.

Parameters

context	The fc2Context to be used.
address	GVCP address to be written to.
value	The value to be written.

Returns

An Error indicating the success or failure of the function.

4.1.1.132 FLYCAPTURE2_C_API fc2Error fc2WriteGVCPRegisterBlock (fc2Context context, unsigned int address, const unsigned int * pBuffer, unsigned int length)

Write a GVCP register block.

Parameters

context	The fc2Context to be used.
address	GVCP address to be write to.
pBuffer	Array containing data to be written.
length	Size of array, in quadlets.

Returns

An Error indicating the success or failure of the function.

4.1.1.133 FLYCAPTURE2_C_API fc2Error fc2WriteGVCPRegisterBroadcast (fc2Context context, unsigned int address, unsigned int value)

Write a GVCP register with broadcast.

Parameters

context	The fc2Context to be used.
address	GVCP address to be written to.
value	The value to be written.

Returns

An Error indicating the success or failure of the function.

4.1.1.134 FLYCAPTURE2_C_API fc2Error fc2WriteRegister (fc2Context context, unsigned int address, unsigned int value)

Write to the specified register on the camera.

Parameters

context	The fc2Context to be used.
address	DCAM address to be written to.
value	The value to be written.

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.135 FLYCAPTURE2_C_API fc2Error fc2WriteRegisterBlock (fc2Context context, unsigned short addressHigh, unsigned int addressLow, const unsigned int * pBuffer, unsigned int length)

Write to the specified register block on the camera.

context	The fc2Context to be used.	
addressHigh	Top 16 bits of the 48 bit absolute address to write to.	
addressLow	Bottom 32 bits of the 48 bits absolute address to write to.	
pBuffer	Array containing data to be written.	
length	Size of array, in quadlets.	

Returns

A fc2Error indicating the success or failure of the function.

4.1.1.136 FLYCAPTURE2_C_API fc2Error fc2WriteRegisterBroadcast (fc2Context context, unsigned int address, unsigned int value)

Write to the specified register on the camera with broadcast.

Parameters

	context	The fc2Context to be used.
ĺ	address	DCAM address to be written to.
	value	The value to be written.

Returns

A fc2Error indicating the success or failure of the function.

4.2 FlyCapture2Defs_C.h File Reference

Data Structures

struct fc2PGRGuid

A GUID to the camera.

- struct fc2Image
- · struct fc2SystemInfo
- struct fc2Version
- struct fc2Config
- struct fc2TriggerDelayInfo
- struct fc2TriggerDelay
- struct fc2TriggerModeInfo
- struct fc2TriggerMode
- struct fc2StrobeInfo
- struct fc2StrobeControl
- struct fc2Format7ImageSettings
- struct fc2Format7Info
- struct fc2Format7PacketInfo
- struct fc2IPAddress
- struct fc2MACAddress
- struct fc2GigEProperty
- struct fc2GigEStreamChannel
- struct fc2GigEConfig
- struct fc2GigEImageSettingsInfo
- struct fc2GigEImageSettings

- struct fc2TimeStamp
- struct fc2ConfigROM
- · struct fc2CameraInfo
- · struct fc2EmbeddedImageInfoProperty
- struct fc2EmbeddedImageInfo
- struct fc2ImageMetadata
- struct fc2LUTData
- · struct fc2PNGOption
- struct fc2PPMOption
- struct fc2PGMOption
- struct fc2TIFFOption
- struct fc2JPEGOption
- struct fc2JPG2Option
- struct fc2AVIOption
- struct fc2MJPGOption
- struct fc2H264Option

Defines

- #define FALSE 0
- #define TRUE 1
- #define FULL 32BIT VALUE 0x7FFFFFF
- #define MAX_STRING_LENGTH 512

Typedefs

- typedef int BOOL
- typedef void * fc2Context

A context to the FlyCapture2 C library.

typedef void * fc2GuiContext

A context to the FlyCapture2 C GUI library.

typedef void * fc2lmageImpl

An internal pointer used in the fc2lmage structure.

typedef void * fc2AVIContext

A context referring to the AVI recorder object.

• typedef void * fc2ImageStatisticsContext

A context referring to the ImageStatistics object.

- typedef void * fc2CallbackHandle
- typedef void(* fc2BusEventCallback)(void *pParameter, unsigned int serial-Number)
- typedef void(* fc2ImageEventCallback)(fc2Image *image, void *pCallbackData)
- typedef void(* fc2AsyncCommandCallback)(fc2Error retError, void *pUserData)

Enumerations

- enum fc2Error { FC2_ERROR_UNDEFINED = -1, FC2_ERROR_OK, FC2-_ERROR_FAILED, FC2_ERROR_NOT_IMPLEMENTED, FC2_ERROR_FAIL-ED_BUS_MASTER_CONNECTION, FC2_ERROR_NOT_CONNECTED, FC2-_ERROR_INIT_FAILED, FC2_ERROR_NOT_INTITIALIZED, FC2_ERROR_I-NVALID_PARAMETER, FC2_ERROR_INVALID_SETTINGS, FC2_ERROR_-INVALID BUS MANAGER, FC2 ERROR MEMORY ALLOCATION FAILED, FC2 ERROR LOW LEVEL FAILURE, FC2 ERROR NOT FOUND, FC2 -ERROR FAILED GUID, FC2 ERROR INVALID PACKET SIZE, FC2 ERR-OR_INVALID_MODE, FC2_ERROR_NOT_IN_FORMAT7, FC2_ERROR_NO-T SUPPORTED, FC2 ERROR TIMEOUT, FC2 ERROR BUS MASTER F-AILED, FC2 ERROR INVALID GENERATION, FC2 ERROR LUT FAILED, FC2 ERROR IIDC FAILED, FC2 ERROR STROBE FAILED, FC2 ERRO-R_TRIGGER_FAILED, FC2_ERROR_PROPERTY_FAILED, FC2_ERROR_P-ROPERTY_NOT_PRESENT, FC2_ERROR_REGISTER_FAILED, FC2_ERR-OR READ REGISTER FAILED, FC2 ERROR WRITE REGISTER FAILED, FC2_ERROR_ISOCH_FAILED, FC2_ERROR_ISOCH_ALREADY_STARTED, FC2_ERROR_ISOCH_NOT_STARTED, FC2_ERROR_ISOCH_START_FAIL-ED, FC2_ERROR_ISOCH_RETRIEVE_BUFFER_FAILED, FC2_ERROR_ISO-CH STOP FAILED, FC2 ERROR ISOCH SYNC FAILED, FC2 ERROR IS-OCH_BANDWIDTH_EXCEEDED, FC2_ERROR_IMAGE_CONVERSION_FAI-LED, FC2_ERROR_IMAGE_LIBRARY_FAILURE, FC2_ERROR_BUFFER_T-OO_SMALL, FC2_ERROR_IMAGE_CONSISTENCY_ERROR, FC2_ERROR-
- enum fc2BusCallbackType { FC2_BUS_RESET, FC2_ARRIVAL, FC2_REMO-VAL, FC2_CALLBACK_TYPE_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2GrabMode { FC2_DROP_FRAMES, FC2_BUFFER_FRAMES, FC2_UNSPECIFIED_GRAB_MODE, FC2_GRAB_MODE_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2GrabTimeout { FC2_TIMEOUT_NONE = 0, FC2_TIMEOUT_INFINITE = -1, FC2_TIMEOUT_UNSPECIFIED = -2, FC2_GRAB_TIMEOUT_FORCE_-32BITS = FULL_32BIT_VALUE }
- enum fc2BandwidthAllocation { FC2_BANDWIDTH_ALLOCATION_OFF = 0, FC2_BANDWIDTH_ALLOCATION_ON = 1, FC2_BANDWIDTH_ALLOCATION_UNSUPPORTED = 2, FC2_BANDWIDTH_ALLOCATION_UNSPECIFIED = 3, FC2_BANDWIDTH_ALLOCATION_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2InterfaceType { FC2_INTERFACE_IEEE1394, FC2_INTERFACE_US-B_2, FC2_INTERFACE_USB_3, FC2_INTERFACE_GIGE, FC2_INTERFACE_UNKNOWN, FC2_INTERFACE_TYPE_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2DriverType { FC2_DRIVER_1394_CAM, FC2_DRIVER_1394_PRO, FC2_DRIVER_1394_JUJU, FC2_DRIVER_1394_VIDEO1394, FC2_DRIVER_R_1394_RAW1394, FC2_DRIVER_USB_NONE, FC2_DRIVER_USB_CAM, FC2_DRIVER_USB3_PRO, FC2_DRIVER_GIGE_NONE, FC2_DRIVER_GIGE_FILTER, FC2_DRIVER_GIGE_PRO, FC2_DRIVER_UNKNOWN = -1, FC2_DRIVER_FORCE_32BITS = FULL_32BIT_VALUE }

Types of low level drivers that flycapture uses.

- enum fc2PropertyType { FC2_BRIGHTNESS, FC2_AUTO_EXPOSURE, FC2_SHARPNESS, FC2_WHITE_BALANCE, FC2_HUE, FC2_SATURATION, F-C2_GAMMA, FC2_IRIS, FC2_FOCUS, FC2_ZOOM, FC2_PAN, FC2_TILT, FC2_SHUTTER, FC2_GAIN, FC2_TRIGGER_MODE, FC2_TRIGGER_DELA-Y, FC2_FRAME_RATE, FC2_TEMPERATURE, FC2_UNSPECIFIED_PROPERTY_TYPE, FC2_PROPERTY_TYPE_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2FrameRate { FC2_FRAMERATE_1_875, FC2_FRAMERATE_3_75, FC2_FRAMERATE_7_5, FC2_FRAMERATE_15, FC2_FRAMERATE_30, F-C2_FRAMERATE_60, FC2_FRAMERATE_120, FC2_FRAMERATE_240, F-C2_FRAMERATE_FORMAT7, FC2_NUM_FRAMERATES, FC2_FRAMERATE FORCE 32BITS = FULL 32BIT VALUE }
- enum fc2VideoMode { FC2_VIDEOMODE_160x120YUV444, FC2_VIDEOMODE_320x240YUV422, FC2_VIDEOMODE_640x480YUV411, FC2_VIDEOMODE_640x480YUV422, FC2_VIDEOMODE_640x480RGB, FC2_VIDEOMODE_640x480Y8, FC2_VIDEOMODE_640x480Y16, FC2_VIDEOMODE_800x600-YUV422, FC2_VIDEOMODE_800x600RGB, FC2_VIDEOMODE_800x600Y8, FC2_VIDEOMODE_800x600Y16, FC2_VIDEOMODE_1024x768YUV422, FC2_VIDEOMODE_1024x768RGB, FC2_VIDEOMODE_1024x768Y8, FC2_VIDEOMODE_1024x768Y16, FC2_VIDEOMODE_1280x960YUV422, FC2_VIDEOMODE_1280x960RGB, FC2_VIDEOMODE_1280x960Y8, FC2_VIDEOMODE_1280x960Y16, FC2_VIDEOMODE_1600x1200YUV422, FC2_VIDEOMODE_1600x1200YUV422, FC2_VIDEOMODE_1600x1200YUF6, FC2_VIDEOMODE_1600x1200YUFF, FC2_VIDEOMODE_1600x1200YIFF, FC2_VIDEOM
- enum fc2Mode { FC2_MODE_0 = 0, FC2_MODE_1, FC2_MODE_2, FC2_MODE_3, FC2_MODE_4, FC2_MODE_5, FC2_MODE_6, FC2_MODE_7, FC2_MODE_8, FC2_MODE_9, FC2_MODE_10, FC2_MODE_11, FC2_MODE_12, FC2_MODE_13, FC2_MODE_14, FC2_MODE_15, FC2_MODE_16, FC2_MODE_17, FC2_MODE_18, FC2_MODE_19, FC2_MODE_20, FC2_MODE_21, FC2_MODE_22, FC2_MODE_23, FC2_MODE_24, FC2_MODE_25, FC2_MODE_26, FC2_MODE_27, FC2_MODE_28, FC2_MODE_29, FC2_MODE_30, FC2_MODE_31, FC2_NUM_MODES, FC2_MODE_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2PixelFormat { FC2_PIXEL_FORMAT_MONO8 = 0x80000000, F-C2_PIXEL_FORMAT_411YUV8 = 0x40000000, FC2_PIXEL_FORMAT_422-YUV8 = 0x20000000, FC2_PIXEL_FORMAT_444YUV8 = 0x100000000, F-C2_PIXEL_FORMAT_RGB8 = 0x08000000, FC2_PIXEL_FORMAT_MONO16 = 0x04000000, FC2_PIXEL_FORMAT_RGB16 = 0x020000000, FC2_PIXEL_FORMAT_S_RGB16 = 0x008000000, FC2_PIXEL_FORMAT_RAW8 = 0x004000000, FC2_PIXEL_FORMAT_RAW16 = 0x002000000, FC2_PIXEL_FORMAT_MONO12 = 0x001000000, FC2_PIXEL_FORMAT_RAW12 = 0x000800000, FC2_PIXEL_FORMAT_BGR = 0x80000008, FC2_PIXEL_FORMAT_BGRU = 0x40000008, FC2_PIXEL_FORMAT_RGBU = 0x40000008, FC2_PIXEL_FORMAT_RGBU = 0x40000002, FC2_PIXEL_FORMAT_RGBB, FC2_PIXEL_FORMAT_RGBU = 0x40000002, FC2_PIXEL_FORMAT_BGR16 = 0x02000001, FC2_PIXEL_FORMAT_BG

- enum fc2BusSpeed { FC2_BUSSPEED_S100, FC2_BUSSPEED_S200, FC2_BUSSPEED_S400, FC2_BUSSPEED_S480, FC2_BUSSPEED_S800, FC2_BUSSPEED_S1600, FC2_BUSSPEED_S3200, FC2_BUSSPEED_S5000, × FC2_BUSSPEED_10BASE_T, FC2_BUSSPEED_100BASE_T, FC2_BUSSPEED_S2_FASTEST, FC2_BUSSPEED_ANY, FC2_BUSSPEED_S2_FASTEST, FC2_BUSSPEED_ANY, FC2_BUSSPEED_SPEED_UNKNOWN = -1, FC2_BUSSPEED_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2PCleBusSpeed { FC2_PCIE_BUSSPEED_2_5, FC2_PCIE_BUSSPEED_5_0, FC2_PCIE_BUSSPEED_UNKNOWN = -1, FC2_PCIE_BUSSPEED_FORCE 32BITS = FULL 32BIT VALUE }
- enum fc2ColorProcessingAlgorithm { FC2_DEFAULT, FC2_NO_COLOR_PRO-CESSING, FC2_NEAREST_NEIGHBOR_FAST, FC2_EDGE_SENSING, FC2_ HQ_LINEAR, FC2_RIGOROUS, FC2_IPP, FC2_DIRECTIONAL, FC2_COL-OR PROCESSING ALGORITHM FORCE 32BITS = FULL 32BIT VALUE }
- enum fc2BayerTileFormat { FC2_BT_NONE, FC2_BT_RGGB, FC2_BT_GRB-G, FC2_BT_GBRG, FC2_BT_BGGR, FC2_BT_FORCE_32BITS = FULL_32B-IT_VALUE }
- enum fc2ImageFileFormat { FC2_FROM_FILE_EXT = -1, FC2_PGM, FC2_P-PM, FC2_BMP, FC2_JPEG, FC2_JPEG2000, FC2_TIFF, FC2_PNG, FC2_RAW, FC2_IMAGE_FILE_FORMAT_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2GigEPropertyType { FC2_HEARTBEAT, FC2_HEARTBEAT_TIMEO-UT }
- enum fc2StatisticsChannel { FC2_STATISTICS_GREY, FC2_STATISTICS_R-ED, FC2_STATISTICS_GREEN, FC2_STATISTICS_BLUE, FC2_STATISTICS_HUE, FC2_STATISTICS_SATURATION, FC2_STATISTICS_LIGHTNESS, FC2_STATISTICS_FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2OSType { FC2_WINDOWS_X86, FC2_WINDOWS_X64, FC2_LINU-X_X86, FC2_LINUX_X64, FC2_MAC, FC2_UNKNOWN_OS, FC2_OSTYPE-FORCE_32BITS = FULL_32BIT_VALUE }
- enum fc2ByteOrder { FC2_BYTE_ORDER_LITTLE_ENDIAN, FC2_BYTE_ORDER_BIG_ENDIAN, FC2_BYTE_ORDER_FORCE_32BITS = FULL_32BIT_V-ALUE }
- enum fc2TIFFCompressionMethod { FC2_TIFF_NONE = 1, FC2_TIFF_PACK-BITS, FC2_TIFF_DEFLATE, FC2_TIFF_ADOBE_DEFLATE, FC2_TIFF_CCITTFAX3, FC2_TIFF_CCITTFAX4, FC2_TIFF_LZW, FC2_TIFF_JPEG }
- 4.2.1 Define Documentation
- 4.2.1.1 #define FALSE 0
- 4.2.1.2 #define FULL_32BIT_VALUE 0x7FFFFFF
- 4.2.1.3 #define MAX_STRING_LENGTH 512
- 4.2.1.4 #define TRUE 1

94 File Documentation

- 4.2.2 Typedef Documentation
- 4.2.2.1 typedef int BOOL
- 4.2.2.2 typedef void(* fc2AsyncCommandCallback)(fc2Error retError, void *pUserData)
- 4.2.2.3 typedef void* fc2AVIContext

A context referring to the AVI recorder object.

- 4.2.2.4 typedef void(* fc2BusEventCallback)(void *pParameter, unsigned int serialNumber)
- 4.2.2.5 typedef void* fc2CallbackHandle
- 4.2.2.6 typedef void* fc2Context

A context to the FlyCapture2 C library.

It must be created before performing any calls to the library.

4.2.2.7 typedef void* fc2GuiContext

A context to the FlyCapture2 C GUI library.

It must be created before performing any calls to the library.

- 4.2.2.8 typedef void(* fc2ImageEventCallback)(fc2Image *image, void *pCallbackData)
- 4.2.2.9 typedef void* fc2ImageImpl

An internal pointer used in the fc2lmage structure.

4.2.2.10 typedef void* fc2ImageStatisticsContext

A context referring to the ImageStatistics object.

- 4.2.3 Enumeration Type Documentation
- 4.2.3.1 enum fc2BandwidthAllocation

Enumerator:

FC2_BANDWIDTH_ALLOCATION_OFF
FC2_BANDWIDTH_ALLOCATION_ON
FC2_BANDWIDTH_ALLOCATION_UNSUPPORTED
FC2_BANDWIDTH_ALLOCATION_UNSPECIFIED

FC2_BANDWIDTH_ALLOCATION_FORCE_32BITS

4.2.3.2 enum fc2BayerTileFormat

Enumerator:

FC2_BT_RGGB Red-Green-Green-Blue.
FC2_BT_GRBG Green-Red-Blue-Green.
FC2_BT_GBRG Green-Blue-Red-Green.
FC2_BT_BGGR Blue-Green-Green-Red.

FC2_BT_FORCE_32BITS

4.2.3.3 enum fc2BusCallbackType

Enumerator:

FC2_BUS_RESET
FC2_ARRIVAL
FC2_REMOVAL
FC2_CALLBACK_TYPE_FORCE_32BITS

4.2.3.4 enum fc2BusSpeed

Enumerator:

FC2_BUSSPEED_S100 100Mbits/sec.

FC2_BUSSPEED_S200 200Mbits/sec.

FC2 BUSSPEED S400 400Mbits/sec.

FC2_BUSSPEED_S480 480Mbits/sec. Only for USB2 cameras.

FC2_BUSSPEED_S800 800Mbits/sec.

FC2_BUSSPEED_S1600 1600Mbits/sec.

FC2_BUSSPEED_S3200 3200Mbits/sec.

FC2_BUSSPEED_S5000 5000Mbits/sec. Only for USB3 cameras.

FC2_BUSSPEED_10BASE_T 10Base-T. Only for GigE cameras.

FC2_BUSSPEED_100BASE_T 100Base-T. Only for GigE cameras.

FC2_BUSSPEED_1000BASE_T 1000Base-T (Gigabit Ethernet). Only for GigE cameras.

 ${\it FC2_BUSSPEED_10000BASE_T}$ 10000Base-T. Only for GigE cameras.

FC2_BUSSPEED_S_FASTEST The fastest speed available.

FC2_BUSSPEED_ANY Any speed that is available.

FC2_BUSSPEED_SPEED_UNKNOWN Unknown bus speed.

FC2_BUSSPEED_FORCE_32BITS

4.2.3.5 enum fc2ByteOrder

Enumerator:

96

FC2_BYTE_ORDER_LITTLE_ENDIAN
FC2_BYTE_ORDER_BIG_ENDIAN
FC2_BYTE_ORDER_FORCE_32BITS

4.2.3.6 enum fc2ColorProcessingAlgorithm

Enumerator:

FC2_DEFAULT
FC2_NO_COLOR_PROCESSING
FC2_NEAREST_NEIGHBOR_FAST
FC2_EDGE_SENSING
FC2_HQ_LINEAR
FC2_RIGOROUS
FC2_IPP
FC2_DIRECTIONAL

FC2_COLOR_PROCESSING_ALGORITHM_FORCE_32BITS

4.2.3.7 enum fc2DriverType

Types of low level drivers that flycapture uses.

Enumerator:

FC2_DRIVER_1394_CAM PGRCam.sys.
FC2_DRIVER_1394_PRO PGR1394.sys.
FC2_DRIVER_1394_JUJU firewire_core.
FC2_DRIVER_1394_VIDEO1394 video1394.
FC2_DRIVER_1394_RAW1394 raw1394.
FC2_DRIVER_USB_NONE No usb driver used just BSD stack. (Linux only)
FC2_DRIVER_USB_CAM PGRUsbCam.sys.
FC2_DRIVER_USB3_PRO PGRXHCI.sys.
FC2_DRIVER_GIGE_NONE no gige drivers used,MS/BSD stack.
FC2_DRIVER_GIGE_FILTER PGRGigE.sys.
FC2_DRIVER_GIGE_PRO PGRGigEPro.sys.
FC2_DRIVER_GIGE_PRO PGRGigEPro.sys.
FC2_DRIVER_UNKNOWN Unknown driver type.
FC2_DRIVER_FORCE 32BITS

4.2.3.8 enum fc2Error

Enumerator:

- FC2_ERROR_UNDEFINED Undefined.
- FC2 ERROR OK Function returned with no errors.
- FC2_ERROR_FAILED General failure.
- FC2 ERROR NOT IMPLEMENTED Function has not been implemented.
- FC2_ERROR_FAILED_BUS_MASTER_CONNECTION Could not connect to Bus Master.
- FC2_ERROR_NOT_CONNECTED Camera has not been connected.
- FC2 ERROR INIT FAILED Initialization failed.
- FC2_ERROR_NOT_INTITIALIZED Camera has not been initialized.
- FC2 ERROR INVALID PARAMETER Invalid parameter passed to function.
- FC2_ERROR_INVALID_SETTINGS Setting set to camera is invalid.
- FC2_ERROR_INVALID_BUS_MANAGER Invalid Bus Manager object.
- FC2_ERROR_MEMORY_ALLOCATION_FAILED Could not allocate memory.
- FC2 ERROR LOW LEVEL FAILURE Low level error.
- FC2_ERROR_NOT_FOUND Device not found.
- FC2_ERROR_FAILED_GUID GUID failure.
- FC2_ERROR_INVALID_PACKET_SIZE Packet size set to camera is invalid.
- FC2_ERROR_INVALID_MODE Invalid mode has been passed to function.
- FC2_ERROR_NOT_IN_FORMAT7 Error due to not being in Format7.
- FC2_ERROR_NOT_SUPPORTED This feature is unsupported.
- FC2 ERROR TIMEOUT Timeout error.
- FC2_ERROR_BUS_MASTER_FAILED Bus Master Failure.
- FC2_ERROR_INVALID_GENERATION Generation Count Mismatch.
- FC2_ERROR_LUT_FAILED Look Up Table failure.
- FC2_ERROR_IIDC_FAILED IIDC failure.
- FC2 ERROR STROBE FAILED Strobe failure.
- FC2_ERROR_TRIGGER_FAILED Trigger failure.
- FC2_ERROR_PROPERTY_FAILED Property failure.
- FC2_ERROR_PROPERTY_NOT_PRESENT Property is not present.
- FC2_ERROR_REGISTER_FAILED Register access failed.
- FC2_ERROR_READ_REGISTER_FAILED Register read failed.
- FC2_ERROR_WRITE_REGISTER_FAILED Register write failed.
- FC2 ERROR ISOCH FAILED Isochronous failure.
- **FC2_ERROR_ISOCH_ALREADY_STARTED** Isochronous transfer has already been started.
- **FC2_ERROR_ISOCH_NOT_STARTED** Isochronous transfer has not been started.

98 File Documentation

FC2 ERROR ISOCH START FAILED Isochronous start failed.

FC2_ERROR_ISOCH_RETRIEVE_BUFFER_FAILED Isochronous retrieve buffer failed.

FC2_ERROR_ISOCH_STOP_FAILED Isochronous stop failed.

FC2_ERROR_ISOCH_SYNC_FAILED Isochronous image synchronization failed.

FC2_ERROR_ISOCH_BANDWIDTH_EXCEEDED Isochronous bandwidth exceeded.

FC2_ERROR_IMAGE_CONVERSION_FAILED Image conversion failed.

FC2 ERROR IMAGE LIBRARY FAILURE Image library failure.

FC2_ERROR_BUFFER_TOO_SMALL Buffer is too small.

FC2_ERROR_IMAGE_CONSISTENCY_ERROR There is an image consistency error.

FC2_ERROR_FORCE_32BITS

4.2.3.9 enum fc2FrameRate

Enumerator:

FC2_FRAMERATE_1_875 1.875 fps.

FC2_FRAMERATE_3_75 3.75 fps.

FC2_FRAMERATE_7_5 7.5 fps.

FC2_FRAMERATE_15 15 fps.

FC2_FRAMERATE_30 30 fps.

FC2 FRAMERATE 60 60 fps.

FC2_FRAMERATE_120 120 fps.

FC2_FRAMERATE_240 240 fps.

FC2_FRAMERATE_FORMAT7 Custom frame rate for Format7 functionality.

FC2_NUM_FRAMERATES Number of possible camera frame rates.

FC2_FRAMERATE_FORCE_32BITS

4.2.3.10 enum fc2GigEPropertyType

Enumerator:

FC2_HEARTBEAT

FC2_HEARTBEAT_TIMEOUT

4.2.3.11 enum fc2GrabMode

Enumerator:

FC2_DROP_FRAMES
FC2_BUFFER_FRAMES
FC2_UNSPECIFIED_GRAB_MODE
FC2_GRAB_MODE_FORCE_32BITS

4.2.3.12 enum fc2GrabTimeout

Enumerator:

FC2_TIMEOUT_NONE
FC2_TIMEOUT_INFINITE
FC2_TIMEOUT_UNSPECIFIED
FC2_GRAB_TIMEOUT_FORCE_32BITS

4.2.3.13 enum fc2ImageFileFormat

Enumerator:

FC2_FROM_FILE_EXT Determine file format from file extension.
FC2_PGM Portable gray map.
FC2_PPM Portable pixmap.
FC2_BMP Bitmap.
FC2_JPEG JPEG.
FC2_JPEG2000 JPEG 2000.
FC2_TIFF Tagged image file format.
FC2_PNG Portable network graphics.
FC2_RAW Raw data.

4.2.3.14 enum fc2InterfaceType

Enumerator:

FC2_INTERFACE_IEEE1394
FC2_INTERFACE_USB_2
FC2_INTERFACE_USB_3
FC2_INTERFACE_GIGE
FC2_INTERFACE_UNKNOWN
FC2_INTERFACE_TYPE_FORCE_32BITS

FC2_IMAGE_FILE_FORMAT_FORCE_32BITS

4.2.3.15 enum fc2Mode

Enumerator:

- FC2_MODE_0
- FC2_MODE_1
- FC2_MODE_2
- FC2_MODE_3
- FC2_MODE_4
- FC2_MODE_5
- FC2_MODE_6
- FC2_MODE_7
- FC2_MODE_8
- FC2_MODE_9
- ______
- FC2_MODE_10
- FC2_MODE_11
- FC2_MODE_12
- FC2_MODE_13
- FC2_MODE_14
- FC2_MODE_15
- FC2_MODE_16
- FC2_MODE_17
- FC2_MODE_18
- FC2_MODE_19
- FC2_MODE_20
- FC2_MODE_21
- FC2_MODE_22
- FC2_MODE_23
- FC2_MODE_24
- FC2_MODE_25
- FC2_MODE_26
- FC2_MODE_27
- FC2_MODE_28
- FC2_MODE_29
- FC2_MODE_30
- FC2_MODE_31
- FC2_NUM_MODES Number of modes.
- FC2_MODE_FORCE_32BITS

4.2.3.16 enum fc2OSType

Enumerator:

FC2 WINDOWS X86

FC2_WINDOWS_X64

FC2_LINUX_X86

FC2 LINUX X64

FC2_MAC

FC2_UNKNOWN_OS

FC2_OSTYPE_FORCE_32BITS

4.2.3.17 enum fc2PCleBusSpeed

Enumerator:

FC2_PCIE_BUSSPEED_2_5

FC2_PCIE_BUSSPEED_5_0 2.5 Gb/s

FC2 PCIE BUSSPEED UNKNOWN 5.0 Gb/s

FC2_PCIE_BUSSPEED_FORCE_32BITS Speed is unknown.

4.2.3.18 enum fc2PixelFormat

Enumerator:

```
FC2_PIXEL_FORMAT_MONO8 8 bits of mono information.
```

FC2_PIXEL_FORMAT_411YUV8 YUV 4:1:1.

FC2 PIXEL FORMAT 422YUV8 YUV 4:2:2.

FC2_PIXEL_FORMAT_444YUV8 YUV 4:4:4.

 $FC2_PIXEL_FORMAT_RGB8$ R = G = B = 8 bits.

FC2_PIXEL_FORMAT_MONO16 16 bits of mono information.

 $FC2_PIXEL_FORMAT_RGB16$ R = G = B = 16 bits.

FC2_PIXEL_FORMAT_S_MONO16 16 bits of signed mono information.

 $FC2_PIXEL_FORMAT_S_RGB16$ R = G = B = 16 bits signed.

FC2_PIXEL_FORMAT_RAW8 8 bit raw data output of sensor.

FC2_PIXEL_FORMAT_RAW16 16 bit raw data output of sensor.

FC2_PIXEL_FORMAT_MONO12 12 bits of mono information.

FC2_PIXEL_FORMAT_RAW12 12 bit raw data output of sensor.

FC2 PIXEL FORMAT BGR 24 bit BGR.

FC2_PIXEL_FORMAT_BGRU 32 bit BGRU.

FC2_PIXEL_FORMAT_RGB 24 bit RGB.

102 File Documentation

FC2_PIXEL_FORMAT_RGBU 32 bit RGBU.

 $FC2_PIXEL_FORMAT_BGR16$ R = G = B = 16 bits.

FC2_PIXEL_FORMAT_BGRU16 64 bit BGRU.

FC2_NUM_PIXEL_FORMATS Number of pixel formats.

FC2_UNSPECIFIED_PIXEL_FORMAT Unspecified pixel format.

4.2.3.19 enum fc2PropertyType

Enumerator:

FC2_BRIGHTNESS

FC2_AUTO_EXPOSURE

FC2_SHARPNESS

FC2_WHITE_BALANCE

FC2_HUE

FC2_SATURATION

FC2_GAMMA

FC2_IRIS

FC2_FOCUS

FC2 ZOOM

FC2 PAN

FC2_TILT

FC2_SHUTTER

FC2_GAIN

FC2_TRIGGER_MODE

FC2_TRIGGER_DELAY

FC2_FRAME_RATE

FC2_TEMPERATURE

FC2_UNSPECIFIED_PROPERTY_TYPE

FC2_PROPERTY_TYPE_FORCE_32BITS

4.2.3.20 enum fc2StatisticsChannel

Enumerator:

FC2_STATISTICS_GREY

FC2_STATISTICS_RED

FC2_STATISTICS_GREEN

FC2_STATISTICS_BLUE

FC2_STATISTICS_HUE
FC2_STATISTICS_SATURATION
FC2_STATISTICS_LIGHTNESS
FC2_STATISTICS_FORCE_32BITS

4.2.3.21 enum fc2TIFFCompressionMethod

Enumerator:

FC2_TIFF_NONE

FC2_TIFF_PACKBITS

FC2_TIFF_DEFLATE

FC2_TIFF_ADOBE_DEFLATE

FC2_TIFF_CCITTFAX3

FC2_TIFF_CCITTFAX4

FC2_TIFF_LZW

FC2_TIFF_JPEG

4.2.3.22 enum fc2VideoMode

Enumerator:

FC2_VIDEOMODE_160x120YUV444 160x120 YUV444.

FC2_VIDEOMODE_320x240YUV422 320x240 YUV422.

FC2_VIDEOMODE_640x480YUV411 640x480 YUV411.

FC2_VIDEOMODE_640x480YUV422 640x480 YUV422.

FC2_VIDEOMODE_640x480RGB 640x480 24-bit RGB.

FC2_VIDEOMODE_640x480Y8 640x480 8-bit.

FC2_VIDEOMODE_640x480Y16 640x480 16-bit.

FC2_VIDEOMODE_800x600YUV422 800x600 YUV422.

FC2_VIDEOMODE_800x600RGB 800x600 RGB.

FC2 VIDEOMODE 800x600Y8 800x600 8-bit.

FC2 VIDEOMODE 800x600Y16 800x600 16-bit.

FC2_VIDEOMODE_1024x768YUV422 1024x768 YUV422.

FC2_VIDEOMODE_1024x768RGB 1024x768 RGB.

FC2_VIDEOMODE_1024x768Y8 1024x768 8-bit.

FC2_VIDEOMODE_1024x768Y16 1024x768 16-bit.

FC2_VIDEOMODE_1280x960YUV422 1280x960 YUV422.

FC2_VIDEOMODE_1280x960RGB 1280x960 RGB.

FC2_VIDEOMODE_1280x960Y8 1280x960 8-bit.

104 File Documentation

FC2_VIDEOMODE_1280x960Y16 1280x960 16-bit.

FC2_VIDEOMODE_1600x1200YUV422 1600x1200 YUV422.

FC2_VIDEOMODE_1600x1200RGB 1600x1200 RGB.

FC2_VIDEOMODE_1600x1200Y8 1600x1200 8-bit.

FC2_VIDEOMODE_1600x1200Y16 1600x1200 16-bit.

FC2_VIDEOMODE_FORMAT7 Custom video mode for Format7 functionality.

FC2_NUM_VIDEOMODES Number of possible video modes.

FC2_VIDEOMODE_FORCE_32BITS

4.3 FlyCapture2GUI_C.h File Reference

Functions

FLYCAPTURE2_C_API fc2Error fc2CreateGUIContext (fc2GuiContext *p-Context)

Create a GUI context.

FLYCAPTURE2_C_API fc2Error fc2DestroyGUIContext (fc2GuiContext context)

Destroy a GUI context.

FLYCAPTURE2_C_API void fc2GUIConnect (fc2GuiContext context, fc2Context cameraContext)

Connect GUI context to a camera context.

• FLYCAPTURE2 C API void fc2Disonnect (fc2GuiContext context)

Disconnect GUI context from camera.

FLYCAPTURE2_C_API void fc2Show (fc2GuiContext context)

Show the GUI.

• FLYCAPTURE2_C_API void fc2Hide (fc2GuiContext context)

Hide the GUI.

FLYCAPTURE2_C_API BOOL fc2IsVisible (fc2GuiContext context)

Check if the GUI is visible.

 FLYCAPTURE2_C_API void fc2ShowModal (fc2GuiContext context, BOOL *p-OkSelected, fc2PGRGuid *guidArray, unsigned int *size)

Show the camera selection dialog.

4.3.1 Function Documentation

4.3.1.1 FLYCAPTURE2_C_API fc2Error fc2CreateGUIContext (fc2GuiContext * pContext)

Create a GUI context.

Parameters

pContext | Pointer to context to be created.

Returns

An Error indicating the success or failure of the function.

4.3.1.2 FLYCAPTURE2_C_API fc2Error fc2DestroyGUIContext (fc2GuiContext context)

Destroy a GUI context.

Parameters

context	Context to be destroyed.
---------	--------------------------

Returns

An Error indicating the success or failure of the function.

4.3.1.3 FLYCAPTURE2_C_API void fc2Disonnect (fc2GuiContext context)

Disconnect GUI context from camera.

Parameters

context	GUI context to disconnect.

Returns

An Error indicating the success or failure of the function.

4.3.1.4 FLYCAPTURE2_C_API void fc2GUIConnect (fc2GuiContext context, fc2Context cameraContext)

Connect GUI context to a camera context.

Parameters

context	GUI context to connect.
camera-	Camera context to connect.
Context	

Returns

An Error indicating the success or failure of the function.

4.3.1.5 FLYCAPTURE2_C_API void fc2Hide (fc2GuiContext context)

Hide the GUI.

Parameters

context	Pointer to context to hide.

Returns

An Error indicating the success or failure of the function.

4.3.1.6 FLYCAPTURE2_C_API BOOL fc2lsVisible (fc2GuiContext context)

Check if the GUI is visible.

Parameters

context	Pointer to context to show.
---------	-----------------------------

Returns

Whether the GUI is visible.

4.3.1.7 FLYCAPTURE2_C_API void fc2Show (fc2GuiContext context)

Show the GUI.

Parameters

context	Pointer to context to show.	

Returns

An Error indicating the success or failure of the function.

4.3.1.8 FLYCAPTURE2_C_API void fc2ShowModal (fc2GuiContext context, BOOL * pOkSelected, fc2PGRGuid * guidArray, unsigned int * size)

Show the camera selection dialog.

Parameters

context	Pointer to context to show.
pOkSelected	Whether Ok (true) or Cancel (false) was clicked.
guidArray	Array of PGRGuids containing the selected cameras.
size	Size of PGRGuid array.

4.4 FlyCapture2Internal_C.h File Reference

Data Structures

- struct fc2InternalContext
- struct fc2InternalGuiContext
- struct fc2InternalImageCallback

Functions

- bool IsContextValid (fc2Context context)
- bool IsGuiContextValid (fc2GuiContext context)
- void SyncCppImageToStruct (fc2Image *pImage)

4.4.1 Function Documentation

```
4.4.1.1 bool lsContextValid (fc2Context context) [inline]
```

- 4.4.1.2 bool lsGuiContextValid (fc2GuiContext context) [inline]
- 4.4.1.3 void SyncCppImageToStruct (fc2Image * pImage) [inline]

4.5 FlyCapture2Platform_C.h File Reference

Defines

- #define FLYCAPTURE2 C API
- #define FLYCAPTURE2 C CALL CONVEN

4.5.1 Define Documentation

- 4.5.1.1 #define FLYCAPTURE2_C_API
- 4.5.1.2 #define FLYCAPTURE2_C_CALL_CONVEN

4.6 MultiSyncLibrary_C.h File Reference

Functions

 MULTISYNCLIBRARY_C_API syncError syncCreateContext (syncContext *p-Context)

Create a Sync context for MultiSync Library.

MULTISYNCLIBRARY_C_API syncError syncDestroyContext (syncContext context)

Destory the sync context.

MULTISYNCLIBRARY_C_API syncError syncStart (syncContext context)
 Start the sync progress.

- MULTISYNCLIBRARY_C_API syncError syncStop (syncContext context) Stop the sync progress.
- MULTISYNCLIBRARY_C_API syncError syncRescanMasterTimingBus (sync-Context context)

Scan newly connected or removed timing bus (for corss-PC syncing only)

MULTISYNCLIBRARY_C_API syncMessage syncGetStatus (syncContext context)

Start the sync progress.

MULTISYNCLIBRARY_C_API double syncGetTimeSinceSynced (syncContext context)

Time since sync started.

 MULTISYNCLIBRARY_C_API bool synclsTimingBusConnected (syncContext context)

Whether syncing across PCs.

 MULTISYNCLIBRARY_C_API bool syncEnableCrossPCSynchronization (sync-Context context)

Enable across pc synchronization support.

 MULTISYNCLIBRARY_C_API bool syncDisableCrossPCSynchronization (sync-Context context)

Disable across pc synchronization support.

 MULTISYNCLIBRARY_C_API bool syncQueryCrossPCSynchronizationSetting (syncContext context)

Query cross pc synchronizaion support status.

4.6.1 Function Documentation

4.6.1.1 MULTISYNCLIBRARY_C_API syncError syncCreateContext (syncContext * pContext)

Create a Sync context for MultiSync Library.

This call must be made before any other calls that use a context will succeed.

Parameters

pContext | A pointer to the syncContext to be created.

Returns

A syncError indicating the success or failure of the function.

4.6.1.2 MULTISYNCLIBRARY_C_API syncError syncDestroyContext (syncContext context)

Destory the sync context.

This must be called when the user is finished with the context in order to prevent memory leaks.

Parameters

context	The syncContext to be destoryed.
---------	----------------------------------

Returns

A syncError indicating the success or failure of the function.

4.6.1.3 MULTISYNCLIBRARY_C_API bool syncDisableCrossPCSynchronization (syncContext context)

Disable across pc synchronization support.

Parameters

context The syncContext to be used.

Returns

True if operation was successful

4.6.1.4 MULTISYNCLIBRARY_C_API bool syncEnableCrossPCSynchronization (syncContext context)

Enable across pc synchronization support.

Parameters

context The syncContext to be used.

Returns

True if operation was successful

4.6.1.5 MULTISYNCLIBRARY_C_API syncMessage syncGetStatus (syncContext context)

Start the sync progress.

Parameters

context	The syncContext to be used.

Returns

A syncMessage indicating the sync status.

4.6.1.6 MULTISYNCLIBRARY_C_API double syncGetTimeSinceSynced (syncContext context)

Time since sync started.

Parameters

Returns

Time sinced synced.

4.6.1.7 MULTISYNCLIBRARY_C_API bool synclsTimingBusConnected (syncContext context)

Whether syncing across PCs.

Parameters

context Th	ne syncContext to be used.

Returns

True if its syncing across PC

4.6.1.8 MULTISYNCLIBRARY_C_API bool syncQueryCrossPCSynchronizationSetting (syncContext context)

Query cross pc synchronizaion support status.

Parameters

context	The syncContext to be used.

Returns

True if cross pc synchronization was supported

4.6.1.9 MULTISYNCLIBRARY_C_API syncError syncRescanMasterTimingBus (syncContext context)

Scan newly connected or removed timing bus (for corss-PC syncing only)

Parameters

context	t The syncContext to be used.	

Returns

A syncError indicating the success or failure of the function.

4.6.1.10 MULTISYNCLIBRARY_C_API syncError syncStart (syncContext context)

Start the sync progress.

Parameters

context	The syncContext to be used.

Returns

A syncError indicating the success or failure of the function.

4.6.1.11 MULTISYNCLIBRARY_C_API syncError syncStop (syncContext context)

Stop the sync progress.

Parameters

context The syncContext to be used.	
---------------------------------------	--

Returns

A syncError indicating the success or failure of the function.

4.7 MultiSyncLibraryDefs_C.h File Reference

Defines

- #define FALSE 0
- #define TRUE 1
- #define FULL_32BIT_VALUE 0x7FFFFFF
- #define MAX_STRING_LENGTH 512

Typedefs

- typedef int BOOL
- typedef void * syncContext

A context to the MultiSync C library.

Enumerations

- enum syncError { SYNC_ERROR_OK = 0, SYNC_ERROR_FAILED, SYN-C_ERROR_ALREADY_STARTED, SYNC_ERROR_ALREADY_STOPPED, S-YNC_ERROR_CONTEXT_NOT_INITIALIZED, SYNC_ERROR_UNKNOWN_E-RROR }
- enum syncMessage { SYNC_MESSAGE_OK = 0, SYNC_MESSAGE_FAILED, SYNC_MESSAGE_STARTED, SYNC_MESSAGE_STOPPED, SYNC_MESS-AGE_SYNCING, SYNC_MESSAGE_NOMASTER, SYNC_MESSAGE_THRE-AD_ERROR, SYNC_MESSAGE_DEVICE_ERROR, SYNC_MESSAGE_NOT_ ENOUGH_DEVICES, SYNC_MESSAGE_BUS_RESET, SYNC_MESSAGE_-NOT_INITIALIZED, SYNC_MESSAGE_UNKNOWN_ERROR }
- 4.7.1 Define Documentation
- 4.7.1.1 #define FALSE 0
- 4.7.1.2 #define FULL_32BIT_VALUE 0x7FFFFFFF
- 4.7.1.3 #define MAX_STRING_LENGTH 512
- 4.7.1.4 #define TRUE 1
- 4.7.2 Typedef Documentation
- 4.7.2.1 typedef int BOOL
- 4.7.2.2 typedef void* syncContext

A context to the MultiSync C library.

It must be created before performing any calls to the library.

4.7.3 Enumeration Type Documentation

4.7.3.1 enum syncError

Enumerator:

SYNC_ERROR_OK
SYNC_ERROR_FAILED
SYNC_ERROR_ALREADY_STARTED
SYNC_ERROR_ALREADY_STOPPED
SYNC_ERROR_CONTEXT_NOT_INITIALIZED
SYNC_ERROR_UNKNOWN_ERROR

4.7.3.2 enum syncMessage

Enumerator:

SYNC_MESSAGE_OK
SYNC_MESSAGE_FAILED
SYNC_MESSAGE_STARTED
SYNC_MESSAGE_STOPPED
SYNC_MESSAGE_SYNCING
SYNC_MESSAGE_NOMASTER
SYNC_MESSAGE_THREAD_ERROR
SYNC_MESSAGE_DEVICE_ERROR
SYNC_MESSAGE_NOT_ENOUGH_DEVICES
SYNC_MESSAGE_BUS_RESET
SYNC_MESSAGE_NOT_INITIALIZED
SYNC_MESSAGE_UNKNOWN_ERROR

4.8 MultiSyncLibraryPlatform_C.h File Reference

Defines

- #define MULTISYNCLIBRARY_C_API
- #define MULTISYNCLIBRARY_C_CALL_CONVEN

4.8.1 Define Documentation

- 4.8.1.1 #define MULTISYNCLIBRARY_C_API
- 4.8.1.2 #define MULTISYNCLIBRARY_C_CALL_CONVEN

Index

FC2_ARRIVAL	FC2_BUSSPEED_10BASE_T
FlyCapture2Defs_C.h, 95	FlyCapture2Defs_C.h, 95
FC2_AUTO_EXPOSURE	FC2_BUSSPEED_ANY
FlyCapture2Defs_C.h, 102	FlyCapture2Defs_C.h, 95
FC2_BANDWIDTH_ALLOCATION_FOR-	FC2_BUSSPEED_FORCE_32BITS
CE_32BITS	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 94	FC2_BUSSPEED_S100
FC2_BANDWIDTH_ALLOCATION_OFF	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 94	FC2_BUSSPEED_S1600
FC2_BANDWIDTH_ALLOCATION_ON	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 94	FC2_BUSSPEED_S200
FC2_BANDWIDTH_ALLOCATION_UNS-	FlyCapture2Defs_C.h, 95
PECIFIED	FC2_BUSSPEED_S3200
FlyCapture2Defs_C.h, 94	FlyCapture2Defs_C.h, 95
FC2_BANDWIDTH_ALLOCATION_UNS-	FC2_BUSSPEED_S400
UPPORTED	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 94	FC2_BUSSPEED_S480
FC2_BMP	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 99	FC2_BUSSPEED_S5000
FC2_BRIGHTNESS	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 102	FC2_BUSSPEED_S800
FC2_BT_BGGR	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 95	FC2_BUSSPEED_SPEED_UNKNOWN
FC2_BT_FORCE_32BITS	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 95	FC2_BUSSPEED_S_FASTEST
FC2_BT_GBRG	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 95	FC2_BUS_RESET
FC2_BT_GRBG	FlyCapture2Defs_C.h, 95
FlyCapture2Defs_C.h, 95	FC2_BYTE_ORDER_BIG_ENDIAN
FC2_BT_NONE	FlyCapture2Defs_C.h, 96
FlyCapture2Defs_C.h, 95	FC2_BYTE_ORDER_FORCE_32BITS
FC2_BT_RGGB	FlyCapture2Defs_C.h, 96
FlyCapture2Defs_C.h, 95	FC2_BYTE_ORDER_LITTLE_ENDIAN
FC2_BUFFER_FRAMES	FlyCapture2Defs_C.h, 96
FlyCapture2Defs_C.h, 99	FC2_CALLBACK_TYPE_FORCE_32BIT
FC2_BUSSPEED_10000BASE_T	S
FlyCapture2Defs_C.h, 95	FlyCapture2Defs_C.h, 95
FC2_BUSSPEED_1000BASE_T	FC2_COLOR_PROCESSING_ALGORIT
FlyCapture2Defs_C.h, 95	HM_FORCE_32BITS
FC2_BUSSPEED_100BASE_T	FlyCapture2Defs_C.h, 96
FlyCapture2Defs C.h, 95	FC2 DEFAULT

FlyCapture2Defs_C.h, 96	FlyCapture2Defs_C.h, 98
FC2_DIRECTIONAL	FC2_ERROR_IMAGE_CONVERSION
FlyCapture2Defs_C.h, 96	FAILED
FC2_DRIVER_1394_CAM	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 96	FC2_ERROR_IMAGE_LIBRARY_FAILU-
FC2_DRIVER_1394_JUJU	RE
FlyCapture2Defs_C.h, 96	FlyCapture2Defs_C.h, 98
FC2_DRIVER_1394_PRO	FC2_ERROR_INIT_FAILED
FlyCapture2Defs_C.h, 96	FlyCapture2Defs_C.h, 97
FC2_DRIVER_1394_RAW1394	FC2_ERROR_INVALID_BUS_MANAGE-
FlyCapture2Defs_C.h, 96	R
FC2_DRIVER_1394_VIDEO1394	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 96	FC2_ERROR_INVALID_GENERATION
FC2_DRIVER_FORCE_32BITS	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 96	FC2_ERROR_INVALID_MODE
FC2_DRIVER_GIGE_FILTER	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 96	FC2 ERROR INVALID PACKET SIZE
FC2 DRIVER GIGE NONE	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 96	FC2_ERROR_INVALID_PARAMETER
FC2 DRIVER GIGE PRO	FlyCapture2Defs C.h, 97
FlyCapture2Defs_C.h, 96	FC2_ERROR_INVALID_SETTINGS
FC2_DRIVER_UNKNOWN	FlyCapture2Defs_C.h, 97
FlyCapture2Defs C.h, 96	FC2_ERROR_ISOCH_ALREADY_STAR
FC2_DRIVER_USB3_PRO	TED
FlyCapture2Defs_C.h, 96	FlyCapture2Defs_C.h, 97
FC2_DRIVER_USB_CAM	FC2_ERROR_ISOCH_BANDWIDTH_E-
FlyCapture2Defs_C.h, 96	XCEEDED
· · · —	
FC2_DRIVER_USB_NONE	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 96	FC2_ERROR_ISOCH_FAILED
FC2_DROP_FRAMES	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 99	FC2_ERROR_ISOCH_NOT_STARTED
FC2_EDGE_SENSING	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 96	FC2_ERROR_ISOCH_RETRIEVE_BUF-
FC2_ERROR_BUFFER_TOO_SMALL	FER_FAILED
FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 98
FC2_ERROR_BUS_MASTER_FAILED	FC2_ERROR_ISOCH_START_FAILED
FlyCapture2Defs_C.h, 97	FlyCapture2Defs_C.h, 97
FC2_ERROR_FAILED	FC2_ERROR_ISOCH_STOP_FAILED
FlyCapture2Defs_C.h, 97	FlyCapture2Defs_C.h, 98
FC2_ERROR_FAILED_BUS_MASTER	FC2_ERROR_ISOCH_SYNC_FAILED
CONNECTION	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 97	FC2_ERROR_LOW_LEVEL_FAILURE
FC2_ERROR_FAILED_GUID	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 97	FC2_ERROR_LUT_FAILED
FC2_ERROR_FORCE_32BITS	FlyCapture2Defs_C.h, 97
FlyCapture2Defs_C.h, 98	FC2_ERROR_MEMORY_ALLOCATION-
FC2_ERROR_IIDC_FAILED	_FAILED
FlyCapture2Defs_C.h, 97	FlyCapture2Defs_C.h, 97
FC2_ERROR_IMAGE_CONSISTENCY	FC2_ERROR_NOT_CONNECTED
ERROR	FlyCapture2Defs_C.h, 97

FC2_ERROR_NOT_FOUND	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 97	FC2_FRAMERATE_FORCE_32BITS
FC2_ERROR_NOT_IMPLEMENTED	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 97	FC2_FRAMERATE_FORMAT7
FC2_ERROR_NOT_INTITIALIZED	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 97	FC2_FRAME_RATE
FC2_ERROR_NOT_IN_FORMAT7	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 97	FC2_FROM_FILE_EXT
FC2_ERROR_NOT_SUPPORTED	FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 97	FC2 GAIN
FC2 ERROR OK	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 97	FC2 GAMMA
FC2 ERROR PROPERTY FAILED	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 97	FC2_GRAB_MODE_FORCE_32BITS
FC2_ERROR_PROPERTY_NOT_PRES-	FlyCapture2Defs_C.h, 99
ENT	FC2_GRAB_TIMEOUT_FORCE_32BITS
FlyCapture2Defs_C.h, 97	FlyCapture2Defs_C.h, 99
FC2_ERROR_READ_REGISTER_FAIL-	FC2 HEARTBEAT
ED	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 97	FC2_HEARTBEAT_TIMEOUT
FC2_ERROR_REGISTER_FAILED	FlyCapture2Defs_C.h, 98
FlyCapture2Defs_C.h, 97	FC2 HQ LINEAR
FC2_ERROR_STROBE_FAILED	FlyCapture2Defs_C.h, 96
FlyCapture2Defs_C.h, 97	FC2 HUE
FC2 ERROR TIMEOUT	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 97	FC2_IMAGE_FILE_FORMAT_FORCE
FC2_ERROR_TRIGGER_FAILED	32BITS
FlyCapture2Defs_C.h, 97	FlyCapture2Defs_C.h, 99
FC2_ERROR_UNDEFINED	FC2_INTERFACE_GIGE
FlyCapture2Defs_C.h, 97	FlyCapture2Defs_C.h, 99
FC2_ERROR_WRITE_REGISTER_FAIL-	FC2 INTERFACE IEEE1394
ED	FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 97	FC2_INTERFACE_TYPE_FORCE_32BI-
FC2 FOCUS	TS
FlyCapture2Defs_C.h, 102	FlyCapture2Defs_C.h, 99
FC2 FRAMERATE 120	FC2_INTERFACE_UNKNOWN
FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 99
FC2_FRAMERATE_15	· · · —
FlyCapture2Defs C.h, 98	FC2 INTERFACE LISB 2
- · - ·	FC2_INTERFACE_USB_2 FlyCapture2Defs_C h_99
FC2 FRAMERATE 1 875	FlyCapture2Defs_C.h, 99
FC2_FRAMERATE_1_875 FlyCanture2Defs_C.h. 98	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3
FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_30	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96 FC2_IRIS
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_30 FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96 FC2_IRIS FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_30 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_3_75	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96 FC2_IRIS FlyCapture2Defs_C.h, 102 FC2_JPEG
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_30 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_3_75 FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96 FC2_IRIS FlyCapture2Defs_C.h, 102 FC2_JPEG FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_30 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_3_75 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_60	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96 FC2_IRIS FlyCapture2Defs_C.h, 102 FC2_JPEG FlyCapture2Defs_C.h, 99 FC2_JPEG2000
FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_240 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_30 FlyCapture2Defs_C.h, 98 FC2_FRAMERATE_3_75 FlyCapture2Defs_C.h, 98	FlyCapture2Defs_C.h, 99 FC2_INTERFACE_USB_3 FlyCapture2Defs_C.h, 99 FC2_IPP FlyCapture2Defs_C.h, 96 FC2_IRIS FlyCapture2Defs_C.h, 102 FC2_JPEG FlyCapture2Defs_C.h, 99

FlyCapture2Defs_C.h, 101	FlyCapture2Defs_C.h, 100
FC2_LINUX_X86	FC2_MODE_3
FlyCapture2Defs_C.h, 101 FC2_MAC	FlyCapture2Defs_C.h, 100 FC2_MODE_30
FlyCapture2Defs_C.h, 101	FlyCapture2Defs_C.h, 100
FC2_MODE_0	FC2_MODE_31
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_1	FC2_MODE_4
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_10	FC2_MODE_5
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_11	FC2_MODE_6
FlyCapture2Defs_C.h, 100 FC2_MODE_12	FlyCapture2Defs_C.h, 100 FC2_MODE_7
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_13	FC2_MODE_8
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_14	FC2_MODE_9
FlyCapture2Defs_C.h, 100	FlyCapture2Defs C.h, 100
FC2_MODE_15	FC2_MODE_FORCE_32BITS
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_16	FC2_NEAREST_NEIGHBOR_FAST
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 96
FC2_MODE_17	FC2_NO_COLOR_PROCESSING
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 96
FC2_MODE_18	FC2_NUM_FRAMERATES
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 98
FC2_MODE_19	FC2_NUM_MODES
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 100
FC2_MODE_2	FC2_NUM_PIXEL_FORMATS
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 102
FC2_MODE_20 FlyCapture2Defs_C.h, 100	FC2_NUM_VIDEOMODES FlyCapture2Defs_C.h, 104
FC2 MODE 21	FC2_OSTYPE_FORCE_32BITS
FlyCapture2Defs_C.h, 100	FlyCapture2Defs C.h, 101
FC2_MODE_22	FC2 PAN
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 102
FC2_MODE_23	FC2 PCIE BUSSPEED 2 5
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 101
FC2_MODE_24	FC2_PCIE_BUSSPEED_5_0
FlyCapture2Defs_C.h, 100	FlyCapture2Defs_C.h, 101
FC2_MODE_25	FC2_PCIE_BUSSPEED_FORCE_32BIT-
FlyCapture2Defs_C.h, 100	S
FC2_MODE_26	FlyCapture2Defs_C.h, 101
FlyCapture2Defs_C.h, 100	FC2_PCIE_BUSSPEED_UNKNOWN
FC2_MODE_27	FlyCapture2Defs_C.h, 101
FlyCapture2Defs_C.h, 100	FC2_PGM
FC2_MODE_28	FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 100 FC2 MODE 29	FC2_PIXEL_FORMAT_411YUV8 FlyCapture2Defs_C.h, 101
1 02 WODE 28	i iyoapiulezbels_o.li, lul

FC2_PIXEL_FORMAT_422YUV8	FlyCapture2Defs_C.h, 96
FlyCapture2Defs_C.h, 101	FC2_SATURATION
FC2_PIXEL_FORMAT_422YUV8_JPEG	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 102	FC2_SHARPNESS
FC2_PIXEL_FORMAT_444YUV8	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 101	FC2_SHUTTER
FC2_PIXEL_FORMAT_BGR	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 101	FC2_STATISTICS_BLUE
FC2_PIXEL_FORMAT_BGR16	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 102	FC2_STATISTICS_FORCE_32BITS
FC2_PIXEL_FORMAT_BGRU	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_STATISTICS_GREEN
FC2_PIXEL_FORMAT_BGRU16	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 102	FC2_STATISTICS_GREY
FC2_PIXEL_FORMAT_MONO12	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 101	FC2_STATISTICS_HUE
FC2_PIXEL_FORMAT_MONO16	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 101	FC2_STATISTICS_LIGHTNESS
FC2_PIXEL_FORMAT_MONO8	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_STATISTICS_RED
FC2_PIXEL_FORMAT_RAW12	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 101	FC2_STATISTICS_SATURATION
FC2_PIXEL_FORMAT_RAW16	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_TEMPERATURE
FC2_PIXEL_FORMAT_RAW8	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 101	FC2_TIFF
FC2_PIXEL_FORMAT_RGB	FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 101	FC2_TIFF_ADOBE_DEFLATE
FC2_PIXEL_FORMAT_RGB16	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_TIFF_CCITTFAX3
FC2_PIXEL_FORMAT_RGB8	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_TIFF_CCITTFAX4
FC2_PIXEL_FORMAT_RGBU	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_TIFF_DEFLATE
FC2_PIXEL_FORMAT_S_MONO16	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_TIFF_JPEG
FC2_PIXEL_FORMAT_S_RGB16	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 101	FC2_TIFF_LZW
FC2_PNG	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 99	FC2_TIFF_NONE
FC2_PPM	FlyCapture2Defs_C.h, 103
FlyCapture2Defs_C.h, 99	FC2_TIFF_PACKBITS
FC2_PROPERTY_TYPE_FORCE_32BI-	FlyCapture2Defs_C.h, 103
TS	FC2_TILT
FlyCapture2Defs_C.h, 102	FlyCapture2Defs_C.h, 102
FC2_RAW	FC2_TIMEOUT_INFINITE
FlyCapture2Defs_C.h, 99	FlyCapture2Defs_C.h, 99
FC2_REMOVAL	FC2_TIMEOUT_NONE
FlyCapture2Defs_C.h, 95	FlyCapture2Defs_C.h, 99
FC2_RIGOROUS	FC2_TIMEOUT_UNSPECIFIED

FlyCapture2Defs_C.h, 99	FlyCapture2Defs_C.h, 103
FC2 TRIGGER DELAY	FC2 VIDEOMODE 800x600RGB
FlyCapture2Defs_C.h, 102	FlyCapture2Defs_C.h, 103
FC2_TRIGGER_MODE	FC2_VIDEOMODE_800x600Y16
FlyCapture2Defs_C.h, 102	FlyCapture2Defs_C.h, 103
FC2_UNKNOWN_OS	FC2 VIDEOMODE 800x600Y8
FlyCapture2Defs_C.h, 101	FlyCapture2Defs_C.h, 103
FC2_UNSPECIFIED_GRAB_MODE	FC2_VIDEOMODE_800x600YUV422
FlyCapture2Defs_C.h, 99	FlyCapture2Defs C.h, 103
FC2_UNSPECIFIED_PIXEL_FORMAT	FC2 VIDEOMODE FORCE 32BITS
FlyCapture2Defs_C.h, 102	
FC2_UNSPECIFIED_PROPERTY_TYPE	FlyCapture2Defs_C.h, 104
FlyCapture2Defs_C.h, 102	FC2_VIDEOMODE_FORMAT7
FC2_VIDEOMODE_1024x768RGB	FlyCapture2Defs_C.h, 104
FlyCapture2Defs_C.h, 103	FC2_WHITE_BALANCE
FC2_VIDEOMODE_1024x768Y16	FlyCapture2Defs_C.h, 102
FlyCapture2Defs_C.h, 103	FC2_WINDOWS_X64
FC2_VIDEOMODE_1024x768Y8	FlyCapture2Defs_C.h, 101
FlyCapture2Defs_C.h, 103	FC2_WINDOWS_X86
FC2_VIDEOMODE_1024x768YUV422	FlyCapture2Defs_C.h, 101
FlyCapture2Defs_C.h, 103	FC2_ZOOM
FC2_VIDEOMODE_1280x960RGB	FlyCapture2Defs_C.h, 102
	FlyCapture2Defs_C.h
FlyCapture2Defs_C.h, 103	FC2_ARRIVAL, 95
FC2_VIDEOMODE_1280x960Y16	FC2_AUTO_EXPOSURE, 102
FlyCapture2Defs_C.h, 103	FC2_BANDWIDTH_ALLOCATION
FC2_VIDEOMODE_1280x960Y8	FORCE_32BITS, 94
FlyCapture2Defs_C.h, 103	FC2_BANDWIDTH_ALLOCATION
FC2_VIDEOMODE_1280x960YUV422	OFF, 94
FlyCapture2Defs_C.h, 103	FC2_BANDWIDTH_ALLOCATION
FC2_VIDEOMODE_1600x1200RGB	ON, 94
FlyCapture2Defs_C.h, 104	FC2_BANDWIDTH_ALLOCATION
FC2_VIDEOMODE_1600x1200Y16	UNSPECIFIED, 94
FlyCapture2Defs_C.h, 104	FC2_BANDWIDTH_ALLOCATION
FC2_VIDEOMODE_1600x1200Y8	UNSUPPORTED, 94
FlyCapture2Defs_C.h, 104	FC2 BMP, 99
FC2_VIDEOMODE_1600x1200YUV422	FC2_BRIGHTNESS, 102
FlyCapture2Defs_C.h, 104	FC2_BT_BGGR, 95
FC2_VIDEOMODE_160x120YUV444	FC2 BT FORCE 32BITS, 95
FlyCapture2Defs_C.h, 103	
FC2_VIDEOMODE_320x240YUV422	FC2_BT_GBRG, 95 FC2_BT_GRBG, 95
FlyCapture2Defs_C.h, 103	
FC2_VIDEOMODE_640x480RGB	FC2_BT_NONE, 95
FlyCapture2Defs_C.h, 103	FC2_BT_RGGB, 95
FC2_VIDEOMODE_640x480Y16	FC2_BUFFER_FRAMES, 99
FlyCapture2Defs_C.h, 103	FC2_BUSSPEED_10000BASE_T,
FC2_VIDEOMODE_640x480Y8	95
FlyCapture2Defs_C.h, 103	FC2_BUSSPEED_1000BASE_T, 95
FC2_VIDEOMODE_640x480YUV411	FC2_BUSSPEED_100BASE_T, 95
FlyCapture2Defs_C.h, 103	FC2_BUSSPEED_10BASE_T, 95
FC2_VIDEOMODE_640x480YUV422	FC2_BUSSPEED_ANY, 95

FC2_BUSSPEED_FORCE_32BITS,	FC2_ERROR_FAILED_GUID, 97
95	FC2_ERROR_FORCE_32BITS, 98
FC2_BUSSPEED_S100, 95	FC2_ERROR_IIDC_FAILED, 97
FC2_BUSSPEED_S1600, 95	FC2_ERROR_IMAGE_CONSISTE-
FC2_BUSSPEED_S200, 95	NCY_ERROR, 98
FC2_BUSSPEED_S3200, 95	FC2_ERROR_IMAGE_CONVERSI-
FC2_BUSSPEED_S400, 95	ON_FAILED, 98
FC2_BUSSPEED_S480, 95	FC2_ERROR_IMAGE_LIBRARY_F-
FC2_BUSSPEED_S5000, 95	AILURE, 98
FC2_BUSSPEED_S800, 95	FC2_ERROR_INIT_FAILED, 97
FC2 BUSSPEED SPEED UNKNO-	FC2 ERROR INVALID BUS MAN
	AGER, 97
FC2_BUSSPEED_S_FASTEST, 95	FC2_ERROR_INVALID_GENERAT
FC2_BUS_RESET, 95	 ION, 97
FC2_BYTE_ORDER_BIG_ENDIAN,	FC2_ERROR_INVALID_MODE, 97
96	FC2_ERROR_INVALID_PACKET
FC2_BYTE_ORDER_FORCE_32BI-	SIZE, 97
TS, 96	FC2 ERROR INVALID PARAMET
FC2_BYTE_ORDER_LITTLE_ENDI-	ER, 97
AN, 96	FC2_ERROR_INVALID_SETTINGS
FC2_CALLBACK_TYPE_FORCE	97
32BITS, 95	FC2 ERROR ISOCH ALREADY -
FC2_COLOR_PROCESSING_AL-	STARTED, 97
GORITHM_FORCE_32BITS,	FC2_ERROR_ISOCH_BANDWIDT-
96	H EXCEEDED, 98
FC2_DEFAULT, 96	FC2_ERROR_ISOCH_FAILED, 97
FC2_DIRECTIONAL, 96	FC2_ERROR_ISOCH_NOT_STAR-
FC2_DRIVER_1394_CAM, 96	TED, 97
FC2_DRIVER_1394_JUJU, 96	FC2_ERROR_ISOCH_RETRIEVE_
FC2 DRIVER 1394 PRO, 96	BUFFER FAILED, 98
FC2 DRIVER 1394 RAW1394, 96	FC2_ERROR_ISOCH_START_FAI-
FC2_DRIVER_1394_VIDEO1394,	LED, 97
96	FC2_ERROR_ISOCH_STOP_FAIL-
FC2_DRIVER_FORCE_32BITS, 96	ED, 98
FC2 DRIVER GIGE FILTER, 96	FC2 ERROR ISOCH SYNC FAIL-
FC2 DRIVER GIGE NONE, 96	ED, 98
FC2_DRIVER_GIGE_PRO, 96	FC2_ERROR_LOW_LEVEL_FAILU
FC2_DRIVER_UNKNOWN, 96	RE, 97
FC2_DRIVER_USB3_PRO, 96	FC2_ERROR_LUT_FAILED, 97
FC2_DRIVER_USB_CAM, 96	FC2_ERROR_MEMORY_ALLOCA-
FC2_DRIVER_USB_NONE, 96	TION_FAILED, 97
FC2_DROP_FRAMES, 99	FC2_ERROR_NOT_CONNECTED,
FC2_EDGE_SENSING, 96	97
FC2_ERROR_BUFFER_TOO_SM-	FC2_ERROR_NOT_FOUND, 97
ALL, 98	FC2_ERROR_NOT_IMPLEMENTE-
FC2_ERROR_BUS_MASTER_FAI-	D, 97
LED, 97	FC2_ERROR_NOT_INTITIALIZED,
FC2_ERROR_FAILED, 97	97
FC2_ERROR_FAILED_BUS_MAS-	FC2_ERROR_NOT_IN_FORMAT7,
TER CONNECTION, 97	97

FC2_ERROR_NOT_SUPPORTED,	FC2_INTERFACE_USB_3, 99
97	FC2_IPP, 96
FC2_ERROR_OK, 97	FC2_IRIS, 102
FC2_ERROR_PROPERTY_FAILE-	FC2_JPEG, 99
D, 97	FC2_JPEG2000, 99
FC2_ERROR_PROPERTY_NOT_P-	FC2_LINUX_X64, 101
RESENT, 97	FC2_LINUX_X86, 101
FC2_ERROR_READ_REGISTER	FC2_MAC, 101
FAILED, 97	FC2_MODE_0, 100
FC2_ERROR_REGISTER_FAILED,	FC2_MODE_1, 100
97	FC2_MODE_10, 100
FC2_ERROR_STROBE_FAILED, 97	FC2_MODE_11, 100
FC2_ERROR_TIMEOUT, 97	FC2_MODE_12, 100
FC2_ERROR_TRIGGER_FAILED, 97	FC2_MODE_13, 100
	FC2_MODE_14, 100
FC2_ERROR_UNDEFINED, 97	FC2_MODE_15, 100
FC2_ERROR_WRITE_REGISTER-	FC2_MODE_16, 100
_FAILED, 97	FC2_MODE_17, 100
FC2_FOCUS, 102	FC2_MODE_18, 100
FC2_FRAMERATE_120, 98	FC2_MODE_19, 100
FC2_FRAMERATE_15, 98 FC2_FRAMERATE_1_875, 98	FC2_MODE_2, 100
FC2_FRAMERATE_1240, 98	FC2_MODE_20, 100
FC2 FRAMERATE 30, 98	FC2_MODE_21, 100
FC2_FRAMERATE_3_75, 98	FC2_MODE_22, 100
FC2_FRAMERATE_60, 98	FC2_MODE_23, 100
FC2_FRAMERATE_7_5, 98	FC2_MODE_24, 100
FC2_FRAMERATE_FORCE_32BIT-	FC2_MODE_25, 100
S, 98	FC2_MODE_26, 100
FC2_FRAMERATE_FORMAT7, 98	FC2_MODE_27, 100
FC2_FRAME_RATE, 102	FC2_MODE_28, 100
FC2_FROM_FILE_EXT, 99	FC2_MODE_29, 100
FC2_GAIN, 102	FC2_MODE_3, 100
FC2_GAMMA, 102	FC2_MODE_30, 100
FC2_GRAB_MODE_FORCE_32BI-	FC2_MODE_31, 100
TS, 99	FC2_MODE_4, 100
FC2_GRAB_TIMEOUT_FORCE	FC2_MODE_5, 100
32BITS, 99	FC2_MODE_6, 100
FC2_HEARTBEAT, 98	FC2_MODE_7, 100
FC2_HEARTBEAT_TIMEOUT, 98	FC2_MODE_8, 100
FC2_HQ_LINEAR, 96	FC2_MODE_9, 100
FC2_HUE, 102	FC2_MODE_FORCE_32BITS, 100
FC2_IMAGE_FILE_FORMAT_FOR-	FC2_NEAREST_NEIGHBOR_FAS-
CE_32BITS, 99	T, 96
FC2_INTERFACE_GIGE, 99	FC2_NO_COLOR_PROCESSING,
FC2_INTERFACE_IEEE1394, 99	96
FC2_INTERFACE_TYPE_FORCE 32BITS, 99	FC2_NUM_FRAMERATES, 98 FC2_NUM_MODES, 100
FC2_INTERFACE_UNKNOWN, 99	FC2_NUM_PIXEL_FORMATS, 102
FC2_INTERFACE_USB_2, 99	FC2_NUM_VIDEOMODES, 104

FC2_OSTYPE_FORCE_32BITS,	FC2_STATISTICS_BLUE, 102
101	FC2_STATISTICS_FORCE_32BIT-
FC2_PAN, 102	S, 103
FC2_PCIE_BUSSPEED_2_5, 101	FC2_STATISTICS_GREEN, 102
FC2_PCIE_BUSSPEED_5_0, 101	FC2_STATISTICS_GREY, 102
FC2_PCIE_BUSSPEED_FORCE	FC2_STATISTICS_HUE, 102
32BITS, 101	FC2_STATISTICS_LIGHTNESS,
FC2_PCIE_BUSSPEED_UNKNOW-	103
N, 101	FC2_STATISTICS_RED, 102
FC2_PGM, 99	FC2_STATISTICS_SATURATION,
FC2_PIXEL_FORMAT_411YUV8,	103
101	FC2_TEMPERATURE, 102
FC2_PIXEL_FORMAT_422YUV8,	FC2_TIFF, 99
101	FC2_TIFF_ADOBE_DEFLATE, 103
FC2_PIXEL_FORMAT_422YUV8_J-	FC2_TIFF_CCITTFAX3, 103
PEG, 102	FC2_TIFF_CCITTFAX4, 103
FC2_PIXEL_FORMAT_444YUV8,	FC2_TIFF_DEFLATE, 103
101	FC2_TIFF_JPEG, 103
FC2_PIXEL_FORMAT_BGR, 101	FC2_TIFF_LZW, 103
FC2_PIXEL_FORMAT_BGR16, 102	FC2_TIFF_NONE, 103
FC2_PIXEL_FORMAT_BGRU, 101	FC2_TIFF_PACKBITS, 103
FC2_PIXEL_FORMAT_BGRU16,	FC2_TILT, 102
102	FC2_TIMEOUT_INFINITE, 99
FC2_PIXEL_FORMAT_MONO12,	FC2_TIMEOUT_NONE, 99
101	FC2_TIMEOUT_UNSPECIFIED, 99
FC2_PIXEL_FORMAT_MONO16,	FC2_TRIGGER_DELAY, 102
101	FC2_TRIGGER_MODE, 102
FC2_PIXEL_FORMAT_MONO8,	FC2_UNKNOWN_OS, 101
101	FC2_UNSPECIFIED_GRAB_MOD-
FC2_PIXEL_FORMAT_RAW12, 101	E, 99
FC2_PIXEL_FORMAT_RAW16, 101	FC2_UNSPECIFIED_PIXEL_FOR-
FC2_PIXEL_FORMAT_RAW8, 101	MAT, 102
FC2_PIXEL_FORMAT_RGB, 101	FC2_UNSPECIFIED_PROPERTY_
FC2_PIXEL_FORMAT_RGB16, 101	TYPE, 102
FC2_PIXEL_FORMAT_RGB8, 101	FC2_VIDEOMODE_1024x768RGB,
FC2_PIXEL_FORMAT_RGBU, 101	103
FC2_PIXEL_FORMAT_S_MONO16,	FC2_VIDEOMODE_1024x768Y16,
101	103
FC2_PIXEL_FORMAT_S_RGB16,	FC2_VIDEOMODE_1024x768Y8,
101	103
FC2_PNG, 99	FC2_VIDEOMODE_1024x768YU-
FC2_PPM, 99	V422, 103
FC2_PROPERTY_TYPE_FORCE	FC2_VIDEOMODE_1280x960RGB,
32BITS, 102	103
FC2_RAW, 99	FC2_VIDEOMODE_1280x960Y16,
FC2_REMOVAL, 95	103
FC2_RIGOROUS, 96	FC2_VIDEOMODE_1280x960Y8,
FC2_SATURATION, 102	103
FC2_SHARPNESS, 102	FC2_VIDEOMODE_1280x960YU-
FC2_SHUTTER, 102	V422, 103

FC2_VIDEOMODE_1600x1200RG-	SYNC_MESSAGE_FAILED, 113
B, 104	SYNC_MESSAGE_NOMASTER,
FC2_VIDEOMODE_1600x1200Y16,	113
104	SYNC_MESSAGE_NOT_ENOUGH
FC2_VIDEOMODE_1600x1200Y8,	_DEVICES, 113
104	SYNC_MESSAGE_NOT_INITIALIZ
FC2_VIDEOMODE_1600x1200YU-	ED, 113
V422, 104	SYNC_MESSAGE_OK, 113
FC2_VIDEOMODE_160x120YU-	SYNC_MESSAGE_STARTED, 113
V444, 103	SYNC_MESSAGE_STOPPED, 113
FC2_VIDEOMODE_320x240YU-	SYNC_MESSAGE_SYNCING, 113
V422, 103	SYNC_MESSAGE_THREAD_ERR
FC2_VIDEOMODE_640x480RGB,	OR, 113
103	SYNC_MESSAGE_UNKNOWN_E-
FC2_VIDEOMODE_640x480Y16,	RROR, 113
103	SYNC_ERROR_ALREADY_STARTED
FC2_VIDEOMODE_640x480Y8, 103	MultiSyncLibraryDefs_C.h, 113
FC2_VIDEOMODE_640x480YU-	SYNC_ERROR_ALREADY_STOPPED
V411, 103	MultiSyncLibraryDefs_C.h, 113
FC2_VIDEOMODE_640x480YU-	SYNC_ERROR_CONTEXT_NOT_INITI-
V422, 103	ALIZED
FC2_VIDEOMODE_800x600RGB,	MultiSyncLibraryDefs_C.h, 113
103	SYNC_ERROR_FAILED
FC2_VIDEOMODE_800x600Y16,	MultiSyncLibraryDefs_C.h, 113
103	SYNC_ERROR_OK
FC2_VIDEOMODE_800x600Y8, 103	MultiSyncLibraryDefs_C.h, 113
FC2_VIDEOMODE_800x600YU-	SYNC_ERROR_UNKNOWN_ERROR
V422, 103	MultiSyncLibraryDefs_C.h, 113
FC2_VIDEOMODE_FORCE_32BIT-	SYNC_MESSAGE_BUS_RESET
S, 104	MultiSyncLibraryDefs_C.h, 113
FC2_VIDEOMODE_FORMAT7, 104	SYNC_MESSAGE_DEVICE_ERROR
FC2_WHITE_BALANCE, 102	MultiSyncLibraryDefs_C.h, 113
FC2_WINDOWS_X64, 101	SYNC_MESSAGE_FAILED
FC2_WINDOWS_X86, 101	MultiSyncLibraryDefs_C.h, 113
FC2_ZOOM, 102	SYNC_MESSAGE_NOMASTER
MultiSyncLibraryDefs_C.h	MultiSyncLibraryDefs_C.h, 113
SYNC_ERROR_ALREADY_START-	SYNC_MESSAGE_NOT_ENOUGH_DE
ED, 113	VICES
SYNC_ERROR_ALREADY_STOP-	MultiSyncLibraryDefs_C.h, 113
PED, 113	SYNC_MESSAGE_NOT_INITIALIZED
SYNC_ERROR_CONTEXT_NOT_I-	MultiSyncLibraryDefs_C.h, 113
NITIALIZED, 113	SYNC_MESSAGE_OK
SYNC_ERROR_FAILED, 113	MultiSyncLibraryDefs_C.h, 113
SYNC_ERROR_OK, 113	SYNC_MESSAGE_STARTED
SYNC_ERROR_UNKNOWN_ERR-	MultiSyncLibraryDefs C.h, 113
OR, 113	SYNC MESSAGE STOPPED
SYNC_MESSAGE_BUS_RESET,	MultiSyncLibraryDefs C.h, 113
113	SYNC_MESSAGE_SYNCING
SYNC_MESSAGE_DEVICE_ERRO-	MultiSyncLibraryDefs_C.h, 113
R, 113	SYNC_MESSAGE_THREAD_ERROR

MultiSyncLibraryDefs_C.h, 113	fc2Disonnect, 105
SYNC_MESSAGE_UNKNOWN_ERROR	fc2GUIConnect, 105
MultiSyncLibraryDefs_C.h, 113	fc2Hide, 105
BOOL	fc2IsVisible, 106
FlyCapture2Defs_C.h, 94	fc2Show, 106
MultiSyncLibraryDefs_C.h, 112	fc2ShowModal, 106
FALSE	FlyCapture2Internal_C.h, 107
FlyCapture2Defs_C.h, 93	IsContextValid, 107
MultiSyncLibraryDefs_C.h, 112	IsGuiContextValid, 107
FULL_32BIT_VALUE	SyncCppImageToStruct, 107
FlyCapture2Defs_C.h, 93	FlyCapture2Platform_C.h, 107
MultiSyncLibraryDefs_C.h, 112	FlyCapture2_C.h, 37
FlyCapture2Defs_C.h, 89	fc2AVIAppend, 46
BOOL, 94	fc2AVIClose, 46
FALSE, 93	fc2AVIOpen, 46
TRUE, 93	fc2CalculateImageStatistics, 47
fc2AVIContext, 94	fc2Connect, 47
fc2AsyncCommandCallback, 94	fc2ConvertImage, 47
fc2BandwidthAllocation, 94	fc2ConvertImageTo, 48
fc2BayerTileFormat, 95	fc2CreateAVI, 48
fc2BusCallbackType, 95	fc2CreateContext, 48
fc2BusEventCallback, 94	fc2CreateGigEContext, 49
fc2BusSpeed, 95	fc2CreateImage, 49
fc2ByteOrder, 95	fc2CreateImageStatistics, 49
fc2CallbackHandle, 94	fc2DestroyAVI, 50
fc2ColorProcessingAlgorithm, 96	fc2DestroyContext, 50
fc2Context, 94	fc2DestroyImage, 50
fc2DriverType, 96	fc2DestroyImageStatistics, 51
fc2Error, 96	fc2DetermineBitsPerPixel, 51
fc2FrameRate, 98	fc2Disconnect, 51
fc2GigEPropertyType, 98	fc2DiscoverGigECameras, 51
fc2GrabMode, 98	fc2EnableLUT, 52
fc2GrabTimeout, 99	fc2ErrorToDescription, 52
fc2GuiContext, 94	fc2FireBusReset, 52
fc2ImageEventCallback, 94	fc2FireSoftwareTrigger, 53
fc2ImageFileFormat, 99	fc2FireSoftwareTriggerBroadcast, 53
fc2ImageImpl, 94	fc2ForceAllIPAddressesAutomatically
fc2ImageStatisticsContext, 94	53
fc2InterfaceType, 99	fc2ForceIPAddressAutomatically, 54
fc2Mode, 99	fc2ForceIPAddressToCamera, 54
fc2OSType, 100	fc2GetActiveLUTBank, 54
fc2PCleBusSpeed, 101	fc2GetCameraFromIndex, 55
fc2PixelFormat, 101	fc2GetCameraFromSerialNumber,
fc2PropertyType, 102	55
fc2StatisticsChannel, 102	fc2GetCameraInfo, 55
fc2TIFFCompressionMethod, 103	fc2GetCameraSerialNumberFrom-
fc2VideoMode, 103	Index, 56
FlyCapture2GUI_C.h, 104	fc2GetConfiguration, 56
fc2CreateGUIContext, 104	fc2GetCycleTime, 56
fc2DestroyGUIContext, 105	fc2GetDefaultColorProcessing, 57

fc2GetDefaultOutputFormat, 57	fc2ReadGVCPRegisterBlock, 72
fc2GetDeviceFromIndex, 57	fc2ReadRegister, 72
fc2GetEmbeddedImageInfo, 58	fc2ReadRegisterBlock, 72
fc2GetFormat7Configuration, 58	fc2RegisterCallback, 73
fc2GetFormat7Info, 59	fc2RescanBus, 73
fc2GetGPIOPinDirection, 60	fc2RestoreFromMemoryChannel, 73
fc2GetGigEConfig, 59	fc2RetrieveBuffer, 74
fc2GetGigEImageBinningSettings,	fc2SaveImage, 74
59	fc2SaveImageWithOption, 74
fc2GetGigEImageSettings, 59	fc2SaveToMemoryChannel, 75
fc2GetGigEImageSettingsInfo, 59	fc2SetActiveLUTBank, 75
fc2GetGigEImagingMode, 59	fc2SetCallback, 75
fc2GetGigEProperty, 59	fc2SetConfiguration, 76
fc2GetGigEStreamChannelInfo, 60	fc2SetDefaultColorProcessing, 76
fc2GetImageData, 60	fc2SetDefaultOutputFormat, 76
fc2GetImageStatistics, 61	fc2SetEmbeddedImageInfo, 77
fc2GetImageTimeStamp, 61	fc2SetFormat7Configuration, 77
fc2GetInterfaceTypeFromGuid, 61	fc2SetFormat7ConfigurationPacket,
fc2GetLUTBankInfo, 62	77
fc2GetLUTChannel, 63	fc2SetGPIOPinDirection, 78
fc2GetLUTInfo, 63	fc2SetGPIOPinDirectionBroadcast,
fc2GetLibraryVersion, 62	79
fc2GetMemoryChannel, 63	fc2SetGigEConfig, 78
fc2GetMemoryChannelInfo, 64	fc2SetGigEImageBinningSettings,
fc2GetNumOfCameras, 64	78
fc2GetNumOfDevices, 64	fc2SetGigEImageSettings, 78
fc2GetNumStreamChannels, 65	fc2SetGigEImagingMode, 78
fc2GetProperty, 65	fc2SetGigEProperty, 78
fc2GetPropertyInfo, 65	fc2SetGigEStreamChannelInfo, 78
fc2GetRegisterString, 65	fc2SetImageData, 79
fc2GetStrobe, 66	fc2SetImageDimensions, 80
fc2GetStrobeInfo, 66	fc2SetLUTChannel, 80
fc2GetSystemInfo, 66	fc2SetProperty, 80
fc2GetTriggerDelay, 67	fc2SetPropertyBroadcast, 81
fc2GetTriggerDelayInfo, 67	fc2SetStrobe, 81
fc2GetTriggerMode, 67	fc2SetStrobeBroadcast, 81
fc2GetTriggerModeInfo, 67	fc2SetTriggerDelay, 82
fc2GetVideoModeAndFrameRate, 68	fc2SetTriggerDelayBroadcast, 82
fc2GetVideoModeAndFrameRate-	fc2SetTriggerMode, 82
Info, 68	fc2SetTriggerModeBroadcast, 83
fc2H264Open, 69	fc2SetUserBuffers, 83
fc2lsCameraControlable, 69	fc2SetVideoModeAndFrameRate, 83
fc2LaunchBrowser, 69	fc2StartCapture, 84
fc2LaunchCommand, 70	fc2StartCaptureCallback, 84
fc2LaunchCommandAsync, 70	fc2StartSyncCapture, 85
fc2LaunchHelp, 70	fc2StartSyncCaptureCallback, 85
fc2MJPGOpen, 70	fc2StopCapture, 85
fc2QueryGigEImagingMode, 71	fc2UnregisterCallback, 86
fc2ReadGVCPMemory, 71	fc2ValidateFormat7Settings, 86
fc2ReadGVCPRegister, 71	fc2WriteGVCPMemory, 86

fc2WriteGVCPRegister, 87	fc2TriggerDelayInfo, 33
fc2WriteGVCPRegisterBlock, 87	absValue
fc2WriteGVCPRegisterBroadcast, 87	fc2TriggerDelay, 32
fc2WriteRegister, 88	applicationIPAddress
fc2WriteRegisterBlock, 88	fc2CameraInfo, 7
fc2WriteRegisterBroadcast, 89	applicationPort
GPIOPinState	fc2CameraInfo, 7
fc2EmbeddedImageInfo, 12	asyncBusSpeed
IsContextValid	fc2Config, 9
FlyCapture2Internal_C.h, 107	autoManualMode
IsGuiContextValid	fc2TriggerDelay, 32
FlyCapture2Internal_C.h, 107	autoSupported
MultiSyncLibraryDefs_C.h, 111	fc2TriggerDelayInfo, 33
BOOL, 112	available
FALSE, 112	fc2EmbeddedImageInfoProperty, 12
TRUE, 112	3 1 <i>7</i> ,
syncContext, 112	bandwidthAllocation
syncError, 113	fc2Config, 9
syncMessage, 113	bayerFormat
MultiSyncLibraryPlatform_C.h, 113	fc2Image, 20
MultiSyncLibrary_C.h, 107	bayerTileFormat
syncCreateContext, 108	fc2CameraInfo, 7
syncDestroyContext, 108	binaryFile
syncDisableCrossPCSynchronization,	fc2PGMOption, 26
109	fc2PPMOption, 28
syncEnableCrossPCSynchronization,	bitrate
109	fc2H264Option, 19
syncGetStatus, 109	brightness
syncGetTimeSinceSynced, 110	fc2EmbeddedImageInfo, 11
synclsTimingBusConnected, 110	build
syncQueryCrossPCSynchronization-	fc2Version, 35
Setting, 110	busNumber
syncRescanMasterTimingBus, 111	fc2CameraInfo, 7
syncStart, 111	byteOrder
syncStop, 111	fc2SystemInfo, 30
ROIPosition	
fc2EmbeddedImageInfo, 12	ccpStatus
SyncCppImageToStruct	fc2CameraInfo, 7
FlyCapture2Internal_C.h, 107	chipldHi
TRUE	fc2ConfigROM, 10
FlyCapture2Defs C.h, 93	chipldLo
MultiSyncLibraryDefs C.h, 112	fc2ConfigROM, 10
, , = ,	cols
absControl	fc2Image, 20
fc2TriggerDelay, 32	compression
absMax	fc2TIFFOption, 31
fc2TriggerDelayInfo, 33	compressionLevel
absMin	fc2PNGOption, 27
fc2TriggerDelayInfo, 33	configROM
absValSupported	fc2CameraInfo, 7

cpuDescription	enabled
fc2SystemInfo, 30	fc2LUTData, 25
cycleCount	exposure
fc2TimeStamp, 31	fc2EmbeddedImageInfo, 11
cycleOffset	
fc2TimeStamp, 31	fc2AVIAppend
cycleSeconds	FlyCapture2_C.h, 46
fc2TimeStamp, 31	fc2AVIClose
	FlyCapture2_C.h, 46
dataSize	fc2AVIContext
fc2Image, 20	FlyCapture2Defs_C.h, 94
defaultGateway	fc2AVIOpen
fc2CameraInfo, 7	FlyCapture2_C.h, 46
delay	fc2AVIOption, 5
fc2StrobeControl, 28	frameRate, 5
destinationIpAddress	reserved, 5
fc2GigEStreamChannel, 18	fc2AsyncCommandCallback
doNotFragment	FlyCapture2Defs_C.h, 94
fc2GigEStreamChannel, 18	fc2BandwidthAllocation
driverList	FlyCapture2Defs_C.h, 94
fc2SystemInfo, 30	fc2BayerTileFormat
driverName	FlyCapture2Defs_C.h, 95
fc2CameraInfo, 7	fc2BusCallbackType
driverType	FlyCapture2Defs_C.h, 95
fc2CameraInfo, 7	fc2BusEventCallback
duration	FlyCapture2Defs_C.h, 94
fc2StrobeControl, 28	fc2BusSpeed
	FlyCapture2Defs_C.h, 95
embeddedBrightness	fc2ByteOrder
fc2ImageMetadata, 21	FlyCapture2Defs_C.h, 95
embeddedExposure	fc2CalculateImageStatistics
fc2ImageMetadata, 21	FlyCapture2_C.h, 47
embeddedFrameCounter	fc2CallbackHandle
fc2ImageMetadata, 21	FlyCapture2Defs_C.h, 94
embeddedGPIOPinState	fc2CameraInfo, 6
fc2ImageMetadata, 21	applicationIPAddress, 7
embeddedGain	applicationPort, 7
fc2ImageMetadata, 21	bayerTileFormat, 7
embeddedROIPosition	busNumber, 7
fc2ImageMetadata, 21	ccpStatus, 7
embeddedShutter	configROM, 7
fc2ImageMetadata, 21	defaultGateway, 7
embeddedStrobePattern	driverName, 7
fc2ImageMetadata, 21	driverType, 7
embeddedTimeStamp	firmwareBuildTime, 7
fc2ImageMetadata, 21	firmwareVersion, 7
embeddedWhiteBalance	gigEMajorVersion, 7
fc2ImageMetadata, 21	gigEMinorVersion, 7
enablePacketResend	iidcVer, 8
fc2GigEConfig, 15	interfaceType, 8

ipAddress, 8	FlyCapture2_C.h, 48
isColorCamera, 8	fc2CreateAVI
macAddress, 8	FlyCapture2_C.h, 48
maximumBusSpeed, 8	fc2CreateContext
modelName, 8	FlyCapture2_C.h, 48
nodeNumber, 8	fc2CreateGUIContext
pcieBusSpeed, 8	FlyCapture2GUI_C.h, 104
reserved, 8	fc2CreateGigEContext
sensorInfo, 8	FlyCapture2_C.h, 49
sensorResolution, 8	fc2CreateImage
serialNumber, 8	FlyCapture2_C.h, 49
subnetMask, 8	fc2CreateImageStatistics
userDefinedName, 8	FlyCapture2_C.h, 49
vendorName, 8	fc2DestroyAVI
xmlURL1, 8	FlyCapture2_C.h, 50
xmlURL2, 8	fc2DestroyContext
fc2ColorProcessingAlgorithm	FlyCapture2_C.h, 50
FlyCapture2Defs_C.h, 96	fc2DestroyGUIContext
fc2Config, 8	FlyCapture2GUI_C.h, 105
asyncBusSpeed, 9	fc2DestroyImage
bandwidthAllocation, 9	FlyCapture2_C.h, 50
grabMode, 9	fc2DestroyImageStatistics
grabTimeout, 9	FlyCapture2 C.h, 51
isochBusSpeed, 9	fc2DetermineBitsPerPixel
minNumImageNotifications, 9	FlyCapture2_C.h, 51
numBuffers, 9	fc2Disconnect
numImageNotifications, 9	FlyCapture2_C.h, 51
registerTimeout, 9	fc2DiscoverGigECameras
registerTimeoutRetries, 9	FlyCapture2_C.h, 51
reserved, 9	fc2Disonnect
fc2ConfigROM, 9	FlyCapture2GUI_C.h, 105
chipldHi, 10	fc2DriverType
chipldLo, 10	FlyCapture2Defs C.h, 96
nodeVendorld, 10	fc2EmbeddedImageInfo, 11
pszKeyword, 10	GPIOPinState, 12
reserved, 10	ROIPosition, 12
unitSWVer, 10	brightness, 11
unitSpecId, 10	exposure, 11
unitSubSWVer, 10	frameCounter, 12
vendorUniqueInfo_0, 10	gain, 12
vendorUniqueInfo_1, 10	shutter, 12
vendorUniqueInfo_2, 10	strobePattern, 12
vendorUniqueInfo_3, 10	timestamp, 12
fc2Connect	whiteBalance, 12
FlyCapture2_C.h, 47	fc2EmbeddedImageInfoProperty, 12
fc2Context	available, 12
FlyCapture2Defs_C.h, 94	onOff, 12
fc2ConvertImage	fc2EnableLUT
FlyCapture2_C.h, 47	FlyCapture2_C.h, 52
fc2ConvertImageTo	fc2Error
102 SOLIVEI LITTAGE TO	10221101

FlyCapture2Defs_C.h, 96	FlyCapture2_C.h, 55
fc2ErrorToDescription	fc2GetCameraFromSerialNumber
FlyCapture2_C.h, 52	FlyCapture2_C.h, 55
fc2FireBusReset	fc2GetCameraInfo
FlyCapture2_C.h, 52	FlyCapture2_C.h, 55
fc2FireSoftwareTrigger	fc2GetCameraSerialNumberFromIndex
FlyCapture2_C.h, 53	FlyCapture2_C.h, 56
fc2FireSoftwareTriggerBroadcast	fc2GetConfiguration
FlyCapture2_C.h, 53	FlyCapture2_C.h, 56
fc2ForceAllIPAddressesAutomatically	fc2GetCycleTime
FlyCapture2 C.h, 53	FlyCapture2_C.h, 56
fc2ForceIPAddressAutomatically	fc2GetDefaultColorProcessing
FlyCapture2_C.h, 54	FlyCapture2_C.h, 57
fc2ForceIPAddressToCamera	fc2GetDefaultOutputFormat
FlyCapture2_C.h, 54	FlyCapture2_C.h, 57
fc2Format7ImageSettings, 12	fc2GetDeviceFromIndex
height, 13	FlyCapture2_C.h, 57
mode, 13	fc2GetEmbeddedImageInfo
offsetX, 13	FlyCapture2_C.h, 58
offsetY, 13	fc2GetFormat7Configuration
pixelFormat, 13	FlyCapture2 C.h, 58
reserved, 13	fc2GetFormat7Info
width, 13 fc2Format7Info, 13	FlyCapture2_C.h, 59
•	fc2GetGPIOPinDirection
imageHStepSize, 14	FlyCapture2_C.h, 60
imageVStepSize, 14	fc2GetGigEConfig
maxHeight, 14	FlyCapture2_C.h, 59
maxPacketSize, 14	fc2GetGigEImageBinningSettings
maxWidth, 14	FlyCapture2_C.h, 59
minPacketSize, 14	fc2GetGigEImageSettings
mode, 14	FlyCapture2_C.h, 59
offsetHStepSize, 14	fc2GetGigEImageSettingsInfo
offsetVStepSize, 14	FlyCapture2_C.h, 59
packetSize, 14	fc2GetGigEImagingMode
percentage, 14	FlyCapture2_C.h, 59
pixelFormatBitField, 14	fc2GetGigEProperty
reserved, 14	FlyCapture2_C.h, 59
vendorPixelFormatBitField, 14	fc2GetGigEStreamChannelInfo
fc2Format7PacketInfo, 14	FlyCapture2_C.h, 60
maxBytesPerPacket, 14	fc2GetImageData
recommendedBytesPerPacket, 15	FlyCapture2_C.h, 60
reserved, 15	fc2GetImageStatistics
unitBytesPerPacket, 15	FlyCapture2_C.h, 61
fc2FrameRate	fc2GetImageTimeStamp
FlyCapture2Defs_C.h, 98	FlyCapture2_C.h, 61
fc2GUIConnect	fc2GetInterfaceTypeFromGuid
FlyCapture2GUI_C.h, 105	FlyCapture2_C.h, 61
fc2GetActiveLUTBank	fc2GetLUTBankInfo
FlyCapture2_C.h, 54	FlyCapture2_C.h, 62
fc2GetCameraFromIndex	fc2GetLUTChannel

FlyCapture2_C.h, 63	width, 16
fc2GetLUTInfo	fc2GigEImageSettingsInfo, 16
FlyCapture2_C.h, 63	imageHStepSize, 17
fc2GetLibraryVersion	imageVStepSize, 17
FlyCapture2_C.h, 62	maxHeight, 17
fc2GetMemoryChannel	maxWidth, 17
FlyCapture2_C.h, 63	offsetHStepSize, 17
fc2GetMemoryChannelInfo	offsetVStepSize, 17
FlyCapture2_C.h, 64	pixelFormatBitField, 17
fc2GetNumOfCameras	reserved, 17
FlyCapture2_C.h, 64	vendorPixelFormatBitField, 17
fc2GetNumOfDevices	fc2GigEProperty, 17
FlyCapture2_C.h, 64	isReadable, 17
fc2GetNumStreamChannels	isWritable, 17
FlyCapture2_C.h, 65	max, 17
fc2GetProperty	min, 17
FlyCapture2_C.h, 65	propType, 17
fc2GetPropertyInfo	reserved, 18
FlyCapture2_C.h, 65	value, 18
fc2GetRegisterString	fc2GigEPropertyType
FlyCapture2_C.h, 65	FlyCapture2Defs_C.h, 98
fc2GetStrobe	fc2GigEStreamChannel, 18
FlyCapture2_C.h, 66	destinationIpAddress, 18
fc2GetStrobeInfo	doNotFragment, 18
FlyCapture2_C.h, 66	hostPost, 19
fc2GetSystemInfo	interPacketDelay, 19
FlyCapture2_C.h, 66	networkInterfaceIndex, 19
fc2GetTriggerDelay	packetSize, 19
FlyCapture2_C.h, 67	reserved, 19
fc2GetTriggerDelayInfo	sourcePort, 19
FlyCapture2_C.h, 67	fc2GrabMode
fc2GetTriggerMode	FlyCapture2Defs_C.h, 98
FlyCapture2_C.h, 67	fc2GrabTimeout
fc2GetTriggerModeInfo	FlyCapture2Defs_C.h, 99
FlyCapture2_C.h, 67	fc2GuiContext
fc2GetVideoModeAndFrameRate	FlyCapture2Defs_C.h, 94
FlyCapture2_C.h, 68	fc2H264Open
fc2GetVideoModeAndFrameRateInfo	FlyCapture2_C.h, 69
FlyCapture2_C.h, 68	fc2H264Option, 19
fc2GigEConfig, 15	bitrate, 19
enablePacketResend, 15	frameRate, 19
maxPacketsToResend, 15	height, 19
reserved, 15	reserved, 19
timeoutForPacketResend, 15	width, 19
fc2GigEImageSettings, 16	fc2Hide
height, 16	FlyCapture2GUI_C.h, 105
offsetX, 16	fc2IPAddress, 23
offsetY, 16	octets, 23
pixelFormat, 16	fc2lmage, 20
reserved, 16	bayerFormat, 20
	·

2012 000	facility of
cols, 20	fc2LUTData, 25
dataSize, 20	enabled, 25
format, 20	inputBitDepth, 25
imageImpl, 20	numBanks, 25
pData, 20	numChannels, 25
receivedDataSize, 20	numEntries, 25
rows, 20	outputBitDepth, 25
stride, 20	reserved, 25
fc2ImageEventCallback	supported, 25
FlyCapture2Defs_C.h, 94	fc2LaunchBrowser
fc2ImageFileFormat	FlyCapture2_C.h, 69
FlyCapture2Defs_C.h, 99	fc2LaunchCommand
fc2ImageImpl	FlyCapture2_C.h, 70
FlyCapture2Defs_C.h, 94	fc2LaunchCommandAsync
fc2ImageMetadata, 20	FlyCapture2_C.h, 70
embeddedBrightness, 21	fc2LaunchHelp
embeddedExposure, 21	FlyCapture2_C.h, 70
embeddedFrameCounter, 21	fc2MACAddress, 25
embeddedGPIOPinState, 21	octets, 25
embeddedGain, 21	fc2MJPGOpen
embeddedROIPosition, 21	FlyCapture2_C.h, 70
embeddedShutter, 21	fc2MJPGOption, 26
embeddedStrobePattern, 21	frameRate, 26
embeddedTimeStamp, 21	quality, <mark>26</mark>
embeddedWhiteBalance, 21	reserved, 26
reserved, 21	fc2Mode
fc2ImageStatisticsContext	FlyCapture2Defs_C.h, 99
FlyCapture2Defs_C.h, 94	fc2OSType
fc2InterfaceType	FlyCapture2Defs_C.h, 100
FlyCapture2Defs_C.h, 99	fc2PCleBusSpeed
fc2InternalContext, 21	FlyCapture2Defs_C.h, 101
pBusMgr, <mark>22</mark>	fc2PGMOption, 26
pCamera, 22	binaryFile, 26
fc2InternalGuiContext, 22	reserved, 26
pCameraControlDlg, 22	fc2PGRGuid, 27
pCameraSelectionDlg, 22	value, 27
fc2InternalImageCallback, 23	fc2PNGOption, 27
pCallback, 23	compressionLevel, 27
pCallbackData, 23	interlaced, 27
fc2IsCameraControlable	reserved, 27
FlyCapture2_C.h, 69	fc2PPMOption, 28
fc2lsVisible	binaryFile, 28
FlyCapture2GUI_C.h, 106	reserved, 28
fc2JPEGOption, 24	fc2PixelFormat
progressive, 24	FlyCapture2Defs_C.h, 101
quality, 24	fc2PropertyType
reserved, 24	FlyCapture2Defs_C.h, 102
fc2JPG2Option, 24	fc2QueryGigEImagingMode
quality, 24	FlyCapture2_C.h, 71
reserved, 24	fc2ReadGVCPMemory

FlyCapture2_C.h, 71	FlyCapture2_C.h, 78
fc2ReadGVCPRegister	fc2SetGigEProperty
FlyCapture2_C.h, 71	FlyCapture2_C.h, 78
fc2ReadGVCPRegisterBlock	fc2SetGigEStreamChannelInfo
FlyCapture2_C.h, 72	FlyCapture2_C.h, 78
fc2ReadRegister	fc2SetImageData
FlyCapture2_C.h, 72	FlyCapture2_C.h, 79
fc2ReadRegisterBlock	fc2SetImageDimensions
FlyCapture2_C.h, 72	FlyCapture2_C.h, 80
fc2RegisterCallback	fc2SetLUTChannel
FlyCapture2_C.h, 73	FlyCapture2_C.h, 80
fc2RescanBus	fc2SetProperty
FlyCapture2_C.h, 73	FlyCapture2_C.h, 80
fc2RestoreFromMemoryChannel	fc2SetPropertyBroadcast
FlyCapture2_C.h, 73	FlyCapture2_C.h, 81
fc2RetrieveBuffer	fc2SetStrobe
FlyCapture2_C.h, 74	FlyCapture2_C.h, 81
fc2SaveImage	fc2SetStrobeBroadcast
FlyCapture2_C.h, 74	FlyCapture2_C.h, 81
fc2SaveImageWithOption	fc2SetTriggerDelay
FlyCapture2_C.h, 74	FlyCapture2_C.h, 82
fc2SaveToMemoryChannel	fc2SetTriggerDelayBroadcast
FlyCapture2_C.h, 75	FlyCapture2_C.h, 82
fc2SetActiveLUTBank	fc2SetTriggerMode
FlyCapture2_C.h, 75	FlyCapture2_C.h, 82
fc2SetCallback	fc2SetTriggerModeBroadcast
FlyCapture2_C.h, 75	FlyCapture2_C.h, 83
fc2SetConfiguration	fc2SetUserBuffers
FlyCapture2_C.h, 76	FlyCapture2_C.h, 83
fc2SetDefaultColorProcessing	fc2SetVideoModeAndFrameRate
FlyCapture2_C.h, 76	FlyCapture2_C.h, 83
fc2SetDefaultOutputFormat	fc2Show
FlyCapture2_C.h, 76	FlyCapture2GUI_C.h, 106
fc2SetEmbeddedImageInfo	fc2ShowModal
FlyCapture2_C.h, 77	FlyCapture2GUI_C.h, 106
fc2SetFormat7Configuration	fc2StartCapture
FlyCapture2_C.h, 77	FlyCapture2_C.h, 84
fc2SetFormat7ConfigurationPacket	fc2StartCaptureCallback
FlyCapture2_C.h, 77	FlyCapture2_C.h, 84
fc2SetGPIOPinDirection	fc2StartSyncCapture
FlyCapture2_C.h, 78	FlyCapture2_C.h, 85
fc2SetGPIOPinDirectionBroadcast	fc2StartSyncCaptureCallback
FlyCapture2_C.h, 79	FlyCapture2_C.h, 85
fc2SetGigEConfig	fc2StatisticsChannel
FlyCapture2_C.h, 78	FlyCapture2Defs_C.h, 102
fc2SetGigEImageBinningSettings	fc2StopCapture
FlyCapture2_C.h, 78	FlyCapture2_C.h, 85
fc2SetGigEImageSettings	fc2StrobeControl, 28
FlyCapture2_C.h, 78	delay, 28
fc2SetGigEImagingMode	duration, 28

onOff, 28	absMax, 33
polarity, 28	absMin, 33
reserved, 28	absValSupported, 33
source, 28	autoSupported, 33
fc2StrobeInfo, 29	manualSupported, 33
maxValue, 29	max, 33
minValue, 29	min, 33
onOffSupported, 29	onOffSupported, 33
polaritySupported, 29	onePushSupported, 33
present, 29	pUnitAbbr, 33
readOutSupported, 29	pUnits, 33
reserved, 29	present, 33
source, 29	readOutSupported, 33
fc2SystemInfo, 29	reserved, 33
byteOrder, 30	type, <mark>33</mark>
cpuDescription, 30	fc2TriggerMode, 34
driverList, 30	mode, 34
gpuDescription, 30	onOff, 34
libraryList, 30	parameter, 34
numCpuCores, 30	polarity, 34
osDescription, 30	reserved, 34
osType, 30	source, 34
reserved, 30	fc2TriggerModeInfo, 34
screenHeight, 30	modeMask, 35
screenWidth, 30	onOffSupported, 35
sysMemSize, 30	polaritySupported, 35
fc2TIFFCompressionMethod	present, 35
FlyCapture2Defs_C.h, 103	readOutSupported, 35
fc2TIFFOption, 30	reserved, 35
compression, 31	softwareTriggerSupported, 35
reserved, 31	sourceMask, 35
fc2TimeStamp, 31	valueReadable, 35
cycleCount, 31	fc2UnregisterCallback
cycleOffset, 31	FlyCapture2_C.h, 86
cycleSeconds, 31	fc2ValidateFormat7Settings
microSeconds, 31	FlyCapture2_C.h, 86
reserved, 31	fc2Version, 35
seconds, 31	build, 35
fc2TriggerDelay, 31	major, 35
absControl, 32	minor, 35
absValue, 32	type, 35
autoManualMode, 32	fc2VideoMode
onOff, 32	FlyCapture2Defs_C.h, 103
onePush, 32	fc2WriteGVCPMemory
present, 32	FlyCapture2_C.h, 86
reserved, 32	fc2WriteGVCPRegister
type, 32	FlyCapture2_C.h, 87
valueA, 32	fc2WriteGVCPRegisterBlock
valueB, 32	FlyCapture2_C.h, 87
fc2TriggerDelayInfo, 32	fc2WriteGVCPRegisterBroadcast

FlyCapture2_C.h, 87	inputBitDepth
fc2WriteRegister	fc2LUTData, 25
FlyCapture2_C.h, 88	interPacketDelay
fc2WriteRegisterBlock	fc2GigEStreamChannel, 19
FlyCapture2_C.h, 88	interfaceType
fc2WriteRegisterBroadcast	fc2CameraInfo, 8
FlyCapture2_C.h, 89	interlaced
firmwareBuildTime	fc2PNGOption, 27
fc2CameraInfo, 7	ipAddress
firmwareVersion	fc2CameraInfo, 8
fc2CameraInfo, 7	isColorCamera
format	fc2CameraInfo, 8
	isReadable
fc2Image, 20	
frameCounter	fc2GigEProperty, 17
fc2EmbeddedImageInfo, 12	isWritable
frameRate	fc2GigEProperty, 17
fc2AVIOption, 5	isochBusSpeed
fc2H264Option, 19	fc2Config, 9
fc2MJPGOption, 26	
	libraryList
gain	fc2SystemInfo, 30
fc2EmbeddedImageInfo, 12	
gigEMajorVersion	macAddress
fc2CameraInfo, 7	fc2CameraInfo, 8
gigEMinorVersion	major
fc2CameraInfo, 7	fc2Version, 35
gpuDescription	manualSupported
fc2SystemInfo, 30	fc2TriggerDelayInfo, 33
grabMode	max
fc2Config, 9	fc2GigEProperty, 17
grabTimeout	fc2TriggerDelayInfo, 33
fc2Config, 9	maxBytesPerPacket
,	fc2Format7PacketInfo, 14
height	maxHeight
fc2Format7ImageSettings, 13	fc2Format7Info, 14
fc2GigEImageSettings, 16	fc2GigElmageSettingsInfo, 17
fc2H264Option, 19	maxPacketSize
hostPost	fc2Format7Info, 14
fc2GigEStreamChannel, 19	maxPacketsToResend
iczdigeotreamonannei, 19	fc2GigEConfig, 15
iidcVer	maxValue
fc2CameraInfo, 8	fc2StrobeInfo, 29
imageHStepSize	maxWidth
fc2Format7Info, 14	fc2Format7Info, 14
fc2GigEImageSettingsInfo, 17	fc2GigEImageSettingsInfo, 17
imageImpl	maximumBusSpeed
fc2Image, 20	fc2CameraInfo, 8
imageVStepSize	microSeconds
fc2Format7Info, 14	fc2TimeStamp, 31
fc2GigEImageSettingsInfo, 17	min

fc2GigEProperty, 17	offsetY
fc2TriggerDelayInfo, 33	fc2Format7ImageSettings, 13
minNumImageNotifications	fc2GigEImageSettings, 16
fc2Config, 9	onOff
minPacketSize	fc2EmbeddedImageInfoProperty, 12
fc2Format7Info, 14	fc2StrobeControl, 28
minValue	fc2TriggerDelay, 32
fc2StrobeInfo, 29	fc2TriggerMode, 34
minor	onOffSupported
fc2Version, 35	fc2StrobeInfo, 29
mode	fc2TriggerDelayInfo, 33
fc2Format7ImageSettings, 13	fc2TriggerModeInfo, 35
fc2Format7Info, 14	onePush
fc2TriggerMode, 34	fc2TriggerDelay, 32
modeMask	onePushSupported
fc2TriggerModeInfo, 35	fc2TriggerDelayInfo, 33
modelName	osDescription
fc2CameraInfo, 8	fc2SystemInfo, 30
	osType
networkInterfaceIndex	fc2SystemInfo, 30
fc2GigEStreamChannel, 19	outputBitDepth
nodeNumber	fc2LUTData, 25
fc2CameraInfo, 8	5
nodeVendorld	pBusMgr
fc2ConfigROM, 10	fc2InternalContext, 22
numBanks	pCallback
fc2LUTData, 25	fc2InternalImageCallback, 23
numBuffers	pCallbackData
fc2Config, 9	fc2InternalImageCallback, 23
numChannels	pCamera
fc2LUTData, 25	fc2InternalContext, 22
numCpuCores	pCameraControlDlg
fc2SystemInfo, 30	fc2InternalGuiContext, 22
numEntries	pCameraSelectionDlg
fc2LUTData, 25	fc2InternalGuiContext, 22
numImageNotifications	pData
fc2Config, 9	fc2Image, 20
	pUnitAbbr
octets	fc2TriggerDelayInfo, 33
fc2IPAddress, 23	pUnits
fc2MACAddress, 25	fc2TriggerDelayInfo, 33
offsetHStepSize	packetSize
fc2Format7Info, 14	fc2Format7Info, 14
fc2GigEImageSettingsInfo, 17	fc2GigEStreamChannel, 19
offsetVStepSize	parameter
fc2Format7Info, 14	fc2TriggerMode, 34
fc2GigEImageSettingsInfo, 17	pcieBusSpeed
offsetX	fc2CameraInfo, 8
fc2Format7ImageSettings, 13	percentage
fc2GigEImageSettings, 16	fc2Format7Info, 14

pixelFormat	fc2GigEImageSettings, 16
fc2Format7ImageSettings, 13	fc2GigEImageSettingsInfo, 17
fc2GigEImageSettings, 16	fc2GigEProperty, 18
pixelFormatBitField	fc2GigEStreamChannel, 19
fc2Format7Info, 14	fc2H264Option, 19
fc2GigEImageSettingsInfo, 17	fc2ImageMetadata, 21
polarity	fc2JPEGOption, 24
fc2StrobeControl, 28	fc2JPG2Option, 24
	•
fc2TriggerMode, 34	fc2LUTData, 25
polaritySupported	fc2MJPGOption, 26
fc2StrobeInfo, 29	fc2PGMOption, 26
fc2TriggerModeInfo, 35	fc2PNGOption, 27
present	fc2PPMOption, 28
fc2StrobeInfo, 29	fc2StrobeControl, 28
fc2TriggerDelay, 32	fc2StrobeInfo, 29
fc2TriggerDelayInfo, 33	fc2SystemInfo, 30
fc2TriggerModeInfo, 35	fc2TIFFOption, 31
progressive	fc2TimeStamp, 31
fc2JPEGOption, 24	fc2TriggerDelay, 32
propType	fc2TriggerDelayInfo, 33
fc2GigEProperty, 17	fc2TriggerMode, 34
pszKeyword	fc2TriggerModeInfo, 35
fc2ConfigROM, 10	rows
iczonnighow, to	
quality	fc2Image, 20
quality	screenHeight
fc2JPEGOption, 24	_
fc2JPG2Option, 24	fc2SystemInfo, 30
fc2MJPGOption, 26	screenWidth
10.10	fc2SystemInfo, 30
readOutSupported	seconds
fc2StrobeInfo, 29	fc2TimeStamp, 31
fc2TriggerDelayInfo, 33	sensorInfo
fc2TriggerModeInfo, 35	fc2CameraInfo, 8
receivedDataSize	sensorResolution
fc2Image, 20	fc2CameraInfo, 8
recommendedBytesPerPacket	serialNumber
fc2Format7PacketInfo, 15	fc2CameraInfo, 8
registerTimeout	shutter
fc2Config, 9	fc2EmbeddedImageInfo, 12
registerTimeoutRetries	softwareTriggerSupported
fc2Config, 9	fc2TriggerModeInfo, 35
reserved	source
fc2AVIOption, 5	fc2StrobeControl, 28
fc2CameraInfo, 8	fc2StrobeInfo, 29
fc2Config, 9	fc2TriggerMode, 34
fc2ConfigROM, 10	sourceMask
_	
fc2Format7ImageSettings, 13	fc2TriggerModeInfo, 35
fc2Format7PacketInfo, 15	sourcePort
fc2Format7PacketInfo, 15	fc2GigEStreamChannel, 19
fc2GigEConfig, 15	stride

fc2Image, 20	unitSWVer
strobePattern	fc2ConfigROM, 10
fc2EmbeddedImageInfo, 12	unitSpecId
subnetMask	fc2ConfigROM, 10
fc2CameraInfo, 8	unitSubSWVer
supported	fc2ConfigROM, 10
fc2LUTData, 25	userDefinedName
syncContext	fc2CameraInfo, 8
MultiSyncLibraryDefs_C.h, 112	
syncCreateContext	value
MultiSyncLibrary_C.h, 108	fc2GigEProperty, 18
syncDestroyContext	fc2PGRGuid, 27
MultiSyncLibrary_C.h, 108	valueA
syncDisableCrossPCSynchronization	fc2TriggerDelay, 32
MultiSyncLibrary_C.h, 109	valueB
syncEnableCrossPCSynchronization	fc2TriggerDelay, 32
MultiSyncLibrary_C.h, 109	valueReadable
syncError	fc2TriggerModeInfo, 35
MultiSyncLibraryDefs_C.h, 113	vendorName
syncGetStatus	fc2CameraInfo, 8
MultiSyncLibrary_C.h, 109	vendorPixelFormatBitField
syncGetTimeSinceSynced	fc2Format7Info, 14
MultiSyncLibrary_C.h, 110	fc2GigEImageSettingsInfo, 17
synclsTimingBusConnected	vendorUniqueInfo_0
MultiSyncLibrary_C.h, 110	fc2ConfigROM, 10
syncMessage	vendorUniqueInfo_1
MultiSyncLibraryDefs_C.h, 113	fc2ConfigROM, 10
syncQueryCrossPCSynchronization-	vendorUniqueInfo_2
Setting	fc2ConfigROM, 10
MultiSyncLibrary_C.h, 110	vendorUniqueInfo_3
syncRescanMasterTimingBus	fc2ConfigROM, 10
MultiSyncLibrary_C.h, 111	outsite Delevere
syncStart	whiteBalance
MultiSyncLibrary_C.h, 111	fc2EmbeddedImageInfo, 12
syncStop	width
MultiSyncLibrary_C.h, 111	fc2Format7ImageSettings, 13
sysMemSize	fc2GigEImageSettings, 16
fc2SystemInfo, 30	fc2H264Option, 19
	xmlURL1
timeoutForPacketResend	fc2CameraInfo, 8
fc2GigEConfig, 15	xmlURL2
timestamp	fc2CameraInfo, 8
fc2EmbeddedImageInfo, 12	io-oumorumo, o
type	
fc2TriggerDelay, 32	
fc2TriggerDelayInfo, 33	
fc2Version, 35	
70 L D D L .	
unitBytesPerPacket	
fc2Format7PacketInfo, 15	