3 NOTE *3:LHD J/B *4:RHD *9: WHEN CONNECTOR NO. C-107 HAS 18 PINS. ETACS-ECU FUSE 12 * 10 : WHEN CONNECTOR NO. C-107 (C-316)2 W HAS 22 PINS. J/C(4) (FUSE 15) J/C(4) (FUSE 13) 56 65 2 13 (C-303) R-L <T>0. 35G <T>0.35B 9*10 7*9 20*10 16*9 J/C (CAN2) (C-107)8*10 6*9 19*10 21*¹⁰ 17*⁹ 10*¹⁰ 8*⁹ 15*9 <T>(BR-R) $\langle T \rangle (R-W)$ <T>0.35V <T>0.35Y 0.35L W-R 15 14 16 14 DIAGNOSIS CONNECTOR (CANL) (CANH) (IG+) (B+B) 5 (C-113)CAN FRONT TRANSCEIVER B-R B-R **CIRCUIT** LED DRIVE CIRCUIT CPU 4 *3 3 *4 COMBINATION METER C-10 (C-107)(C-113) FRONT SIDE (C-303)(C-10)***9 *** 10 MU801857 1 2 3 4 5 6 7 8 9 1011 1213141516171819202122 MU803797 SIDE 1 2 3 4 5 6 7 8 9 101111213141516 AMP 1 2 3 4 5 6 7 8 9 1011112 131415161718192021222324 1 2 3 4 5 6 7 8 9 1011121314 10 11 12 13 14 15 16 17 18 (C-316)

BCJA8564AB