

axi_dma_0
S_AXI_LITE
S_AXIS_S2MM
s_axi_lite_aclk
m_axi_mm2s_aclk
m_axi_s2mm_aclk
axi_resetn
M_AXI_MM2S
M_AXI_S2MM
M_AXIS_MM2S
mm2s_prmry_reset_out_n
s2mm_prmry_reset_out_n
mm2s_introut
s2mm_introut
AXI Direct Memory Access
axi_mem_intercon
S00_AXI
S01_AXI
ACLK
ARESETN
S00_ACLK
S00_ARESETN
M00_ACLK
M00_ARESETN
S01_ACLK
S01_ARESETN
M00_AXI
AXI Interconnect (Discontinued)
processing_system7_0
S_AXI_HP0_FIFO_CTRL
S_AXI_HP0
M_AXI_GP0_ACLK
S_AXI_HP0_ACLK
DDR
FIXED_IO
USBIND_0
M_AXI_GP0
FCLK_CLK0
FCLK_RESET0_N
ZYNQ7 Processing System
DDR
FIXED_IO
axi_smc
S00_AXI
aclk
aresetn
M00_AXI
M01_AXI
AXI SmartConnect
FFT_512_l_ip_stream_0
AXI4_Lite
AXI4_Stream_Slave
IPCORE_CLK
IPCORE_RESETN
AXI4_Lite_ACLK
AXI4_Lite_ARESETN
AXI4_Stream_Master
FFT_512_l_ip_stream_2x2
rst_ps7_0_100M
slowest_sync_clk
ext_reset_in
aux_reset_in
mb_debug_sys_rst
dcm_locked
mb_reset
bus_struct_reset[0:0]
peripheral_reset[0:0]
interconnect_aresetn[0:0]
peripheral_aresetn[0:0]
Processor System Reset
xlconstant_dcm
dout[0:0]
Constant (Discontinued)