## Multi Purpose PWM block

## **Feature supports:**


- Complementary output with programmable deadtime
- Maximum duty cycle/reference limiter
- Use C-block Trunc() for improved timing control


By: Arief Noor Rahman

## The PWM Block Operating Method

ref his carrier X2 log Isense new\_cmc double dtime = 200e-9 double maxref = 4.5 bool cmc0\_vmc1 = 0

The "output" signal then will be connected to deadtime module to then generate the "hi" and "lo" signals





## The Block Example Use Case (CMC and VMC)

