
LED connectors are for "4digit display"
LED_H1 and LED_H2 connect to first digit
LED_H3 and LED_H4 connect to second digit
LED_L1 and LED_L2 connect to third digit
LED_L3 and LED_L4 connect to fourth digit
74LS245
U1
74LS245
U2
74LS574
U3
74LS574
U5
74LVC2G02
U4A
74LVC2G02
U4B
J1
BUS
TR_HIGH
J2
TR_LOW
J3
PWR_FLAG
PWR_FLAG
All control signals active low
Sheet: /
File: TR Register.sch
Title:
Size: A4
Date:
Rev:
KiCad E.D.A. kicad (5.1.4)-1
Id: 1/1