
Gear Box



| G002 Gear Box Center G1 G003 Gear Box Rear G1 G004 Brake Shoe G1 G100 Diffenetial G1 G101 Ball Bearing 8x16x7 G1 | G013 Shim 8x1.6 G104 Gear Z40 G105 Ball Bearing 14x25.5x6 G106 Ball Bearing 6x13x5 G107 Shim 6x0.1 G108 Gear Z15 G109 Shat 6x68 | G110 Ball Bearing 6x13x5 G111 Clutch G900 M4x70mm G930 M3x8mm G931 M3x5mm (set screw) G940 M4x35mm G941 M4x4mm (set screw) | G942 M4x5mm (set screw) G974 Washer M4 G984 Washer M4x11.8 G993 Nut M3 G094 Nut M4 |
|--|---|--|--|
|--|---|--|--|

