ENSEO SET-TOP BOX (STB)

Television Troubleshooting Guide

This guide is designed for front desk associates to handle common guest room television issues involving the Enseo set-top box (STB) without the need for the Engineering Department.

Any team member can contact Enseo support 24/7 at **866-717-3075**.

Basic Power & Visual Checks

- **LED Status:** Ensure the Enseo box has power by checking for a **solid green LED** light inside the unit.
- **Startup Delay:** There is at least a **5-second delay** before the system responds after pushing the power button on the remote. Look for a blinking red LED on the front or underside of the TV to confirm it received the signal from the remote.
- **Cable Integrity:** Verify that power cables for both the Enseo STB and the TV are firmly connected. Ensure the HDMI cable is securely plugged into the box and into the TV's **HDMI 1** port. Confirm that the MPI cable is also plugged into the TV's MPI port and into the Enseo STB. (Looks like a telephone wire.) Verify the coaxial cable is plugged into the wall and the Enseo STB.

Quick Reset Steps (The First Response)

Most issues can be resolved by a "Power Cycle." If a guest has any TV issue, try this first:

1. **Unplug the power cord** from the back of the Enseo box. The round “barrell” type plug.
2. **Wait 30 seconds** to allow the internal capacitors to discharge.
3. Plug the power back in.
4. **Wait 7 minutes** for the system to reboot. The Enseo logo should appear on the screen during this time. The TV will also automatically turn off. Continue to wait the full 7 minutes. Then try turning the power back on.

Common Scenarios & Solutions

1. "No Signal" or Black/Grey Screen

- **HDMI Cable:** Sometimes replacing the cable can resolve issues with picture and sound.
- **Check Input:** Ensure the TV is on the correct HDMI input (usually **HDMI 1**). Guests often accidentally change this using buttons on the TV frame.
- **Loose Cables:** Verify the HDMI cable is securely plugged into both the Enseo box and the TV.
- **Grey Screen:** This often means the box is stuck while trying to load the channel tuner. Perform a Power Cycle.
- **Resolution Mismatch:** If the screen says "Unsupported Mode," the box resolution might be set too high. A reboot usually auto-negotiates the correct resolution.

2. Remote Control Not Responding

- **Line of Sight:** Ensure the bottom of the TV isn't blocked by guest items.
- **Batteries:** Replace with 2 fresh AA batteries.
- **MPI Cable:** Ensure the MPI (Multi-Port Interface) cable is plugged into the back of the TV as well as into the Enseo STP.
- **If Problem Persists:** Give the guest a new remote control. Put the non-functional remote in the Engineering Department Work Order Drop Box.

3. Frozen Image or Pixelation

- **Network Check:** Pixelation is often caused by a weak signal. If multiple rooms are reporting this, it may be a property-wide server or "headend" issue.
- **Cable Swap:** If only one room is affected, the HDMI cable may be damaged.

4. Low or No Volume

- **Two Volume Controls:** Both the TV and the Enseo box have volume settings. Ensure the TV's physical volume is set to around 50%, then use the Enseo remote to adjust the guest's level.
- **Mute:** Check if "Mute" is active on the Enseo interface.

5. No Internet

- Check that the remote antennas are connected to the Enseo STB's USB ports.

Phone Support

- Enseo's support team is available 24/7 at **1-866-717-3075**.
- Provide them with your name, name of the hotel, position (eg. Front Desk) and room number. They will be more than happy to assist you.
- Sometimes issues with the STB can be resolved if they 'remote' into it.