DORMAKABA / LED SIGNAL GUIDE

Dormakaba LED Visual Guide

G Green Y Yellow R Red

01 Normal keycard indicators

Common front-desk signals, including successful access and power warnings.

N01 Access Granted

Green (G) 12 flashes

Green (Flashes 12x)

Normal operation.

NONE **Normal operation**

N02 Deadbolt / Privacy Switch Is On

Yellow (Y) 12 flashes

Yellow (Flashes 12x)

Room is occupied or locked from the inside.

LOW **Check with guest**

N03 Access Denied

Yellow (Y) 8 flashes

Yellow (Flashes 8x)

Keycard is expired, wrong room, or blocked.

LOW **Re-make keycard**

N04 Battery is Low (Mid-Level)

Yellow (Y) Yellow → Red (R) Red → Yellow (Y) Yellow → Red (R) Red

Yellow then Red, Yellow then Red

The lock has entered an early warning power state.

MEDIUM **Replace batteries soon**

N05 Battery is Critically Low

Green (G) Green ↔ Red (R) Red

Green and Red (Alternating)

The lock is about to die completely.

HIGH **Replace batteries immediately**

N06 Lock Clock Reset

Red (R) Simultaneous flashes*

Red (Simultaneous Flashes)

The lock's internal clock lost its time.

HIGH **Reprogram lock with LPI/MKO probe**

> * The source wording is retained. It does not name another LED or specify a count.

N07 Dead Batteries / Broken Lock

No lights at all

No Lights at All

The lock has completely lost power or is physically broken.

CRITICAL **Emergency mechanical key needed**

02 Special function keycards

Read the complete signal, including the follow-on flashes.

S01 Fatal Test Mode (Lock E2 failed)

Green (G) Yellow (Y) Red (R) 1 flash each; order not stated
→ **Green (G) Yellow (Y) Red (R) 4 flashes**

1 Green, 1 Yellow, 1 Red (then all 3 flash 4x)

Drill the lock to open.

CRITICAL **Destructive entry required**

> The source lists one flash of each color before the ×4 group; it does not state the order within that first group.

S02 MODE 0: Circuit board problem

Red (R) Green (G) Yellow (Y) 4 simultaneous flashes

Red, Green, Yellow (Simultaneous flash 4x)

Use E2 erase keycard to enter Mode 1 and reprogram.

HIGH **Maintenance needed**

S03 MODE 1: Lock not programmed

Green (G) 2 flashes → Green (G) Yellow (Y) Red (R) 4 flashes

Green 2x (then all 3 flash 4x)

Reprogram using the LPI probe.

HIGH **Maintenance needed**

S04 MODE 3: Programming chip problem

Green (G) + Yellow (Y) 2 Green + Yellow flashes → Green (G) Yellow (Y) Red (R) 4 flashes

2 Green + Yellow flashes (then all 3 flash 4x)

Replace the circuit board.

CRITICAL **Hardware replacement**

> The source preserves “2 Green + Yellow flashes.” It does not separately define the Yellow count or timing.

S05 MODE 4: Lock E2 disabled

Red (R) 2 flashes → Green (G) Yellow (Y) Red (R) 4 flashes

2 Red flashes (then all 3 flash 4x)

Use PPK + E2 disable/enable keycard to re-enable.

HIGH **Maintenance needed**

S06 MODE 5: Motor jammed / switch problem

Yellow (Y) 2 flashes → Green (G) Yellow (Y) Red (R) 4 flashes → Yellow (Y) Slow yellow flash

2 Yellow flashes (then all 3 flash 4x then slow yellow flash)

Replace the entire lockset.

CRITICAL **Hardware replacement**

03 Invalid lock mode indicators

Resequence, inhibit, electronic lockout, programming, and erase-card responses.

I01 Resequence Completed

Green (G) + Yellow (Y) 6 flashes

Green + Yellow (Flashes 6x)

New keycard sequence accepted successfully.

NONE

I02 Lock Not Out of Sequence

Yellow (Y) 6 flashes

Yellow (Flashes 6x)

Lock was already on the correct sequence.

NONE

I03 Resequence Failed

Red (R) 1 flash → Sequence

Red 1x (Before a sequence)

Keycard sequence error.

LOW **Issue a new keycard**

I04 Lock Successfully Inhibited

Red (R) 1 flash + Yellow (Y) 12 flashes

Red 1x + 12 Yellow flashes

Guest-level keycards are now disabled.

NONE **Normal if intentional**

I05 Lock Already Inhibited

Yellow (Y) 12 flashes

Yellow (Flashes 12x)

Lock was already in an inhibited state.

NONE

I06 Electronic Lockout Enabled

Red (R) 1 flash + Yellow (Y) 12 flashes

Red 1x + 12 Yellow flashes

All lower-tier access blocked.

NONE **Normal if intentional**

I07 Electronic Lockout Removed

Green (G) 1 flash + Yellow (Y) 12 flashes

Green 1x + 12 Yellow flashes

Normal room access restored.

NONE

I08 Programming Active

Yellow (Y) Flashes for 20 seconds

Yellow (Flashes for 20 seconds)

Primary / Secondary Program card accepted.

LOW **Proceed with programming**

I09 E2 Erase Keycard Accepted

Yellow (Y) + Green (G) 2 flashes

Yellow + Green (Flashes 2x)

Lock memory cleared to Mode 1.

LOW **Proceed with programming**

Reading the signals

× = flash count. Arrows = stated order. Letters identify colors even in grayscale.

Sequence key: In special-function patterns, the first group precedes the all-three ×4 group. Only MODE 0 explicitly says simultaneous.

Reused signals: I04 and I06 have the same pattern and different meanings. Yellow ×12 is also used in N02 and I05. Match the card/function context as well as the lights. “+” is retained from the source; it does not establish timing.

Source notes: N06 does not name another LED or specify a count. S01 does not state the order within its first group. S04 does not separately define the Yellow count or timing.

All counts and durations shown are those stated in the source. Diagrams are schematic, not timed animations.

Source: Dormakaba LED Light Indicator Table.pdf · source page 1. 22 entries · 3 sections.