Download File: 103A1273.D29

Application Name: MERS_HI

 Unit Number:
 1273
 Laptop Time:
 2023/10/29 13:56:46

 Recording Start:
 2023/10/18 14:11:29
 Download Time:
 2023/10/29 13:57:14

 Recording Stop:
 2023/10/29 13:57:14
 Prev. Download:
 2023/10/27 10:42:00

Recorder Type:ERS2 Freq, 16 Analog,Firmware Version:4.6748 Digital ChannelsFlexware Version:2.218 MB Flash MemoryDownload Version:1.61Vigilance: InstalledSerial Number:080311WinDNLD Download

F02 **Processor Module:** 2.21 Freq. Channels: SPD Freq & ID: 0.90 Wheel Diameter (in.): 35.3 35.1 Analog Module 1: 1.60 Pulses/Revolution: 383 383 **PWM** 0.10 **Event Threshold:** 1 1 **EPP** HLV Analog Channels: **BCP** A03 **BTV** A06 TMC **80A**

Max. Input (V): 10 10 10 100 100 100 20 20 10.0 Max. Sensor (V): 10.0 10.0 100.0 100.0 100.0 20.0 20.0 Sensor Offset (V): 1.6 1.6 1.6 0.4 2.5 -2.6 8.0 0.5 Sensor Full Scale (EU): 232 241 239 116 116 117 2351 4462 **Event Threshold (EU):** 2 2 5 5 104 5 4

PWM Analog Channels: A10 A11 A12 A13 A14 A15 A16 Max. Input (V): 100 100 100 100 100 100 100 100 Max. Sensor (V): 100.0 100.0 100.0 100.0 100.0 100.0 100.0 100.0 Sensor Offset (V): 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 Sensor Full Scale (EU): 100 100 100 100 100 100 100 100 **Event Threshold (EU):** 2 2 100 100 100 100 100 2

Odometer (miles): 280219.8

Odo. Set Time: 2013/12/13 13:03:35 F01, SPD, Spd of Highliner F1(F02, F02, Spd of Highliner F2(mph)

A01, BCP, Brake Cylinder PresA02, EPP, Emergency Pipe PrA03, A03, Spare Pressure ChaA04, HLV, Headlight Voltage A05, BTV, Battery Voltage

A06, A06, Spare Analog ChanrA07, TMC, Traction Motor CurrA08, A08, Spare Analog ChanrA09, PWM, Accel. & Brake CoiA10, A10, Spare A11, A11, Spare A12, A12, Spare A13, A13, Spare A14, A14, Spare A15, A15, Spare

A16, A16, Spare

D01, ZSP, Zero Speed D02, DIB, Door Interlock BypasD03, ZSB, Zero Speed BypassD04, D04, Spare Digital Input D05, PWR, Power Trainline

D06, DOR, Door Closed IndicaD07, TRL, This Cab Trailing D08, PBK, Parking Brake D09, D09, Spare Digital Input D10, FWD, Forward

D11, REV, Reverse
D12, SNW, Snow Brake
D13, BPD, Bridge Plate DeployD14, D14, Spare Digital Input
D15, RST, Manual Alerter Reset
D16, HRN, Horn
D17, WHE, Wheel Slip
D18, REL, Brakes Released
D19, MCE, Master Control EnaD20, D20, Spare Digital Input
D21, BEL, Bell
D22, PEN, No Alerter Penalty
D23, OVR, ERS TMS Override D24, BTE, Bench Test Enablec D25, D25, Spare Digital Input
D26, D26, Spare Digital Input
D27, D27, Spare Digital Input
D28, D28, Spare Digital Input
D29, DLC, Ditch Light Switch CD30, DLF, Ditch Light Switch Flash

D31, DLA, Ditch Light Switch AD32, HFP, Horn Foot Pedal D33, D33, Spare Digital Input D34, OSP, Overspeed D35, D35, Spare Digital Input

D36, D36, Spare Digital Input D37, VEN, ERS- Vigilance EnaD38, VAL, ERS- Vigilance AlarD39, VPE, ERS- Vigilance PenD40, D40, Digital 40 D41, D41, Digital 41 D42, D42, Digital 42 D43, D43, Digital 43 D44, D44, Digital 44 D45, D45, D45, Digital 45

D46, FLT, ERS- System Fault D47, MGV, ERS- MGV Output D48, PFT, ERS- Penalty due to Faul