

IPOD Glue head brackets Fx3 - 1383G1

Operating and maintenance manual






OPERATING AND MAINTENANCE MANUAL

"IPOD Glue head brackets Fx3"


M25B2






M10A2

M26B2





M12A2

Manual No.: D0001240 Revision: 0, 16.03.2020

Year of manufacture: 2020

Serial number: A0BT191383G1



GENERAL INDEX

| Section 1 | <u>Introduction</u> |
|------------|-------------------------------------|
| Section 2 | Process functions |
| Section 3 | Safety |
| Section 4 | Technical data |
| Section 5 | Handling |
| Section 6 | Use of the machine (HMI) |
| Section 7 | Setting and adjustments |
| Section 8 | Maintenance, lubrication & cleaning |
| Section 9 | Disposal |
| Section 10 | How to order spare parts |
| Section 11 | List of the enclosures |
| Section 12 | Request for intervention |