1. Safety

Never raise the platform on a slope steeper than 2 degrees; the tilt alarm sounds at 1.5 degrees and lift-up is disabled at 2 degrees.

Maximum platform load is 300 kg including two occupants. The overload sensor blocks lift-up above 330 kg.

Do not operate outdoors in wind gusts above 12.5 m/s (28 mph).

2. Specifications

Maximum working height 9.8 m; maximum platform height 7.8 m; stowed height 2.1 m.

Batteries: four 6 V 225 Ah deep-cycle batteries (24 V system). A full charge takes 8 hours on the onboard 25 A charger.

Drive speed: 3.5 km/h stowed, 0.8 km/h with the platform raised.

3. Maintenance schedule

Daily: check hydraulic oil level with the platform fully lowered; it must reach the FULL mark on the dipstick.

Every 250 hours: replace the hydraulic return filter (part HL-F250).

Every 1000 hours or yearly: replace the hydraulic oil (ISO VG 32, 19 litres) and inspect the scissor pins for wear above 0.5 mm.

4. Fault codes

E01 - Tilt alarm: the chassis is more than 1.5 degrees off level. Move the machine to level ground and lower the platform.

E07 - Overload: the platform load exceeds 330 kg. Remove material until the alarm clears.

E12 - Low battery voltage below 21.6 V: lift-up is disabled; drive to a charger and charge for 8 hours.

E18 - Pothole guard did not deploy: check the guard linkage for debris; the machine will not drive with the platform raised until it clears.