


A




A

U1	
1	3.3V
2	RST
3	GPIO36/S_VP
4	GPIO39/S_VN
5	GPIO34
6	GPIO35
7	GPIO32/XTAL32
8	GPIO33/XTAL33
9	GPIO25/DAC2
10	GPIO26/DAC1
11	GPIO27/TOUCH7
12	GPIO14/TOUCH6
13	GPIO12/TOUCH5
14	GND
15	GPIO13/TOUCH4
16	SD2
17	SD3
18	CMD
19	5V
38	GND
37	V_SPLD/GPIO23
36	SCL/V_SPL_WP/GPIO22
35	TXD/CLK3/GPIO01
34	RXD/CLK2/GPIO03
33	SDA/V_SPL_HD/GPIO21
32	GND
31	LoRa_Mosi/V_SPI_Q/GPIO19
30	V_SPL_CLK/GPIO18
29	V_SPL_CS0/GPIO05
28	GPIO17
27	GPIO16
26	TOUCH0/HSPI_HD/GPIO04
25	TOUCH1/CLK1/GPIO00
24	TOUCH2/HSPI_WP/GPIO02
23	TOUCH3/HSPI_CS0/GPIO15
22	SD1
21	SD0
20	CLK

B

C

D



1 J\_RCsignal  
2 ~

Sheet: /  
File: Switchboard.kicad\_sch

**Title: Swithcboard**

Size: A4 Date: 2025-09-10  
KiCad E.D.A. 9.0.4

Rev: 0  
Id: 1/1