

11/8/2026

Assignment-3

Created By
~pintu mer

1. List 5 common issues users face with **USB** keyboards or mice on laptops, and write one possible solution for each.

No.	Common Issue	Possible Solution
1.	Device not detected	Unplug it and connect it to another USB port.
2.	Keyboard/Mouse not working	Restart the laptop and reconnect the device.
3.	Cursor moves slowly or freezes	Clean the mouse sensor and try another surface.
4.	Some keys do not work	Clean the keyboard and check for stuck/damaged keys.
5.	USB keeps disconnecting	Update the USB driver and try a different USB port.

2. Simulate a troubleshooting flow: Your **Bluetooth** headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.



Bluetooth Headphones Not Connecting – Steps

1. **Check Battery**

- Make sure the headphones have enough battery.

2. **Turn ON Headphones**

- Press the power button and check the **power light**.

3. **Turn ON Bluetooth**

- Go to **Phone Settings** → **Bluetooth** → **ON**.

4. **Enable Pairing Mode**

- Press and hold the Bluetooth button until the **blue light starts blinking**.

5. Check Device List

- Look for your headphone name under **Available Devices**.

6. Tap Connect

- Select the headphone name and wait for “**Connected**”.

7. Forget and Pair Again

- If it does not connect, select **Forget/Unpair**, then search and pair again.

8. Restart and Try Again

- Restart both the **phone and headphones**, then repeat the connection.

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

External Webcam Not Detected – 6-Step Checklist

• **1. Check USB Connection**

- Make sure the webcam USB cable is connected properly. Try another USB port.

• **2. Check Device Manager**

- Open **Device Manager** → **Cameras** and check if the webcam is listed. If it has a warning mark, update the driver.

• **3. Check Windows Privacy Settings**

- Go to **Settings** → **Privacy** → **Camera** and make sure **Camera access is ON**.

• **4. Allow App Access**

- In **Camera Privacy Settings**, make sure **Allow apps to access your camera** is ON.

- **5. Check Zoom Camera Settings**

- Open **Zoom** → **Settings** → **Video** and select the correct external webcam.

- **6. Restart and Test**

- Close Zoom, unplug and reconnect the webcam, restart Windows, and test the webcam again.

4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

❖ **Using Windows Troubleshooter to Fix an Offline Printer**

- **Open Settings → Devices → Printers & scanners.**
- **Select the offline printer.**
- **Click Manage → Run the troubleshooter.**
- **Wait while Windows checks for problems.**
- **Check the problem and suggested solution.**
- **Follow the instructions to fix the problem.**
- **Restart the printer if needed.**
- **Print a test page to check the printer.**

❖ **Information Provided by the Troubleshooter:**

- **Printer connection status**
- **Printer driver problems**
- **Print Spooler problems**
- **Printer setting problems**
- **Detected problems**
- **Suggested solutions**
- **Fix status – whether the problem was fixed or not.**