
FREEDOM WINDOW & OTD ILLUSTRATED PARTS LIST

- MANUFACTURED PRIOR TO SEPT 2008




Item	Part Number	Description		Notes
1	R019311-001	Bracket Kit	8'-13'	4
4		Awning Rail	See Hardware and Accessories	
6	R001503XXX	End Cap, Motor (2 pieces)	LH	3
7	R001026XXX	End Cap, Manual Crank	LH	
9	R036425-001	End plate, Housing, Tubular Motor	LH, RH	2
11	R001189	Motor, Tubular		2, 5
14a	R001188	Bushing, Roller Tube	RH	2, 5
15	R034923-001	Pivot Tube, Roller Tube	RH	2
16	R001502XXX	Motor & End Cap Assembly, Worm Drive		
21		Roller Tube, 2 1/4	See Hardware and Accessories	
22		Roller Tube, 1 7/8	See Hardware and Accessories	
23	R012530-TB32L	Spring Arm Assy	LH	
25	R012530-TB32R	Spring Arm Assy	RH	
29	R001027XXX	End Plate, Lead Rail	LH	
30	R001028XXX	End Plate, Lead Rail	RH	
31	R001605	Switch Kit		6

- Notes: 1. XXX = Color.
 - 2. Used on motorized models Mid-2005 and ON.
 - 3. Silver motor used on motorized models prior to Mid-2005.
 - 4. Brackets available in kits only. All kits include carriage bolts, washers and nuts.
 - 5. Motor Replacement Kit (item 11) includes bearing and drive.
 - 6. Switch kit (item 31) contains switch and bezels. Kit replaces all previous switches.

12 070000-DIS

FREEDOM WINDOW & OTD ILLUSTRATED PARTS LIST

- MANUFACTURED AFTER SEPT 2008



	<u> </u>				
Item	Part Number	Description		Notes	
1	R019311-001	Bracket Kit	8'-13'	2	
4		Awning Rail	See Hardware and Accessories		
7	R036425-001	End plate, Housing, Motorized, Tub	ular Motor LH, RH		
8	R001189	Motor, Tubular		3	
12	R001188	Bushing, Roller Tube	RH		
13	R034923-001	Pivot Tube, Roller Tube	RH		
14	R062777-XXX	Manual Crank Assy			
18	R001539	End Plate, Housing, Manual Crank	RH		
19		Roller Tube, 2 1/4	See Hardware and Accessories		
20		Roller Tube, 1 7/8, Steel	See Hardware and Accessories		
21	R012530-TB32L	Spring Arm Assy	LH		
23	R012530-TB32R	Spring Arm Assy	RH		
29	R001605	Switch, DPDT, Momentary Contact	Ext/Ret	4	
31		Hand Crank Assembly	See Hardware and Accessories		
32	R001251	Shim Kit	not shown		

- Notes: 1. XXX = Color; xxx = Length in inches.
 - Brackets available in kits only. All kits include carriage bolts, washers and nuts.
 Motor Replacement Kit (item 8) includes bearing and drive.

 - 4. Switch kit (item 29) includes switch and bezels. Kit replaces all previous switches.

13 070000-DIS