# **Dalmia**BHARAT CEMENT

### DALMIA CEMENT (B) LIMITED - ARIYALUR

#### **MECHANICAL SOP**

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/MEC/109

Issued By: M.R Approved By: HOD Mechanical

Bucket elevator boot jam removal due to power cut

**Scope**: Bucket Elevator Maintenance & Inspection

**Responsibility: General Fitter** 

Accountability: Mechanical-Section Engineer

PPE:

Safety helmet.
 Safety shoe.

#### **TOOLS:**

1. Box spanner set

- 2. Ring spanner set
- 3. Chain Block
- 4. Wire rope slings
- 5. Manila / Nylon rope
- 6. "D" Shackle.
- 7. Local stop Key.

#### **Hazard Analysis:**

Risks associated: Mitigating Measures

Heavy Material : Use of Chain blocks & Ropes

Auxiliary Drive May start : 1) Keep the Auxiliary LPB is visibly locked & controlled.

: 2) Check and conform the Auxiliary derive LPBs (both top &

bottom) are working.

### SOP for the Bucket elevator boot jam removal due to power cut

- 1. Stop the Bucket elevator & take the Line clearance of the main drive. With LOTO system
- 2. The LOTO key and line clearance paper should be with the person who responsible for job
- 3. Take General work area permit from the relevant department.

# **Dalmia**BHARAT CEMENT

#### DALMIA CEMENT (B) LIMITED - ARIYALUR

#### **MECHANICAL SOP**

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/MEC/109

Issued By: M.R Approved By: HOD Mechanical

## Bucket elevator boot jam removal due to power cut

4. Use PPE.

- 5. Encage the B/E Auxiliary drive clutch with the main gearbox.
- 6. Start the Auxiliary drive in local mode and check the healthy signal of boot level switch.
- 7. If it is not showing healthy signal open the bottom boot door.
- 8. Again Start the Auxiliary drive in local mode and check the healthy signal of boot level switch.
- 9. If it is healthy close the boot door.
- 10. Clear the Line clearance and take trial.

#### **Emergency / Emergency Shut OFF:**

1. If any injury takes place, provide First aid and inform to the Safety department or Call Emergency number 3108/9865152222

#### **Records/Annexure:**

- 1. Refer Line clearance certificates.
- 2. JSA as enclosed below

Job Safety Analysis	Job: Bucket Elevator Maintenance / Inspection	Date: 20/10/2012	Analysis by: Section Engineer	Reviewed by: Section Head				
Title of employee doing job: <b>Fitter</b>	Supervisor: Section Engineer (Mech.)	Department:  Mechanical	Section: Pyro.: RVRM; CVRM; Packing Plant	Approved by: HOD Mech.				
Req'd /recommended PPE:								
Sequence of Basic Job Steps	Potential Hazards	Recommended Safe Job	What Could Go Wrong	Corrective Action				



## **DALMIA CEMENT (B) LIMITED - ARIYALUR**

## **MECHANICAL SOP**

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/MEC/109

Issued By: M.R Approved By: HOD Mechanical

Bucket elevator boot jam removal due to power cut

		Procedure				
Opening inspection	Material May flush	Ensure the BOOT empty or keep the way to escape from the flushing Material	Material in Boot may release suddenly	Don't open all the bolts of the door, keep some bolts loosen at its place. Empty out without flushing		
Open the inspection door	Loose material may fall from top of the Maintenance doo	Tap the casing before opening the inspection door to release loose material	Material may fall on the working personnel	Don't engage anybody at the top(Drive station)  Take care of fingers at nip points		
Bucket may fall during handling for replacement.	Fingers trap	Use Suitable tools to handle (Chain Block, slings, etc)	Slings & chain tightening.			

S L N o	Activity		Isolation Matrix								
			Isolation Type								
	_		Electrical Energy					Other Energy			
1	Bucket elevator internal inspecti on	Name and Tag for the Equipment	Drive For The Elevator		Feeding Equipme nt for the Elevator.		Elevator discharge Air RSLIDE FAN		Bag Filter related to the Elevator		