

DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR

INSTRUMENTATION DEPARTMENT

Issued By: M.R Approved By: HOD-INSTRUMENTATION

CALIBRATION PROCEDURE OF RTD TRANSMITTER

The Instrument engineer/Foreman/Assistant Foreman takes action as follows, for calibration:

- 1.1 Connect the transmitter to DTM through ABB DCS.
- 1.2 Connect the Calibrator to the input terminals of the transmitter.
- 1.3 Set the resistance corresponding to the desired full scale temperature. CCR indication Should show full scale temperature. If not Adjust adjust it by desired offset in DTM.
- 1.4 Record the observations in the Instrument calibration format F-1/WI-7(SP-8; AM-7)

2.0 CONNECTED DOCUMENT:

F-1/WI-7(SP-8; AM-7)

CALIBRATION OF RTD TRANSMITTER

CALIBRATION OF RAW MILL OUTLET TEMPERATURE TRANSMITTER
CALIBRATION OF COAL MILL OUTLET TEMPERATURE TRANSMITTERCALIBRATION OF COAL
MILL BH INLET TEMPERATURE TRANSMITTER CALIBRATION OF CEMENT MILL OUTLET
TEMPERATURE TRANSMITTER

RAW MILL OUTLET TEMPRATURE RANGE 0- 150 Deg

Applied Value In Ohms Calculated value in DEG.

100.0 0.0

 130.890
 80.0

 157.320
 150.0

COAL MILL OUTLET TEMPRATURE RANGE 0- 150 Deg

Applied Value In Ohms Calculated value in DEG.

100.0 0.0

130.890 80.0

157.320 150.0



DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR

INSTRUMENTATION DEPARTMENT

Issue No. 02 | Rev. No: 00 | Effective Date: 01.11.2019 | WI-7 (SP-8; AM-7)

Issued By: M.R Approved By: HOD-INSTRUMENTATION

CALIBRATION PROCEDURE OF RTD TRANSMITTER

COAL MILL BH INLET TEMPRATURE

RANGE 0-150 Deg

Applied Value In Ohms Calculated value in DEG.

 100.0
 0.0

 130.890
 80.0

 157.320
 150.0

CEMENT MILL OUTLET TEMPRATURE RANGE 0- 150 Deg

Applied Value In Ohms Calculated value in DEG.

 100.0
 0.0

 130.890
 80.0

 157.320
 150.0