

DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR



MECHANICAL DEPARTMENT

Issue No. 01	Rev. No: 00	Effective Date: 15/5/2018 SO	OP/MEC/154		
Issued By: M.R		Approved By: HOD MECHANICAL			

HYDRA WATER SERVICE

Scope : Outdoor car washing may result in a discharge of water to storm

water drain that is potentially contaminated with gasoline, oil, residues from exhaust fumes, and detergents. The water discharged into storm water drains eventually reaches rivers, streams, creeks, and wetlands where it has the potential to impact human health and the environment. This SOP covers the procedures for minimizing the

impacts of car washing.

Responsibility: Hydra maintenance Engineer

Accountability: Section Head – Utility

PPE:

1. Gum boot,

2. Safety helmet,

3. Goggles,

4. Nose Mask,

5. Face shield,

6. Hand Gloves.

Tools:

1. Car washer pump

2. High pressure gun

3. High pressure hose

4. Box Spanner set

5. Ring Spanner set

Hazards/Aspects & Impact:

Risks associated Mitigating Measures

Electrical Shock Wear Rubber gloves and Gum boot (Electrical insulated)

Pipe Burst Switch OFF the pump and change the hose

Monitor the pressure gauge and hose periodically.

High pressure water jet Wear full body Apron and Face shield. exposure with human being Periodically clean the water jet nozzle.

Training needs:

1. High pressure car washer pump operation

2. Emergency preparedness



DALMIA CEMENT (B) LIMITED - CEMENT PLANT **ARIYALUR** MECHANICAL DEPARTMENT



Rev. No: 00 Issue No. 01

Effective Date: 15/5/2018

SOP/MEC/154

Approved By: HOD MECHANICAL Issued By: M.R

HYDRA WATER SERVICE

Procedure:

Definitions:

- Pervious/porous surfaces Surfaces that allow the movement of water and air to lower levels of soil below.
- Waste water Any water that has been adversely affected in quality.
- > Storm drain Structure designed to drain excess rain and groundwater from paved streets, parking lots, sidewalks, and roofs.
- > Sewer drain Transports sewage through cities and other inhabited areas to sewage treatment plants to protect public health and prevent disease. Sewage is treated to control water pollution before discharge to water bodies.
- ➤ Phosphate An inorganic chemical that has historically been one of the main ingredients in detergents. Phosphates have harmful effects on the health of rivers, lakes, streams, and other fresh waters because higher than normal phosphate levels allow algae in the water to grow faster than would naturally occur. Increased algae populations are a detriment to water quality due to increased turbidity and decreased oxygen levels.
- Emulsification The suspension of one liquid in another, for example, oil in water. An example of a detergent that creates this effect is the Dawn brand of detergent, "it cuts through grease," i.e., through emulsification.
- > Pressure washing The term "pressure washing" typically refers to a washing system not capable of generating at least 5,000 psi. Such systems can be found at a car wash or in the form of portable equipment designed for Hydra commercial or home use.
- ➤ High pressure washing The term "high pressure washing" refers to a high pressure washing system capable of generating a pressure of 5,000 pounds per square inch (psi) or more. This includes high pressure washing systems used at lower pressures and high volume.

There are two levels of high pressure washing, based on the water pressure used:

- 1. High pressure water blasting 5,000 to 30,000 psi
- 2. Ultra high pressure jetting greater than 30,000 psi

Safe operation procedures:

- 1. Always parking the Hydra vehicles in a designated area with proper wheel chocks.
- 2. Take General work permit for Cleaning or service activity.
- 3. Keep the washing area neat and well organized. Sweep or pick up all trash and debris daily or as needed, before it is carried away during washing activity.



DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR MECHANICAL DEPARTMENT



Issue No. 01 Rev. No: 00 Effective Date: 15/5/2018 SOP/MEC/154

Issued By: M.R Approved By: HOD MECHANICAL

HYDRA WATER SERVICE

- 4. Inspect the parking vehicles having any fuel leakages or not. If any leakages are found inform your operator/Section Incharge /supervisor for taking necessary action to close or isolate the leakages to avoid the contamination with wash water.
- 5. Wash Hydra vehicles on proper permeable surfaces. i.e, even surface ground level with clear passage of fluids or washing effluents.
- 6. Maintain vehicles and equipment to prevent leaks/drips, which would more easily enter wash water.
- 7. Obtain and use drain guards (filter inserts) to catch sediments, petroleum products, etc.
- 8. Keep the drain sock handy and close by as it will be used frequently. Replace drain sock when it can no longer hold back the sediments from the drain.
- 9. Use the drain socks to protect the wash rack drain from excessive sediments. Prior to any washing activity, put the "sock" filter medium around the sides of the drain to catch any sediment and debris from washing activity.
- 10. After each washing activity, sweep up the filtered sediment and debris after it is dry to keep it from going back down the drain. Transfer to a container for storage. Use DRY cleanup only.
- 11. Discharge all wash water containing degreasers, acids, bases, and/or metal brighteners to an on-site treatment facility, discharge to a vegetated buffer. If the wash water contained any waste oil, separate the Oil and stored in an MS barrels. The stored waste oil should be handover to stores for further disposal.
- 12. DO NOT let waste accumulate at Wash Rack.
- 13. Keep car washing equipment clean; do not allow a buildup of oil/grease/mud. Conduct daily inspections.
- 14. Minimize water and soap use when rinsing or washing vehicles.
- 15. Maintained the safe distance while servicing the Hydra equipments.
- 16. Educate personnel periodically for proper washing practices.

Emergency / Emergency Shut OFF:

- 1. If any Electrical hazard is there, First switch OFF the main and inform to the Section Electrical Authority
- 2. If any Emergency, Call Safety department or Call Emergency number 3108/9865152222/9750963761.
- 3. If any hose pipe got punctured or burst, then stop Car washing pump with an Emergency switch.



DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR MECHANICAL DEPARTMENT



Issue No. 01 Rev. No: 00 Effective Date: 15/5/2018 SOP/MEC/154

Issued By: M.R Approved By: HOD MECHANICAL

HYDRA WATER SERVICE

Records/Annexure:

- 1. Refer General work permit register.
- **2.** JSA as enclosed below.

JOB SAFETY ANALYSIS: (JSA)

Job Safety Analysis	Job: Cleaning of Hydra equipment	Date: 15.05.2018	Analysis by: Sec. Engineer	Reviewed by: Sec. Head		
Title of employee doing job: Helper	Supervisor: Hydra incharge	Department: Mechanical	Section: Utility	Approved by: HOD		
Req'd/recommended PPE: Gum boot, Safety helmet, Safety shoe, Nose Mask, Hand Gloves, Goggles and Face shield.						
Sequence of Basic Job Steps	Potential Hazards	Recommended Safe Job Procedure	What Could Go Wrong	Corrective Action		
	Exposure of high pressure water to the body	Use full body Apron suit	Exposed to high water pressure – Body injury	Training, Tools & Toggles and usage of proper PPE		
Checking and operation of Car washer	Water hose hit to the person	Check the tightness of the hose joints as per checklists, Periodic hose maintenance and replacement. Maintained the safe distance.	Water hose pipe got burst Nozzle block due to scale formation	Replace the Hose. Clean the nozzle periodically.		
Water spray contact with electrical junction box	Electrical shock	Proper Insulation of junction to avoid contact with water	Exposure to electric shock, Body Injury	Training, Tools & Toggles and usage of proper PPE		