

DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR ELECTRICAL MANUAL



Issue No. 01 Rev. No: 02 Effective Date: 07.07.2017 SOP/Elect /056

Issued By: Approved By: HOD - ELECTRICAL

SOP For SEPAM RELAY SETTING CHANGE

Scope : This Procedure to establish and ensure safe method of SEPAM RELAY SETTING

CHANGE.

Responsibility : Section Engineer/Shift Engineer – Electrical

Accountability : Section Head-Electrical

PPE:

1. Safety shoes

2. Safety helmet

3. Rubber Gloves

Tools:

1. Laptop with Communication cables

Hazard Analysis:

Risks associated Mitigating Measures

Injury Use of proper Handling tools Electric shock Use of Proper Isolating tools

Training needs:

- 1. Emergency preparedness
- 2. First aid training
- 3. SEPAM SETTING Knowledge

Procedure:

- 1. Take Electrical Work permit for SEPAM relay setting upload and download.
- 2. Switch OFF the Power Supply (ACB or SFU) and if ACB then Rack out with proper Rubber gloves.
- 3. Plug the Laptop Communication cable connector in SEPAM Relay communication port.



DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR ELECTRICAL MANUAL



Issue No. 01 Rev. No: 02 Effective Date: 07.07.2017 SOP/Elect /056

Issued By: Approved By: HOD - ELECTRICAL

SOP For SEPAM RELAY SETTING CHANGE

- 4. Communicate the SEPAM relay trough Laptop by selecting "connect to front face" Icon in SF2841 software.
- 5. Click the "Protections" option to set the setting parameters
- 6. Click the "50/51-1" option and set the required vales in Setting Group A, Setting Group B for Phase Overcurrent (1).
- 7. Click the "50/51-2" option and set the required vales in Setting Group A, Setting Group B for Phase Overcurrent (2).
- 8. Click the "50N/51N-1" option and set the required vales in Setting Group A, Setting Group B for Earth Fault (1).
- 9. Click the "50N/51N-2" option and set the required vales in Setting Group A, Setting Group B for Earth Fault (2).
- 10. Click the "46" option and set the required vales for Negative sequence current/unbalance Protection.
- 11. If require Recloser operation then Click the "79" option and set required values .
- 12. Upload the setting to SEPAM relay
- 13. Unplug the Laptop Communication cable connector in SEPAM Relay communication port
- 14. Cross check the SEPAM Relay setting by manually.
- 15. Rack in the ACB with proper Rubber gloves.
- 16. Switch ON the power Supply (ACB or SFU).

Emergency / Emergency Shut OFF:

1. If electrical shock injury or body injury is there, give First aid and inform to the Safety department or Call Emergency number 3108/9865152222/9750963761.

Records/Annexure:

1. JSA as enclosed below.

JOB SAFETY ANALYSIS: (JSA)



DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR ELECTRICAL MANUAL



Issue No. 01 Rev. No: 02 Effective Date: 07.07.2017 SOP/Elect /056
Issued By: Approved By: HOD - ELECTRICAL

SOP For SEPAM RELAY SETTING CHANGE

Job Safety Analysis	Job: Sepam relay setting upload and download	Date:	Analysis by:	Reviewed by:
Title of employee doing job: Engineer	Supervisor: Section Engineer/ Shift Engineer	Department: Electrical	Section: Plant	Approved by:
Reqd./recommended PPE: Safety helmet, Safety shoe, Rubber Gloves.				
Sequence of Basic Job Steps	Potential Hazards	Recommended Safe	What Could Go Wrong	Corrective Action
Беср 3		Job Procedure	_	