

DALMIA CEMENT (B) LIMITED - ARIYALUR



MECHANICAL

Issue No. 01 Rev. No: 00 Effective Date: 6.04.2018 SOP/MEC/152

Issued By: M.R Approved By: HOD -Mechanical

SOP-Mobile Crane (ALPHA) rope replacement

Scope: ALPHA crane rope replacement work

Responsibility: Section Engineer

Accountability: Mechanical-Section Incharge

PPE:

- 1. Safety helmet.
- 2. Safety shoe.
- 3. Hand gloves.
- 4. Nose Mask.
- 5. Safety goggles.

TOOLS:

- 1. Box spanner set.
- 2. Ring spanner set.
- 3. Hammer.

Hazard Analysis:

<u>Risks associated</u>: : <u>Mitigating Measures</u>

Body injury : Safe and health tools and tackles

Cut injury : Safe and health tools and tackles

DalmiaBHARAT CEMENT

DALMIA CEMENT (B) LIMITED - ARIYALUR



MECHANICAL

Issue No. 01	Rev. No: 00	Effective Date: 6.04.2018		SOP/MEC/152
Issued Rv: M R			Annroyed Ry: HOD -Med	hanical

SOP-Mobile Crane (ALPHA) rope replacement

SOP FOR ALPHA crane rope replacement work

- 1. Lifting hook position should be Approximately 2 Meters down and near the Joint of the Jib.
- 2. Change the Drum: Disengage the Hoist drum and lick it. Then Engage the Telescopic Drum.
- 3. Raise the Inner mast by pressing up button. Open the Mast lock by pulling the lock rope by hand and lock it.
- 4. Open the Master locking screw on both sides.
- 5. Now lower the crane by pressing down button on the remote.
- 6. While lowering the crane the following movements are to be observed.
 - a) Inner mast will go inside of Outer mast.
 - b) Counter weight will move towards Hoist drum
 - c) Jib will come on the spacing arm.
 - d) Spacing arm movement should be on forward direction.
- 7. Continue the procedure Till Crane resting position.
- 8. Take trolley to the inner position of jib.
- 9. Remove the damaged wire rope.
- 10. Tighten the trolley wire rope.
- 11. Raise the crane by pressing up button on the remote control.
- 12. Watch all the wire rope and cables for any struck.
- 13. While raising the crane the following movements are to be observed.
 - a) Counter weight goes back side.
 - b) Jib goes 1.5 Meter down and goes up.
 - c) The inner mast comes out of outer mast.
- 14. After position of outer mast vertically lock the same with both esid screws.
- 15. Release the wire rope of outer mast lock and press the down button on the remote.



DALMIA CEMENT (B) LIMITED - ARIYALUR



MECHANICAL

Issue No. 01	Rev. No: 00	Effe	ctive Date: 6.04.2018	SOP/MEC/152		
Issued By: M.R			Approved By: HOD -Med	chanical		

SOP-Mobile Crane (ALPHA) rope replacement

- 16. Rest the inner mast on the lock.
- 17. Disengage the telescopic drum and engage the hoist rope drum.

Emergency / Emergency Shut OFF:

1. If body injury is there, First aid will be given and inform to the Safety department or Call Emergency number 3108/9865152222

Records/Annexure:

- 1. Refer Line clearance in Process department.
- 2. JSA is enclosed below.

Emergency / Emergency Shut OFF:

SL No Activity		I:	Isolation Matrix for Utility & General Equipment.				
		Isolation Type					
			Electrical Energy			Other Energy	
1	ALPHA Crane	Name and Tag for the Equipment	Drive for the Equipment	Adjacent Belt conveyor			



Fixing the locking

the Drum

bolt while Changing

Body injury

DALMIA CEMENT (B) LIMITED - ARIYALUR



Use correct size and

condition of spanner

MECHANICAL

Issue No. 01 Rev. No: 00 Effective Date: 6.04.2018 SOP/MEC/152

Issued By: M.R Approved By: HOD -Mechanical

SOP-Mobile Crane (ALPHA) rope replacement

Joh Cofoty	Job:	Date: 6.04.2018	Analysis by	Daviewed by			
Job Safety Analysis	JOD.	Date: 0.04.2016	Analysis by: Section Engineer	Reviewed by : Section Head			
Title of employee doing job: Engineer	Supervisor: Section Incharge	Department: Mechanical.	Section: RMH	Approved by: HOD Mech.			
Req'd/recommended PPE:							
Sequence of Basic Job Steps Potential Hazard		Recommended Safe Job Procedure What Could Go Wrong		Corrective Action			
Removal of locking bolt while Changing the Drum	Body injury	Use proper spanners only to avoid slip	Spanners may slip and chance to fall	Use correct size and condition of spanner			
		Use goggles to avoid the dust entry	Due to coal handling, chance of more fine dust	Use Correct PPE'S			

Use proper

avoid slip

spanners only to

particles

Spanners may slip

and chance to fall