DalmiaBHARAT CEMENT

DALMIA CEMENT (B) LIMITED - DPM

MECHANICAL SOP

Issue No. 02 | Rev. No: 01 | Effective Date: 22.05.2015 | SOP/MEC/48

Issued By: S & P Approved By: Head- Mech

WTP WATER PUMPS

Scope: Maintenance of water pump

Responsibility: Engineer/SH

PPE:

- 1. Safety helmet
- 2. Safety shoe
- 3. Mask
- 4. Safety goggles
- 5. Gloves

TOOLS:

- 1. Screw driver
- 2. spanner set
- 3. Pipe Wrench

Hazard Analysis:

Risks associated: Mitigating Measures

Pressurized water. Isolate all the relative valves with LOTO.

Procedure:

SOP FOR MAINTENANCE OF WATER PUMP AT WTP.

- 1. Pump delivery wall is to be fully closed and suction wall to be closed.
- 2. LOTO has to be taken from CCR and electrical departments.
- 3. Motor connection and earthling tables to be disconnected
- 4. Motor base bolts has to be removed and coupling spider to be removed.
- 5. Pump shaft coupling hub to be removed.
- 6. Pump suction and delivery line flange bolts to be removed and pump to be taken out from dismantling and inspection.

DalmiaBHARAT CEMENT

DALMIA CEMENT (B) LIMITED - DPM

MECHANICAL SOP

Issue No. 02Rev. No: 01Effective Date: 22.05.2015SOP/MEC/48Issued By: S & PApproved By: Head-Mech

WTP WATER PUMPS

- 7. Remove drive end bearing, housing end covers.
- 8. Inspect bearings and oil seal.
- 9. Remove impeller lock nut, take out impeller and inspect and clean impeller for coatings /scale and also inspect the spacer and shaft seal for any damage.
- 10. Remove non drive bearing housing end cover and inspect seal and bearing.
- 11. Replace bearings, seals etc. if found defective of work out.
- 12. Re-assemble pump elements in reverse sequence and tightened all mounting bolts.
- 13. Do the correct alignment and inspect coupling spider, tighten all base bolts of motor.
- 14. Clear the LOTO.
- 15. open suction valve and take trail run of pump and slowly open delivery valve

Emergency Shut- off:

- 16. In case of belt is moving, Emergency pull chord switch should be activated by the person.
- 17. If body injury is there, First aid will be given and inform to the Safety department or Call Emergency number 233/555/9865125176/9865177444.
- 18. Annexure:
- 19. JSA is enclosed below / Isolation Matrix

SL N o	Activity	Isolation Matrix for Utility & General Equipment. Isolation Type		
		Electrical Energy	Other Energy	



DALMIA CEMENT (B) LIMITED – DPM

MECHANICAL SOP

 Issue No. 02
 Rev. No: 01
 Effective Date: 22.05.2015
 SOP/MEC/48

Issued By: S & P Approved By: Head- Mech

WTP WATER PUMPS

8	Maintenance of Water Pump	Name and Tag for the Equipmen t	Drive for the PUMP			Close, Drain & put LOTO for all the inlet & outlet valves	Priming Line		
---	---------------------------------	---	--------------------------	--	--	--	-----------------	--	--

JOB SAFETY ANALYSIS: (JSA)

Job Safety Analysis	Job: Cooler water spray nozzle cleaning	Date: 01 - 10 - 2013	Analysis by: SECTION ENGINEER	Reviewed by: SECTION HEAD
Title of employee doing job: Water Pump Maintenance.	Supervisor: Section Engineer	Department: Mechanical	Section: Utility	Approved by: HOD

Reqd./recommended PPE's: Safety Helmet, Safety shoe, Hand Gloves, Safety goggles. Nose mask.

SI. No	Sequence of Basic Job Steps	Potential Hazards	Recommended Safe Job Procedure	What could go wrong	Corrective action
1	Drain The water in the lines	Slippery	Use Gum Shoes during working at water	Water pressure	Drain slowly.
2	Pump & Motor handling	Injury during handling the Equipment	Use proper tools & Lifting tackles	Failure of lifting tackles	Check thoroughly once again just before use also

HEAD MECHANICAL

HEAD TECHNICAL