



MECHANICAL

Issue No. 02 | Rev. No: 00 | Effective Date: 01.11.2019 | SOP/MEC/168

Issued By: M.R Approved By: HOD-Mechanical

SOP FOR PRIMARY CRUSHER IN-SITU CASTING REPARING

Scope : SOP - Primary Crusher In-situ casting repairing

Responsibility : Section Engineer - Mech
Accountability : Section Manager - Mech

PPE:

1. Safety Helmet,

2. Safety steel toe shoe,

3. Hand Gloves Cotton/Leather

4. Safety goggles.

5. Nose mask.

Tools:

- 1. Welding shield
- 2. Welding machine
- 3. Chipping hammer
- 4. Drill bit
- 5. Wire Brush
- 6. Hand blower
- 7. Cutting set

Hazards:

Risks associated Mitigating Measures

Body injury

Safe and health tools and tackles
Cut injury

Safe and health tools and tackles
Caught in-between

Safe and health tools and tackles

- 1. Take confined space permit with the line clearance. Use LOTO system
- 2. Permits and line clearance paper should be with the people who are working in the site.
- 3. Use PPE's while working
- 4. Take the shutdown of Crusher, Apron feeder and bottom belt conveyor
- 5. Hook the confined space token in designated place and open the door.





MECHANICAL

 Issue No. 02
 Rev. No: 00
 Effective Date: 01.11.2019
 SOP/MEC/168

Issued By: M.R Approved By: HOD-Mechanical

SOP FOR PRIMARY CRUSHER IN-SITU CASTING REPARING

- 6. Lock the wedge piece b/w rotors and also in side combs
- 7. Clean the coating in Primary crusher's rotors.
- 8. Inspect and mark the Damaged Castings Taper tip and three tooth cap in Rotors.
- 9. Cleaning of Damaged taper tip and three tooth caps casting by Drill bit and compressed air.
- 10. If crack found in taper tips castings Welding to be done in Taper tips with 3 tooth cap body by using Phinolloy **101** electrode and use the **Cobal arc 1mm** electrode for Taper tip Hard facing.
- 11. And also find the damages in 3 tooth caps castings top cover plates and Patch-up to be done with hordox plates.
- 12. Remove wedge piece, all tools and tackles.
- 13. Take out confined space token and ensure that nothing inside crusher
- 14. Close the door and take the trial.

Emergency / Emergency Shut OFF:

If body injury is there, first aid will be given and inform to the Safety department or Call Emergency number 3108/9865152222

Records/Annexure:

- 1. JSA is enclosed below.
- 2. Isolation Matrix.





MECHANICAL

Issued By: M.R Approved By: HOD-Mechanical

SOP FOR PRIMARY CRUSHER IN-SITU CASTING REPARING

JOB SAFETY ANALYSIS: (JSA)

Job Safety Analysis	Job: Primary crusher Insitu casting repairing	Date: 08 – 04 - 2020	Analysis by Section Engineer	Reviewed by: Section Head
Title of employee doing job: Section engineer	Supervisor: Section Engineer	Department: Mech	Section: LS CRUSHER	Approved by: HOD-Mechanical

Reqd./recommended PPE's: Safety Helmet, Safety shoe, Hand Gloves, Safety goggles. Nose mask.

Hand Gloves, Safety goggles. Nose mask.				-
Sequence of Basic Job Steps	Potential Hazards	Recommended Safe Job Procedure	What Could Go Wrong	Corrective Action
Open the inspection door	Body injury	Use only proper spanners to avoid slip / shear of bolt and nut during un screwing.	Spanners may slip and hit hands while un screwing. Bolt may shear/cut due to load	Check the condition of the bolt / nut and spanners.
Caught in between	Leg injury	First lock the two rotors with stoppers	Stoppers may be in damage condition.	Check the condition of stoppers
Struck up of drill bit while cleaning the sticky material.	Body injury	Use only certified drilling machines to avoid slip / shear of drill bit during cleaning.	Drill bit may have struck up and hit hands while cleaning. Drill bit may shear / cut during load	Check the condition of the drill bit / handle.
Hand Blower operation	Eye injury & Dust inhalation	Use only certified Hand blowers.	Power Cable damage	Check the condition of cable and certification to use.
Using the Cutting machine	Hand injury	Use only certified cutting sets	Cutting set fail	Check the condition of Hoses, cutting torch, Flash back arrester, Blankets,





MECHANICAL

Issue No. 02Rev. No: 00Effective Date: 01.11.2019SOP/MEC/168Issued By: M.RApproved By: HOD-Mechanical

SOP FOR PRIMARY CRUSHER IN-SITU CASTING REPARING

Pressure Quage Check the earth Using the Welding machine Hand injury Use proper Earth Use proper Earth connection (electric connection before doing the connection Shock) welding Spanners may Use only proper slip and hit hands spanners to while screwing. Body injury Close the inspection door avoid slip / shear Bolt may of bolt and nut shear/cut due to during screwing.

load

SL No	Activity	Isolation Type				
				Other		
		Electrical Energy			Energy	
1	Primary crusher In- situ casting repairingn		Apron feeder 211AF1 Drive	Primary Crusher 211CR1 Drive	Unloadin g Hopper Barricade d	Rotor to be locked
		of the Equipment	Belt conv 211BC1 Drive			