

DALMIA CEMENT (B) LIMITED - ARIYALUR



MECHANICAL DEPARTMENT

Issued By: M.R Approved By:

SOP for Bearing Mounting by Oil Bath

<u>Scope:</u> Bearing Mounting by Oil Bath <u>Responsibility:</u> Section Engineer Accountability: Section Head.

PPE:

Safety harness(Full body)

- 2. Safety helmet,
- 3. Safety shoe,
- 4. Nose Mask,
- 5. Hand gloves / Kevlar Gloves
- 6. Safety goggles

TOOLS:

- 1. Pyro meter
- 2. Fire extinguisher Foam Type.
- 3. Fire tender.
- 4. Clean oil (Probably Transformer Oil)
- 5. Oil Tub with Lid.
- 6. Steel Sling & "D" shekel.

Hazard Analys

<u>Risks associated:</u> <u>Mitigating Measures</u>

Hot Oil Spillage : Keep fresh water available for First aid.

Huge fire : keep the fire in control & monitor continuously.

Oil fire : avoid water entering with Hot Oil

Tilting of Oil Tub : Keep Legs as wide as possible (during Fabrication)

Sudden Ran fall Be prepare accordingly & arrange I side the shed if possible

SOP for Bearing Mounting by Oil Bath:

- > The surrounding area should be as clean and dirt free as possible.
- Heat the bearings in oil having high flash point, use Transformer oil.

DalmiaBHARAT CEMENT

DALMIA CEMENT (B) LIMITED - ARIYALUR



MECHANICAL DEPARTMENT

Issue No. 01 Rev. No: 02 Effective Date: 17.10.2017 SOP/MEC/115

Issued By: M.R Approved By:

SOP for Bearing Mounting by Oil Bath

- Make sure that both the oil as well as the container is clean and free of any contamination.
- ➤ Heat the oil and the bearing simultaneously. Do not put the bearing in hot oil as this would create "thermal stresses" in the bearing.
- The bearing should not be in direct contact with the heat source.
- The bearing may also be suspended in the oil bath with the use of a hanger.
- ➤ Bearings should normally be heated up to a temperature of around 120 degrees C. The larger spherical roller bearings may, depending on the size and the fit on the shaft, have to be heated up to a temperature of around 140 degrees C.
- Continuously monitor the temperature by using a temperature measuring device. Always keep the measuring point of the thermometer as near as possible to the inner ring so that the bearing temperature can be measured.
- After heating, any oil adhering to the bearing should be well drained off and the fitting surfaces should be carefully wiped clean.
- Use heat protective gloves or non fraying cloths. Never use cotton waste.
- Mounting of heated bearings, particularly large size ones, requires some skill. They should be quickly pushed on the shaft and positioned squarely against the shoulder. A slight twisting motion during fitting facilitates the mounting.
- Do keep in mind that there is always a risk that the bearing may cool down well before it reaches its final seating position.
- The entire heating process should be carried out as close to the assembly site as possible
- Hand over the used oil to stores

Emergency / Emergency Shut OFF:

1. If any injury takes place, provide First aid and inform to the Safety department or Call Emergency number 3108/9865152222

Records/Annexure: Job safety analysis.

JOB SAFETY ANALYSIS: (JSA)



DALMIA CEMENT (B) LIMITED - ARIYALUR



MECHANICAL DEPARTMENT

Issue No. 01 Rev. No: 02 Effective Date: 17.10.2017 SOP/MEC/115
Issued By: M.R Approved By:
SOP for Bearing Mounting by Oil Bath

Job Safety Analysis	Job: BearIng / Coupling replacement by oil Bath	Date: 01 – 09 - 2014	Analysis by Section Engineer	Reviewed by: Section head
Title of employee doing job: Section engineer	Supervisor:	Department:	Section: All	Approved by:
	Section Engineer	Mechanical	Sections	HOD. Machining

SI.No	Sequence of Basic Job Steps	Potential Hazards	Recommended Safe Job Procedure		
1	Oil Filling in the tub	Tub May Tile	Use proper tools	T. J. Tile	Keep The legs of the tub
2	Firing	Fire may propagate	Isolate the surroundings from fire propagation	Tub Tilt Fire uncontrolled	as wide as possible Monitor continuously & keep control measures available
3	Oil Heating	Oil Temperature may exceed & oil caught fire due to fire point	Monitor continuously, arrange reliever if out of the spot.	Oil splash while checking the temperature	Use Radiation Pyrometer.
4	Oil Heating	Oil caught fire	Keep the water away	Oil fire	Use "B" Type (foam) fire extinguisher by trained persons
5	Oil Heating	Hot Oil splash	Use pro[per protecting PPE		Keep first aid available
				Oil sash	(water)