



Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59

Issued By: M.R Approved By: HOD - INSTRUMENTATION

SOP FOR BACKING UP DISOMAT SATUS CONTROLLER

**Scope:** To back up the Disomat satus controller via laptop.

**Responsibility:** Instrumentation Engineer.

**Accountability:** Instrumentation Site In-charge.

#### **Tools required:**

Laptop

RS-232 cable


#### **Procedure:**

- 1) Turn on the laptop and connect the laptop with the appropriate **bin weighing port** via RS-232 cable.
- 2) Select "Electrical Lap", Password: electrical



3) Open "Disoplan" software







# DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR




#### **INSTRUMENTATION MANUAL**

Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59


Issued By: M.R Approved By: HOD - INSTRUMENTATION

SOP FOR BACKING UP DISOMAT SATUS CONTROLLER

4) Switch off and switch on the power supply for the display, once.



The appropriate display will be blinking as follows:



Note: In the meantime, steps 5-10 should be performed.

5) A new window will be opened. Click "New scan for devices"





Issue No. 01

#### DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR INSTRUMENTATION MANUAL



Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59

Issued By: M.R Approved By: HOD - INSTRUMENTATION


SOP FOR BACKING UP DISOMAT SATUS CONTROLLER



6) Select "Serial interface" and click "next"



7) Set the interface to "COM1" and click "Next"



8) Set Minimum






Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59

Issued By: M.R Approved By: HOD - INSTRUMENTATION


SOP FOR BACKING UP DISOMAT SATUS CONTROLLER




9) Set Maximum address to "1" and click "Next"



10) Set Number of devices to "1" and click "Next"



11) A new window named "Summary" will open. Click "Complete" in that window.





# DALMIA CEMENT (B) LIMITED - CEMENT PLANT ARIYALUR



INSTRUMENTATION MANUAL

Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59

Issued By: M.R Approved By: HOD - INSTRUMENTATION


SOP FOR BACKING UP DISOMAT SATUS CONTROLLER






(<u>NOTE:</u> If the summary window does not open or if the address is not established properly, switch off and switch on the power supply once and perform the steps 5-10 again).

12) Another window named "Disoplan" will be opened. Double click the COM address on it.



13) Enter "Set up" and click "Settings"








Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59


Issued By: M.R Approved By: HOD - INSTRUMENTATION

SOP FOR BACKING UP DISOMAT SATUS CONTROLLER

#### 14) Double click "Parameter"



15) Enter "File" and click "Export"








Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59


Issued By: M.R Approved By: HOD - INSTRUMENTATION


SOP FOR BACKING UP DISOMAT SATUS CONTROLLER

16) The parameters will be opened in a new window.



17) For backing up the parameters, Enter file and click "Save" and you can save the file wherever you want.









Issue No. 01 Rev. No: 02 Effective Date: 20.09.2017 SOP/INST/59

Issued By: M.R Approved By: HOD - INSTRUMENTATION

SOP FOR BACKING UP DISOMAT SATUS CONTROLLER

18) While returning, the windows have to be closed **one by one**. Follow the steps below.

**(**-----

