

ARIYALUR

INSTRUMENTATION DEPARTMENT

| Issue No. 02 | Rev. No: 00 | Effective Date: 01.11.2019 | | SOP/INST/62 | | | |
|--------------------------------------|-------------|----------------------------|-----------------------------------|-------------|--|--|--|
| Issued By: M.R | | | Approved By: HOD-Instrumenetation | | | | |
| SOP FOR CONFIGURING THE PROCESSOR IP | | | | | | | |

Procedure:

We have individual ABB PM864A Processor for each area, 10 no.s in total.



Processor has 4 Ports. CN1, CN2, COM3 and COM4.

COM4 Port is used for IP Configuration.

Connect the Tool Kit cable between COM4 and PC.

1) Click:

Start \rightarrow All programs \rightarrow ABB Industrial IT 800 XA \rightarrow Engineering \rightarrow Utilities \rightarrow IPConfig





ARIYALUR

INSTRUMENTATION DEPARTMENT

| Issue No. 02 | Rev. No: 00 | Effective Date: 01.11.2019 | | SOP/INST/62 | | | |
|--------------------------------------|-------------|----------------------------|-----------------------------------|-------------|--|--|--|
| Issued By: M.R | | | Approved By: HOD-Instrumenetation | | | | |
| SOP FOR CONFIGURING THE PROCESSOR IP | | | | | | | |





2) Once you click IP Config, a new window named IP Config will be opened





ARIYALUR


INSTRUMENTATION DEPARTMENT

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62

Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP

3) Click Connect in the IP Config tab





ARIYALUR

INSTRUMENTATION DEPARTMENT

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62

Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP



4) The connection will be in progress







ARIYALUR

INSTRUMENTATION DEPARTMENT


Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62

Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP



5) After getting connected, the primary ethernet interface IP- address, primary ethernet interface subnetmask and Toolport interface IP-address will display the present address.





ARIYALUR

INSTRUMENTATION DEPARTMENT


Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62


Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP



6) We can modify the primary ethernet interface IP-address, if we want







ARIYALUR


INSTRUMENTATION DEPARTMENT

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62

Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP

7) Click Set IP





ARIYALUR

INSTRUMENTATION DEPARTMENT


Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62

Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP



8) A confirmation window will be opened. Click \mathbf{OK} in the newly opened window





ARIYALUR

INSTRUMENTATION DEPARTMENT

Issue No. 02 Rev. No: 00 Effective Date: 01.11.2019 SOP/INST/62

Issued By: M.R Approved By: HOD-Instrumenetation

SOP FOR CONFIGURING THE PROCESSOR IP

9) The updated IP address window will be opened

