## MASSACHUSETTS INSTITUTE OF TECHNOLOGY HAYSTACK OBSERVATORY

Westford, Massachusetts 01886

February 24, 2011

# BRIGEN: Generator of Sky Brightness Images in FITS Format

#### Abstract

The brigen program is a part of the MAPS (MIT Array Performance Simulator) package. On input, it reads a list of celestial sources, and outputs a simulated brightness image in the form of a FITS file. The celestial sources are specified as elliptical Gaussians with the intensity, minor and major axes, position angle, and other parameters. Optionally, the user may provide one ore more external images in FITS file (or files) to be added to the output as its background. The brigen-generated images are suitable for further processing with the MAPS\_im2uv program, which applies the FFT to convert the brightness image into the visibility image. The latter in turn are used by the visgen program. The brigen program was created to replace the LOsim program. It is mainly based on \$SIM/LOsim/source/SumSources.c program.

## 1 BRIGEN Command line files and options

Usage:

brigen infile [outfile] [OPTIONS]

The infile is either a simulation project file or a source list file. The oufile is the name of FITS file to hold the generated image. If outfile is not present on the command line, brigen creates FITS file with the same base name as infile, but with the .fits extension.

n number, --mgrid number image RA grid size in pixels
 n number, --ngrid number image Dec grid size in pixels
 a angle, --rasize angle image RA size in angular units
 b angle, --decsize angle image Dec size in angular units

```
    -x angle, --racenter angle image RA center in angular units
    -y angle, --deccenter angle image Dec center in angular units
    -s filename, --srcfile filename name of the text file with specification of sources
    -i filename, --addimage filename name of a FITS file with image to be added to the output
    -h, --help help page
```

## 2 Angular units

The coordinates of the image center and its extents in Right Ascension (RA) and Declination (Dec) are specified in angular units. The angle format consists of a numerical value followed by the units specifier without whitespace in between. There are two kinds of numerical values: a real number and a triad, ±ddd:mm:ss or hh:mm:ss. The units specifiers after a real number are one of the following:

```
rad radians; deg degrees; ' arcminutes (\frac{1}{60} \text{ of a degree}); ' arcseconds (one double quote or two single quotes, \frac{1}{60} of an arcminute);
```

Examples of the angles in this format are: 0.17rad, 10deg, 112.35  $^{\prime},$  18000  $^{\prime\prime}$  , 36000  $^{\prime\prime}$  .

The triads are traditionally used for RA and Dec specification. The RA is usually given in hh:mm:ss, where hh is "hours", mm "minutes of hour", and ss seconds as units of time. The seconds can be given as a fraction with decimal point. The hh:mm:ss triad must be immediately followed by the hms units specifier. The Dec is preferably specified as a  $\pm ddd:mm:ss$  triad, where  $\pm ddd$  is "degrees", mm is "arcminutes", and ss is "arcseconds", which may be a fraction with the decimal point.

Examples of this format are: 1:7:5dms; -21:52:43.765dms; 3:0:0hms; 17:23:34.29hms.

It is important to note that on the command line an angle parameter cannot contain whitespace. In the simulation project files the blanks and tabulations are allowed between number and units. For example, 132 MHz; 15:30:00 hms etc.

## 3 Celestial source list

The celestial sources generated by brigen have the elliptical form. Within each ellipse the brightness is distributed as the elliptical Gaussian function. It has its maximum at the ellipse center and falls off towards the periphery. The list of Gaussian elliptical celestial sources can be provided either in a separate text file or as a section in the simulation project file. In either case it consists of lines, each line specifying a single source. The line consists of the following items:

Min.ax.

PA,

```
where

ID is any identifier not longer than 10 characters,
Intens. is the source intensity (i.e. the I Stokes component),
Q, U, V are the Stokes components describing the polarization,
SI is the source spectral index,
x is the ellipse center RA coordinate in arcseconds,
y is the ellipse center Dec coordinate in arcseconds,
```

Intens. Q U V SI x y Maj.ax.

Maj.ax. is the ellipse major axis in arcseconds,

Min.ax. is the ellipse minor axis in arcseconds,

PA is the position angle of the ellipse major axis in degrees.

The position angle is counted clockwise from the meridian going through the source center. It is actually the angle between the meridian and the major axis.

Note that the current version of brigen ignores the parameters Q, U, V, and SI.

# 4 Import of external images

Additional images can be imported from FITS files whose names are given at -i or --addimage command line options. Generally, there may be several FITS files, each one at individual -i option. The images in these files must

have the same RA and Dec numbers of pixels as given at -m (--mgrid) and -n (--ngrid) options. The resultant image in this case is the sum of the external images and the image generated from the source list.

Note that the current **brigen** version ignores the units given at the BUNIT keyword in the external FITS file headers, producing no scaling before the image summation.

## 5 Sources as elliptical Gaussian distributions

The brigen program composes the brightness image as the superposition of elliptical Gaussians, one for each source,

$$G(x,y) = \frac{I}{2\pi\sigma_x\sigma_y} e^{-\left(\frac{x^2}{\sigma_x^2} + \frac{y^2}{\sigma_y^2}\right)},\tag{1}$$

where x and y are in the ellipse axes coordinate system (i.e. shifted and rotated with respect to the original axes),  $\sigma_x$  and  $\sigma_y$  are its major and minor axes, and I is the source intensity (flux). A Gaussian is not calculated for every node of the image grid. To save computational resources, it is only evaluated within an ellipse drawn around the source center. The ellipse parameters are such that the Gaussian values outside the ellipse are negligibly small and can be assumed equal to zero.

# 6 Simulation project file

The brigen program interface is based on the idea of a simulation project (or simply project) file common for all the MAPS components. Usually MAPS is utilized for solving a problem through simulation. The solution may include several stages: generation of a brightness image with brigen; its conversion into the visibility image with MAPS\_im2uv; array observation simulation to produce visibilities for all the array baselines with visgen; storing the vizibilities obtained from visgen in the UVFITS file using maps2uvfits. Currently the parameters used at the stages are stored in several files. Instead of managing many different text files with the parameters for different programs describing a single simulation it is suggested that all the frequently-changed parameters be gathered in a single project file. When a MAPS program is launched, the user provides the simulation project file name on the command line. For example, if the project name is project1.txt, the

brigen invocation may look like:

## \$ brigen project1.txt

If all the necessary parameters and links to external parameter/data files are present in the project1.txt file, the program will execute and save its result.

The project file consists of several sections, one for each of the MAPS programs. At present time, only brigen and visgen sections are implemented. The project file structure may be described as follows.

The project file can have as many sections as needed. If, for example, the user currently works with only the brigen program, the project file may include just the brigen section:

It is supposed that most of the parameters specified inside the program section in the project file can also be given on its command line with corresponding options. The command line options have higher priority over the parameters in the project file. Thus the user by entering a parameter as a command line option can override the value of the corresponding parameter in the project file. For example, suppose the brightness grid sizes are set in

the project file neb374.txt with the line

```
imgrid_pixels 1024, 1024
```

The user can change the grid dimensions to  $2048 \times 2048$  for a particular brigen execution by running it with the following options:

```
$ brigen neb374.txt -m 2048 -n 2048
```

All other parameters will remain intact.

The convenience of having all the parameters in one place from the user point of view is obvious. For the MAPS developer the project-based architecture is also beneficial, because all the MAPS programs are supposed to use the same piece of software to scan and parse the project file. The lexical analyzer (scanner) and the syntax analyzer (parser) are written with the use of standard generators, Flex and Bison (former Lex and Yacc). They will be described in a separate section below.

## 7 Project file grammar

The simulation project file has its own formal language described with the grammar. The grammar consists of two parts: the lexical analyzer or scanner and the syntax analyzer or parser. Both are located in the directory \$SIM/parser.

The scanner is described as a set of regular expressions defining indivisible lexical elements (lexemae) of the project language. For example, the lexemae ANGLE, FREQ, and DUR are described as

```
ANGLE {NUM}[ \t]*("\""|"''"|"deg"|"rad")

FREQ {NUM}[ \t]*("mHz"|"Hz"|"kHz"|"GHz")

DUR {NUM}[ \t]*("us"|"usec"|"ms"|"msec"|"s"|"sec"|"min"|"hr")
```

A more elementary lexema NUM for any integer or real number has description

```
D [0-9]
L [a-zA-Z_]
E [Ee][+-]?{D}+
FLOATO [+-]?{D}+{E}
FLOAT1 [+-]?{D}*"."{D}+{E}?
```

```
FLOAT2 [+-]?{D}+"."{D}*{E}?

FLT {FLOAT0}|{FLOAT1}|{FLOAT2}

INT [+-]?{D}+

NUM {FLT}|{INT}
```

The scanner is stored in the file \$SIM/parser/read\_prj.l. It is compiled into the C program lex.yy.c with the standard UNIX tool Flex (former Lex). Each call to lex.yy.c returns another lexema read from the project file. The scanner subroutine is sequentially called by the parser.

The parser is specified as the BackusNaur form (BNF) in the file \$SIM/parser/read\_prj.y. It is compiled into the C program read\_prj.tab.c with the standard UNIX tool Bison (former Yacc). The BackusNaur form is a tree-like structure comprising all possible patterns for the project language sentence patterns.

The proposed grammar is common for all the MAPS programs. All the data formats, such as lists of sky sources, lists of array antenna coordinates, brigen and visgen parameters etc. are specified in BNF in a single file. This makes future changes or corrections to the data formats significantly easier.

One project file for several programs allows them to peek into the parameters of each other. For example, the field-of-view dimensions and its center coordinates in **visgen** section, if not specified, may be assumed equal to those from the **brigen** section.

The formal description of the project file syntax and its automated parsing allows good diagnostics of the errors in the project data. The parser catches any syntax error and reports the file name and the line where the error is encountered.

# 8 Image parameters in project file brigen section

In the simulation project file the parameters are specified in the format:

```
<parameter-name> <value>[,<value>...] [<comment>]
```

The comments are ignored by the scanner. They can have arbitrary format, standard for conventional languages: either # <any-text> or // <any-text>

## or /\* <any-text> \*/

All the **brigen** parameters are summarized below. In parentheses the corresponding command line options are given).

#### imgrid\_pixels <number>, <number>

Brightness image size in pixels in RA and Dec dimensions (-m <number> and -n <number>).

#### imcenter\_radec <angle>, <angle>

Brightness image center RA and Dec coordinates (-x <angle> and -y <angle>).

#### imsize\_radec <angle>, <angle>

Brightness image extents in RA and Dec (-a <angle> and -b <angle>).

#### srclist <file-name>

Name of the file where the simulated celestial sources are specified (-s <file-name>).

#### addimage <file-name> or addimage here

Name of a FITS file with external image (-i <file-name>). The word here instead of the file name means that the source list lines immediately follow.

#### imfitsout <file-name>

Name of a FITS file where the simulated brightness image will be saved (a second file name on the command line).

All these parameters are optional. All the parameters must occur in the list only once, with one exception: several addimage lines may appear to specify several FITS files with external brightness images.

The list of celestial sources can be given directly in the simulation project file. To do this, the sourcelist parameter should have the here keyword in place of the <file-name>. The contents of the source list file should follow this header, and the operator end srclist should close the list. Here is an example of the direct source specification:

#### srclist here # Type, Intens., Q, U, V, SI, Maj.ax, Min.ax, PA х, у, 0 2 8500.0 6000.0 1000.0 SrcEll1 0 0 300.0 30.0 SrcEll2 7 2 6000.0 8500.0 3000.0 800.0 60.0 0 0

```
SrcCirc3 6 0 0 0 2 0000.0 5000.0 1000.0 1000.0 00.0 SrcCirc4 2 0 0 0 2 -5000.0 -9000.0 600.0 600.0 00.0 end srclist
```

## 9 A simulation project example

Below is given an example of a simulation project file mwasim01.txt. It contains both brigen and visgen sections. Although the visgen program currently does not use the project files, both visgen and brigen sections are checked for incorrect syntax even if the file is used by brigen only. If a section is not needed at the moment, it

```
/***************
 * mwasim01
 * MAPS simulation example project
 * brigen and visgen sections are present
 ***********************************
mwasim01
               simulation
#
# brigen: generation of the brightness image composed
#
         of the sources from 'srclist'
#
              section
brigen
imgrid_pixels
               1024, 1024 # Brightness grid dims. in pixels
imcenter_radec
               7:39:24 hms, -26:25:52.0 dms # FOV center RA, Dec
imsize_radec
               10 deg, 36000" # Grid dimensions along RA, DEC
srclist
               here
#Type Intens. Q U V SI
                                     Maj.ax Min.ax PA
                        X
       0.05 0 0 0 2
                     0000.0
                                       20.0
                                              20.0
                                                    0.0
Circ1
                             0000.0
Circ2
       0.05 0 0 0 2 -9000.0 0000.0
                                       20.0
                                              20.0
                                                    0.0
Circ3
       0.05 0 0 0 2 0000.0 -9000.0
                                       20.0
                                              20.0 0.0
       0.05 0 0 0 2 9000.0 0000.0
                                              20.0 0.0
Circ4
                                       20.0
Circ5
       0.05 0 0 0 2
                     0000.0 9000.0
                                              20.0 0.0
                                       20.0
Circ6
       0.05
            0 0 0 2
                      6364.0
                             6364.0
                                       20.0
                                              20.0
                                                   0.0
       0.05 0 0 0 2 -6364.0 6364.0
Circ7
                                       20.0
                                              20.0 0.0
Circ8
       0.05 0 0 0 2 6364.0 -6364.0
                                       20.0
                                              20.0 0.0
                                              20.0 0.0
       0.05 0 0 0 2 -6364.0 -6364.0
Circ9
                                       20.0
Ellip10 5
             0 0 0 2 8500.0 6000.0
                                     1000.0
                                             300.0 30.0
```

```
Ellip11 7
             0 0 0 2 6000.0 8500.0 3000.0 800.0 60.0
Circ12
             0 0 0 2 0000.0 5000.0 1000.0 1000.0 0.0
Circ13 2
             0 0 0 2 -5000.0 -9000.0 600.0 600.0 0.0
Ellip14 1
             0 0 0 2 -9000.0 -5000.0 500.0 100.0 0.0
Ellip15 10
             0 0 0 2 -4000.0 -4000.0 10000.0 500.0 40.0
Ellip16 1
             0 0 0 2 0000.0 0000.0
                                       700.0 300.0 10.0
            end
                   srclist
addimage
           extimg1.fits
addimage
           extimg2.fits
imfitsout
           brightness_image_mwasim01.fits # Output file
    end
         brigen
# visgen: conversion of the source visibility image after
         MAPS_im2uv into the visibility image generated
#
         by the radiotelescope specified in 'array' file.
visgen section
         /home/benkev/maps/array/mwa_32.txt # File with array coords
array
visout
         test01_Visibility.dat
                                    # Output file
obsspec
          here # Observation specifications
FOV_center_RA =
                 7:39:24.38467 hms
FOV_center_Dec = -26:25:52.0
                                dms
FOV_size_RA = 36e3"
FOV_size_Dec = 36000.0 ''
Corr_int_time = 2.0 min
Corr_chan_bw = 0.032 MHz
Scan_start = GHA - 7.8237889
Scan_start = 2006:265:16:00:00.3573 ydhms
 Scan_duration = 8.0 s
 Central_freq = 140 MHz
  Bandwidth
              = 32 kHz
Endscan
end
     obsspec
          test01_UVdata.txt
textout
   end
        visgen
```

#### end mwasim01

This project may be given to **brigen** on its command line as below. Note that since the project file includes all the necessary parameters, no command line options are required:

### \$ brigen mwasim01.txt

The source list is inside the project file. Two external images from files extimg1.fits and extimg2.fits will be added to the generated elliptical Gaussian sources. The result will be saved in file brightness\_image\_mwasim01.fits.

Suppose the user decides to try to generate the same image on a finer grid. Or, for example, the grid dimensions are provided as parameters in shell script. Then the command line may look like this:

\$ brigen mwasim01.txt -m 3072 -n 3072

If the user wishes to add one more external image to the result, then he or she calls **brigen** with the corresponding option:

\$ brigen mwasim01.txt -m 3072 -n 3072 -i extimage5.fits

If one desires to change the source list to another one that resides in an external file, it can be provided on the command line:

\$ brigen mwasim01.txt -i extimage5.fits -s SourceList\_test01.txt

Then the source list in the project file will be ignored, because the command line options have the higher priority over the project file parameters.